



Broadcom NetXtreme Ethernet Adapter Diagnostic User's Guide

B57diag Version 6 • Date 03/30/04

**Prepared by: Tak Tomita
Updated by: Paul Nguyen, Austin Hui, Carlton Joseph**

Copyright © 2000-2004 Broadcom Corporation
All Rights Reserved

No part of this document may be reproduced, in any form or by any means, without permission in writing from Broadcom Corporation.

Broadcom Corporation reserves the right to make changes to the products or information contained in this document without notice. No liability is assumed as a result of their use or application. No rights under any patent accompany the sale of any such products or information.

Epigram, InsideLine, and iLine10 are trademarks of Broadcom Corporation.

Broadcom Corporation
16125 Alton Parkway
Irvine, CA 92619-7013
www.broadcom.com

TABLE OF CONTENTS

1	INTRODUCTION	1
2	PREREQUISITES.....	2
3	DIAGNOSTIC TESTS	3
3.1	TEST NAMES	3
3.2	ERROR CODES.....	3
3.3	TEST DESCRIPTIONS.....	3
3.3.1	A1. Indirect Register Test	3
3.3.2	A2. Control Register Test	4
3.3.3	A3. Interrupt Test.....	4
3.3.4	A4. BIST.....	4
3.3.6	B1. Scratch Pad Test	4
3.3.7	B2. BD SRAM Test	5
3.3.8	B3. DMA SRAM Test.....	5
3.3.9	B4. MBUF SRAM Test.....	5
3.3.10	B5. MBUF SRAM via DMA Test.....	6
3.3.11	B6. External SRAM Test.....	6
3.3.12	C1. EEPROM Test	6
3.3.13	C2. CPU Test	7
3.3.14	C3. DMA Test.....	7
3.3.15	C4. MII Test	7
3.3.16	C5. VPD Test.....	8
3.3.17	C6. ASF Test	8
3.3.19	D1. Mac Loopback Test	8
3.3.20	D2. Phy Loopback Test	9
3.3.21	D3. RJ45 Loopback Test	9
3.3.23	D4. 1G False Carrier Test	9
3.3.24	D5. MII Miscellaneous Test	9
3.3.25	D6. MSI Test	9
4	COMMAND LINE OPTION PARAMETERS.....	11
5	EEPROM.TXT FORMAT.....	21
6	USER INTERFACE COMMANDS.....	24
7	SPECIAL INSTRUCTION.....	29
8	SAME SYSTEM SEND/RESPOND TEST	30
8.1	IDENTIFYING A REFERENCE DEVICE.....	30
8.2	TESTING THE DUT AGAINST THE REFERENCE DEVICE	30
8.3	OTHER OPTIONS FOR THE SEND/RESPOND TEST	30
9	TEST AND FUNCTIONS DESCRIPTION	31
9.1	VPDWRITE	31
9.2	VPDREAD	31
9.3	SEMODE	31
9.4	SERREAD	32
9.5	SEWRITE.....	32

9.6	SECFG	33
9.7	SEPRG	40
9.8	UPGFRM	41
9.9	SEVER	41
9.10	SECHKSUM	41
9.11	SEDUMP	41
9.12	ASFCFG	42
9.13	FLSHMODE	42
9.14	FLSHREAD	42
9.15	CHKPXE	42
9.16	DIR	42
9.17	ERASE	42
9.18	PXEPRG	43
9.19	FLSHDEV	43
9.20	BITBANG	43
9.21	SELOCK	43
9.22	SETORTURE	43
9.23	SEINIT	44
9.24	SEARB	44
9.25	SEPROTECT	44
9.26	SELCLOCK	45
9.27	SEMAP	45
9.28	SETWOL	45
9.29	SETPXE	45
9.30	SETASF	45
9.31	SECOMP	46
9.32	DRESET	46
9.33	USERBLOCK	46
9.34	SETMBA	46
9.35	LOADFW	47
9.36	CPUDRT	47
9.37	CPUDTT	48
9.38	CPUTRACE	48
9.39	HALTCPU	48
9.40	LOADBOOTCODE	49
9.41	DISASM	49
9.42	STEP	49
9.43	GO	49
9.44	SHOWGPR	50
9.45	PC	50
9.46	SELECT	50
9.47	BREAKPOINT	50
9.48	U	50
9.49	TRAP	50
9.50	CPUINFO	51
9.51	CPUGPRSTATUS	51
9.52	CPUGPRRESTART	51
9.53	DMAW	51
9.54	DMAR	52
9.55	DMA_H	54
9.56	DMA_D	54
9.57	MACLPK	54
9.58	NICSTATS	55
9.59	RINGINDEX	57
9.60	BLAST	58

9.61	PHYCTRL	60
9.62	TXPKT	60
9.63	STATUSBLK	61
9.64	STSBLK	62
9.65	TXCFG	63
9.66	RXCFG	63
9.67	TPROT	64
9.68	QSTAT	64
9.69	DRVRCFG	64
9.70	IRT	65
9.71	MACMRD	65
9.72	MIIMRD	65
9.73	PCIMRD	66
9.74	MWRITE	66
9.75	MREAD	66
9.76	MDEV	67
9.77	MIIMODE	67
9.78	LBERTRAM	67
9.79	DBERTRAM	68
9.80	BERTSTATS	68
9.81	RM	68
9.82	MRLOOP	68
9.83	PHYMSE	69
9.84	INITPHY	69
9.85	MEMSEARCH	69
9.86	READ	69
9.87	WRITE	70
9.88	POLL	71
9.89	SETBIT	72
9.90	CLEARBIT	73
9.91	READBIT	73
9.92	CREAD	74
9.93	CWRITE	74
9.94	VPDTEST	74
9.95	REGTEST	75
9.96	MIITEST	75
9.97	MSI	75
9.98	MEMTEST	76
9.99	SETEST	76
9.100	BIST	77
9.101	NICTEST	77
9.102	INTRTEST	77
9.103	PKTTEST	78
9.104	CPUTEST	78
9.105	DMATEST	78
9.106	TESTE	79
9.107	TESTD	79
9.108	ASFTTEST	79
9.109	BUSTEST	80
9.110	SRAMTEST	81
9.111	MSITEST	81
9.112	ROMTEST	82
9.113	GPIOTEST	82
9.114	CPUDIAG	82
9.115	PCICFGTEST	83

9.116	PETEST	83
9.117	ERRCTRL	83
9.118	SEDVT	84
9.119	MIIMISCTEST	84
9.120	CPUGPRTEST	84
9.121	PMDCFG	85
9.122	PMPD	85
9.123	INTR	85
9.124	INTRCTRL	86
9.125	INTT	86
9.126	MBUF	86
9.127	LOADDRV	87
9.128	UNLOADDRV	88
9.129	MACHALT	88
9.130	FTQ	88
9.131	ADDMC	89
9.132	DELMC	89
9.133	TXMACDES	89
9.134	TXMACSRC	89
9.135	CHKLDDRV	89
9.136	VLANTAG	90
9.137	REG	90
9.138	DEBUG	90
9.139	GPIOWRITE	91
9.140	GPIOREAD	91
9.141	PXECPY	91
9.142	DEVICE	91
9.143	VERSION	92
9.144	HELP	92
9.145	?	92
9.146	RADIX	92
9.147	NOLOG	93
9.148	LOG	93
9.149	PCIINIT	93
9.150	PCISCAN	93
9.151	DOS	94
9.152	DIAGCFG	94
9.153	RESET	96
9.154	SMBUS	96
9.155	CLS	96
9.156	LOOP	97
9.157	DBMODE	97
9.158	ASF	97
9.159	NEW	97
9.160	ASFPRG	98
9.161	SLEEP	98
9.162	FILLPATTERN	98
9.163	INP	98
9.164	OUTP	99
9.165	SWITCH	99
9.166	DO	99
9.167	TXFILL	100
9.168	WBUF	100
9.169	RBUF	100
9.170	CPBUF	101

9.171	ECHO	101
9.172	PAUSE.....	101
9.173	VERBOSE.....	101
9.174	BEEP	102
9.175	VAR	102
9.176	MEMINFO.....	102
9.177	DELVAR	102
9.178	REGDUMP	102
9.179	REGCOMP.....	103
9.180	REGRESTORE.....	103
9.181	READBR	103
9.182	WRITEBR.....	103
9.183	WRITEBR.....	104
9.184	FINDBRIDGE.....	104
9.185	BRIDGE	104
9.186	PERE	104
9.187	PERD.....	104
9.188	PECLR	104
9.189	PECHK.....	105
9.190	SECFG1	105
9.191	SECFG2	105
9.192	SECFG3	106
9.193	SECFG4	107
9.194	CPUFETCH.....	107
9.195	EXIT.....	107
9.196	QUIT	107
10	ERROR MESSAGES.....	109

1 Introduction

This program runs in two modes: Manufacturing mode and Engineering mode. The mode is determined with the command line option or the configuration file. When the program is running in manufacturing mode, it starts to run all tests in the configuration. If it detects an error, it displays an error and exits the program. When the program is in engineering mode, it prompts user to enter commands. The commands are explained in the later chapters. This document provides the information on configuration file specification, command line options and engineering diagnostic commands on Broadcom NetXtreme Ethernet adapter, in particular to check out the functionality of the BCM5700-5705 and its related components. In general, this program has a set of default configuration. It is overwritten by configuration file. The command line option overwrites both default and the configuration files.

2 Prerequisites

The engineering diagnostic is executed under DOS protected mode.

OS: Dos 6.22 or Win95/98 DOS.

Software: b57diag.exe

Input File List: The following files should be found in the same location of the b57diag.exe.

ee57xxyy.yy (TX & RX CPUs Firmware file, xx chip type, yy version number)

eeeprom.bin (Serial EEPROM/FLASH config input file)

cpu.bin or cpu05.bin (CPU Instruction test)

cpudiag.bin or cpudg05.bin (CPU Accessing test)

flshdiag.bin or flashdg05.bin

config.sys

himem.sys

Output File List:

The following file may be generated in run time depending execution option(s).

diagcfg.bin

3 Diagnostic Tests

The tests are divided into four groups: Register Tests, Memory Tests, Miscellaneous Tests, and Data Tests. They numbered as group 'A', 'B', 'C', and 'D'.

3.1 Test Names

Group A.

- A1. Indirect Register Test
- A2. Control Register Test
- A3. Interrupt Test
- A4. BIST
- A5. PCI Cfg Register Test

Group B.

- B1. Scratch Pad Test
- B2. BD SRAM Test
- B3. DMA SRAM Test
- B4. MBUF SRAM Test
- B5. MBUF SRAM via DMA Test
- B6. External SRAM Test

Group C.

- C1. EEPROM Test
- C2. CPU Test
- C3. DMA Test
- C4. MII Test
- C5. VPD Test
- C6. ASF Test
- C7. ROM Expansion Test

Group D.

- D1. Mac Loopback Test
- D2. Phy Loopback Test
- D3. RJ45 Loopback Test
- D4. 1G False Carrier Test
- D5. MII Miscellaneous Test
- D6. MSI Test

3.2 Error Codes

The Error Codes are presented in Section 9 - ERROR MESSAGES.

3.3 Test Descriptions

3.3.1 A1. Indirect Register Test

Command: regtest -i

Function: Using indirect addressing method, writing increment data into MAC hash Register table and read back for verification. The memory read/write is done 100 times while increment test data.

Default: Test Enabled

3.3.2 A2. Control Register Test

Command: regtest

Function: Each Register specified in the configuration contents read only bit and read/write bit defines. The test writing zero and one into the test bits to insure the read only bits are not changed, and read/write bits are changed accordingly.

Default: Test Enabled.

3.3.3 A3. Interrupt Test

Command: intrtest

Function: This test verifies the interrupt functionality. It enables interrupt and waits for interrupt to occur. It waits for 500ms and reports error if could not generate interrupts.

Default: Enabled

3.3.4 A4. BIST

Command: bist

Function: Hardware Built-In-Self-Test (BIST). This test initiates BIST, and wait for the test result returned by hardware.

Default: Due to the intermittent failure, this test is currently disabled by default

3.3.5 A5. PCI Cfg Register Test

Command: pcicfg

Function: This test verifies the access integrity of the PCI config registers.

3.3.6 B1. Scratch Pad Test

Command: memtest -s

Function: This test tests the scratch pad SRAM on board. The following tests are performed:

Data Pattern Test: Write test data into SRAM, read back to ensure data is correct. The test data used is 0x00000000, 0xffffffff, 0xaa55aa55, and 0x55aa55aa.

Alternate Data Pattern Test: Write test data into SRAM. Write complement test data into next address. Read back both data to insure the data is correct. After the test, the program reads back data one more time to insure the data stays correct. The test data used is 0x00000000, 0xffffffff, 0xaa55aa55, and 0x55aa55aa.

Address Test: Write each address with unique increment data. Read back data to insure data is correct. After fill the entire data with the unique data, the program reads back data again to insure data stays the same.

WalkingOne bit Test: For each address. Data one is written and read back for testing. Then shift the data left one bit, so the data becomes two and do the same test again. It repeats for 32 times until the test bit is shifted out of test data. The same is test is repeated for entire test range.

Pseudo Random Data Test: A pre-calculated pseudo random data is used to write a unique data into each test RAM. After the first pass the test, the program reads back one more time to insure data stays correct.

Default: Enabled

3.3.7 B2. BD SRAM Test

Command: memtest -b

Function: This test tests the BD SRAM. This performs exact the same way of testing as described in B1. Scratch Pad Test.

Default: Enabled

3.3.8 B3. DMA SRAM Test

Command: memtest -d

Function: It tests DMA SRAM by performing the tests described in test B1. The Scratch Pad Test.

Default: Enabled

3.3.9 B4. MBUF SRAM Test

Command: memtest -m

Function: It tests DMA SRAM by performing the tests described in test B1. The Scratch Pad Test.

Default: Enabled

3.3.10 B5. MBUF SRAM via DMA Test

Command: memtest -x

Function: Eight test pattern data are used in the test. They are described below. A 0x1000 sized data buffer is used for this test. Before each pattern test, the buffer is initialized and filled with the test pattern. It then, performs size 0x1000 transmit DMA from host buffer to NIC MBUF memory. Verify the data integrity in MBUF against host memory and repeat the DMA for the entire MBUF buffer. Then it performs receive DMA from NIC to host. The 0x1000-byte test buffer is cleared to zero before each receive-DMA. Verify the data integrity and test is repeated for the entire MBUF SRAM range.

Test Pattern	Description
"16 00's 16 FF's"	Full the entire host DMA buffer with 16 bytes of 00's and then 16 bytes of FF's.
"16 FF's 16 0's"	Full the entire host DMA buffer with 16 bytes of 00's and then 16 bytes of FF's.
"32 00's 32 FF's"	Full the entire host DMA buffer with 32 bytes of 00's and then 32 bytes of FF's.
"32 FF's 32 00's"	Full the entire host DMA buffer with 32 bytes of FF's and then 32 bytes of 00's.
"00000000's"	Full the entire host DMA buffer with all zeros.
"FFFFFFFF's"	Full the entire host DMA buffer with all FF's.
"AA55AA55's"	Full the entire host DMA buffer with data 0xAA55AA55.
"55AA55AA's"	Full the entire host DMA buffer with data 0xAA55AA55.

Default: Enabled

3.3.11 B6. External SRAM Test

Command: memtest -e

Function: It tests DMA SRAM by performing the tests described in test B1. The Scratch Pad Test.

Default: Disabled

3.3.12 C1. EEPROM Test

Command: setest

Function: An increment test data is used in EEPROM test. It fills the test data into the test range and read back to verify the content. After the test, it fills data with zero to clear the memory.

Default: Enabled

3.3.13 C2. CPU Test

Command: cputest

Function: This test opens the file cpu.bin. If file exists and content is good, it loads code to rx and tx CPU and verifies CPU execution.

Default: Enabled

3.3.14 C3. DMA Test

Command: dmatest

Function: Both high and low priorities DMA are tested. It moves data from host memory to NIC SRAM, verifies data, and then moves data back to host memory again to verify data.

Default: Enabled

3.3.15 C4. MII Test

Command: miitest

Function: The function is identical to A2. Control Register Test. Each Register specified in the configuration contents read only bit and read/write bit defines. The test writing zero and one into the test bits to insure the read only bits value are not changed, and read/write bits are changed accordingly.

Default: Test Enabled.

Default Register table

The test will try to read the register configuration file 'miireg.txt' for the register defines. If the file does not exists, the following table is used:

Offset	R/O Mask	R/W Mask
0x00	0x0000	0x7180
0x02	0xffff	0x0000
0x03	0xffff	0x0000
0x04	0x0000	0xffff
0x05	0xffff	0x0000
0x06	0x0001	0x0000
0x07	0x0800	0xb7ff
0x08	0xffff	0x0000
0x09	0x0000	0xff00
0x0a	0x7c00	0x0000
0x10	0x0000	0xffbf
0x11	0x3300	0x0000

0x19	0x001f	0x0000
0x1e	0x0000	0xffff
0x1f	0x0000	0xffff

3.3.16 C5. VPD Test

Command: vpdtest

Function: It saves the content of VPD first before perform the test. Once it is done, it writes one of the five pattern test data, 0xff, 0xaa, 0x55, increment data, or decrement data, into VPD memory. By default, increment data pattern is used. It writes and reads back the data for the entire test range, and then restores the original content.

Default: Disabled

3.3.17 C6. ASF Test

Command: asftest

Function:m

1. Reset test.

Setting reset bit, poll for self-clearing. Verify reset value of registers.

2. Event Mapping Test

Setting SMB_ATTN bit. By changing ASF_ATTN LOC bits, verify the mapping bits in TX_CPU or RX_CPU event bits.

3. Counter Test

Clear WG_TO, HB_TO, PA_TO, PL_TO, RT_TO bits by setting those bits. Make sure the bits clear.

Clear Timestamp Counter. Writing a value 1 into each PL, PA, HB, WG, RT counters. Set TSC_EN bit.

Poll each PA_TO bit and count up to 50 times. Check if PL_TO gets set at the end of 50 times. Continue to count up to 200 times. Check if all other TO bits are set and verify Timestamp Counter is incremented.

3.3.18 C7. ROM Expansion Test

Command: romtest

Function: This function tests the ability to enable/disable/access the expansion rom on the device.

3.3.19 D1. Mac Loopback Test

Command: pkttest -m

Function: This is internal loopback data transmit/receive test. It initializes MAC into internal loopback mode, and transmits 200 packets. The data should be routed back to

receive channel and receive by the receive routine, which verifies the integrity of data. One Giga bit rate is used for this test.

Default: Enabled

3.3.20 D2. Phy Loopback Test

Command: pkttest -p

Function: This test is same as D1. Mac Loopback Test except, the data is routed back via physical layer device. One Giga bit rate is used for this test.

Default: Enabled

3.3.21 D3. RJ45 Loopback Test

Command: pkttest -e

Function: This is external loopback test. From the UUT point of view, no loopback mode is configured. The data expected to be routed back by RJ45 loopback connector. 10M/s, 100M/s, and 1000M/s are used for this test.

Default: Disabled

3.3.23 D4. 1G False Carrier Test

Command: None

Function: This test executes the same procedure as test D3 and tests to see if a *false carrier* was detected at the end of the test. The -l200, -dispgbpkt, -disppkt and -errlimit DOS command line options were added to configure a number of operational parameters. The details of the command line options are provided in the "COMMAND LINE OPTION PARAMETERS" section.

Default: Disabled

3.3.24 D5. MII Miscellaneous Test

Command: None

Function: This function tests the auto-polling and phy-interrupt capabilities. These are the functionalities of the phy.

Default: Enabled

3.3.25 D6. MSI Test

Command: msitest

Function: Testing Message Signaled Interrupt Function to see if it handles this interrupt correctly.

Default: Disabled

4 Command line option parameters

When users invoke this program, a set of option parameter can be used to overwrite the configuration file or the default configuration. This section summarizes the options. The options are case sensitive.

-mfct <filename> updates the PCI SSID and SVID

Use this option to modify the PCI SSID and SVID stored in NVRAM. The new SSID and SVID are specified in the file <filename>. The format of <filename> is specified in the "EEPROM.TXT format" section below.

-sil suppresses warning messages of the "-firm" command

The warning message, "Boot code file and device type incompatible", produced by the "-firm" command is not displayed when the "-sil" command line parameter is entered before the "-firm" command. The "-firm" command is described below.

-rf <x> selects a reference device to use during external loopback

Use this option with the external loopback test D3 to select a reference card. During the external loopback test the physical loopback can be provided with a RJ45 loopback plug or a CAT5 cable connected to a reference device (which loops back the data).

-lbe g:h:t define the number of packets to use during external loopback

Selects the number of packets to send during the external loopback test D3 (g ,h ,t are the gigabit, hundred megabit, and ten megabit packet counts respectively) (default values are g=2000, h=1000, t=600). It is mandatory that all packets counts are entered with this command line option.

-ckdev <xy> executes diagnostic only x=chip rev and y=metal rev

If <xy> does not match the device being accessed diagnostics will not execute. Use this option on a production line to verify that only chips of a specific rev are run with diagnostics and all others fail.

-l200 <m200> controls the number of 200 packets to send

This option is used for the D4, "1G False Carrier", loopback test. During the test packets are sent out in groups of 200. The user specified <m200> value determines the number of 200 packet groups to send out. The default value is <m200> =50 or 50 groups of 200 packets.

-disppkts display the packet count during the progress of the test

This option is used for the D4, “1G False Carrier”, loopback test. On long-term test this option is entered to display the packet count every 20,000 packets to let a user know the test is operating normally and not frozen.

-dispgbend display the packet count at the end of the test

This option is used for the D5, “1G False Carrier”, loopback test. This option is entered to print out the final packet count at the end of the test.

-errlimit <lim> controls the number of errors seen before the test fails

This option is used for the D5, “1G False Carrier”, loopback test. The default value is <lim> =3.

-pktf0 packet data pattern is alternating 64 1's and 0's

This option is used for the D5, “1G False Carrier”, loopback test. The default packet data is an incrementing value per byte. With this option the packet data alternate between 64 1's and 0's that are aligned on a 64-bit PCI bus for maximum transitions.

-dids display chip information such as the PCI DID and VID

The feature outputs the following information: PCI DID, VID, SDID & SVID; MAC address, Firmware revision, PXE, PXESpd, WOL, ASF & MBA. This information can be used to verify the setup of a chip after a firmware upgrade.

-elog <filename> an error log file <filename> used to log diagnostics failures

The feature is used to log the failure information of the diagnostics run. When an error occurs if the file <filename> exists it is appended to and if it does not exist it is created. If there are no diagnostics failures then the file is not appended or created. A user abort of the diagnostics testing is log to the error log file <filename>.

-firm <filename> used for field upgrade of firmware

The feature is used to execute a field upgrade of firmware. The firmware is programmed into a/the device/s of a system if there is a match of the PCI DID, VID, SDID & SVID of firmware and device.

-lbspd <spd> selects the line speeds to run test D3 (external loopback)

The external loopback test, by default, runs line speeds of 10/100/1000 Mb/s. The user can select to run any combination of the line speeds to run the external loopback via this option. The <spd> parameter specifies the operational speed by using t/h/g for 10/100/1000 Mb/s respectively. To run test D3 at a 100 Mb/s line rate the user would enter “b57diag -t abcd -T d3 -lbspd h”. To run test D3 at a 100 Mb/s and 1 Gbit/s the user would enter “b57diag -t abcd -T d3 -lbspd hg”.

-hnb <spd> puts the UUT into the host loopback mode

All data sent to the device on the line side will be looped back to the line. This setup can be used to test a specific device with an external tester or can be used with the `-tr` option to perform a requestor-response test. The optional `<spd>` parameter specifies the operational speed by using 10/100/1000 for 10/100/1000 Mb/s respectively. The default value is 1000 Mb/s.

-tr <pkts> <spd> the UUT transmits and receives data

The UUT will transmit the number of packets specified by `<pkts>`. The default number of packets transmitted is 1,000,000. The UUT will receive all packets sent to it via the line side. Counts of the transmitted and received packets will be presented to the user. This setup can be used to test a specific device with an external tester or can be used with the `-hnb` option to perform a requestor-response test. The optional `<spd>` parameter specifies the operational speed by using 10/100/1000 for 10/100/1000 Mb/s respectively. The default value is 1000 Mb/s.

-c <num> specify UUT device number

When more than one device is in the system, the devices are numbered starting from zero. For example, if there are three devices detected, the devices are numbered as 0, 1, and 2. In this case, by entering the parameter `-c 2` will select the last found device as default UUT.

In manufacture testing mode, by default, all devices are tested; however, if this option is used, only that selected device is tested.

Example: `-c 2`

-l <file> log file

All diagnostic output can be saved in a log file. The log file name is specified by this option. The default is no log file.

Example: `-l mylogfile.txt`

-w <value> enable WOL programming in manufacture mode

After a successful manufacturing testing, the program will program WOL to either enable or disable mode (`<value> = 1/0`). By default, the WOL is programmed as disable. Entering `value=1` will enable WOL.

When `-f` is entered, software uses `eprom.bin`'s content for WOL setting.

When `-w 1` is entered with `-f`, software forces WOL enabled.

-x <value> enable PXE in manufacture mode

After a successful manufacturing testing, the program will program PXE to either enable or disable mode (<value> = 1/0). By default, the PXE is programmed as disable. Entering value=1 will enable PXE.

When -f is entered, software uses eeprom.bin's content for PXE setting.

When -x 1 is entered with -f, software forces PXE enabled.

-t <id> disable test
-T <id> enable test

A certain test is enabled or disabled by default. User can overwrite the enabling status by those options. The test id must start with a letter 'A', 'B', 'C', or 'D' to indication the group and followed by test numbers. Each digit of number represents the sub-test number. For example, if the user wants to disable test A1 and A3. The option -t A13 should be entered. If no test numbers entered, all tests in that group are selected. For the tests not specified, the default setting will be used.

Example -t A15BC1 -T C4 -t D2
 This disables A1, A5, B1, B2, B3, B4, B5, B6, C1, D2 and enables C4

Default Setting:

Enabled Tests:

- A1. Indirect Register Test
- A2. Control Register Test
- A3. BIST
- A4. Interrupt Test
- A5. PCI Cfg Register Test
- B1. Scratch Pad Test
- B2. BD SRAM Test
- B3. DMA SRAM Test
- B4. MBUF SRAM Test
- B5. MBUF SRAM via DMA Test
- C1. NVRAM Test
- C2. CPU Test
- C3. DMA Test
- C4. MII Test
- C5. VPD Test
- C6. ASF Test
- C7. ROM Expansion Test
- D1. Mac Loopback Test
- D2. Phy Loopback Test
- D5. MII Miscellaneous Test
- D6. MSI Test

Disabled Tests:

- B6. External SRAM Test

D3. RJ45 Loopback Test

-I <num> iteration number

Use this option to specify the number of times the tests to be run. The default is run one time. A number zero indicates loop forever. A control-C or control-break key can be used to break the loop. Any error detected will also stop testing after reporting the error.

Example: -I 5
Run tests five times.

-ver display current version number

If this option is entered, it displays the software version number/silkscreen revision and then exits the program.

-e <code> Encryption Code

This option is required to use option -geneep, -f, -m, -n, and -s.

-geneep <file> Generate eeprom.bin file from eeprom.txt

A password is needed to run this option. With this option, it updates the specified eeprom binary file with the specifications defined in eeprom.txt. Please see Section 5.0 EEPROM.TXT format for detailed argument description.

-bus <num> Test UUT location

If this option is specified, the program will only test all the UUTs at the specified bus number. This option is ignored if -c option is entered.

-dpmi Use DPMI memory allocation

Use DPMI memory allocation method to allocate memory instead of malloc() or free()

-f <file> Program eeprom.bin

The program programs the content of the specified file into EEPROM before testing.

-m Program MAC address

If this option is entered, the program will prompt user for a new MAC address to be enter/scan before testing starts.

-mac <mac address> Program MAC address from command line

If this option is entered, the program will retrieve MAC address right after the –mac option is entered. The mac address has to be entered in hex and as shown in the following example:

```
b57diag –mac 001018010203
```

-fmac <file> Program MAC address from a file

If this option is entered, the program will retrieve MAC address from the specified file before starts testing. If the test passes, the MAC address from the specified file will be incremented; if not, it will stay unchanged. The text file which contains the MAC address range has the following format and the numbers are in hexadecimal:

```
mac_addr_pref = xxxxxx    => Which is the prefix of the MAC address.
```

```
mac_addr_start = xxxxxx   => Which is the start of the address range.
```

```
mac_addr_end   = xxxxxx   => Which is the end of the address range.
```

Example:

```
mac_addr_pref = 001018
```

```
mac_addr_start = 000100
```

```
mac_addr_end   = 000FFF
```

Working in conjunction with –f <file> option, this –fmac option is equivalent to option –m.

-n Run program in Manufacturing Loop mode.

With this option, the –I, iteration number option, is ignored. The program will run in manufacturing loop mode. Power on/off is supported. After each test, the program will prompt user to exchange the UUT before starts another testing.

-s Skip eeprom programming process.

With this option, the program will skip the eeprom programming process. However, it will check for the eeprom content and print a warning message if the content is not valid.

The -m and -f combination will create the following behavior:**With both -f and -m:**

Program will not validate the eeprom content and go ahead to prompt user for the MAC address. It programs MAC address and EEPROM content and then checks the validity of eeprom content at the end of programming.


```
Loading EEPROM content from eeprom.bin: passed
Programming EEPROM from eeprom.bin....: passed
Checking EEPROM content.....: passed
```

-f only:

Program will check the validity of eeprom. If it is not valid, it will act as a), -f -m option. If it is good, it saves the MAC address from eeprom, program new eeprom binary file content into EEPROM and then restores the original MAC address. It checks the validity of eeprom content once more at the end of programming.

```
Checking EEPROM content.....: passed
Loading EEPROM content from <file>....: passed
Programming EEPROM from <file>.....: passed
Checking EEPROM content.....: passed
```

or

```
Checking EEPROM content.....: invalid
Loading EEPROM content from <file>....: passed
Programming EEPROM from <file>.....: passed
Checking EEPROM content.....: passed
```

-m only:

Program will check the validity of EEPROM. If it is not valid, it will act as a), -f -m option. If it is good, the program will prompt the user for a new MAC address and program the MAC address only. It checks the validity of EEPROM content once more at the end of programming.

```
Checking EEPROM content.....: passed
Programming MAC address.....: passed
Checking EEPROM content.....: passed
```

or

```
Checking EEPROM content.....: invalid
Loading EEPROM content from <file>....: passed
Programming EEPROM from <file>.....: passed
Checking EEPROM content.....: passed
```

d) no -m and -f options

Program will check the validity of EEPROM. If it is not valid, it will act as a), -f -m option. If it is good, it proceeds to normal diagnostics.

```
Checking EEPROM content.....: passed
```

or

```
Checking EEPROM content.....: invalid
Loading EEPROM content from eeprom.bin: passed
Programming EEPROM from eeprom.bin....: passed
Checking EEPROM content.....: passed
```

-pasf <file> Program ASF firmware

This option needs to follow the `-e` and `-c` options. User has an option to program the ASF firmware from a single bin file that combined all 3 pieces of ASF bin files or from a specified text file that contain the file names of all 3 pieces of ASF bin files.

The program will detect input file type. If it is a single bin file, software will start programming. If the input file is a text file that contains the file name of the 3 pieces of ASF bin files, the program will retrieve the ASF firmware filenames from the specified text file then it will start programming. A sample `asf.txt` is provided and it has the following format:

```
asf_eep_init = asfeinit.bin
```

```
asf_eep_cpua = asfecpua.bin
```

```
asf_eep_cpub = asfecpub.bin
```

-ppxe <file> Program PXE firmware

This option needs to follow the `-e` and `-c` options. If this option is entered, the program will retrieve the PXE firmware filename from the command line then it will start programming.

Example:

```
b57diag -e <code> -c 0 -ppxe b57pxe.bin
```

-mba <value> Enable/Disable Multiple Boot Agent

A value of 1 will enable Multiple Boot Agent and a 0 will disable.

Example:

```
b57diag -mba 0      : Disabling mba.
```

-mbap <value> Select Multiple Boot Agent Protocol

```
value = 0      : Selecting PXE
```

value = 1 : Selecting RPL
value = 2 : Selecting BOOTP

Example:

b57diag -mbap 0

-mbas <value> Select Multiple Boot Agent Speed

value = 0 : Selecting Auto
value = 1 : Selecting 10HD
value = 2 : Selecting 10FD
value = 3 : Selecting 100HD
value = 4 : Selecting 100FD

Example:

b57diag -mbas 0 : To select Auto speed mode.

-pxes <value> Select Multiple Boot Agent Speed

value = 0 : Selecting Auto
value = 1 : Selecting 10HD
value = 2 : Selecting 10FD
value = 3 : Selecting 100HD
value = 4 : Selecting 100FD

Example:

b57diag -mbas 0 : To select Auto speed mode.

-h : High Resolution (80x50) Video Mode
-p : Print on error
-q : Quick diagnostic mode
-asf <value> : Enable/Disable (value = 1/0) ASF in manufacture mode
-com <value> : enable com port, value(1..4)
-errctrl <c> : Action on Error --> a:abort, w:wait, l:loop, c:cont.

- ems <size>** : Enter external memory size in HEX to test
- findref** : Detect reference device
- lbm <n>** : Option to set mac loopback packets
- lbp <n>** : Option to set phy loopback packets
- lbe <n:n:n>** : Option to set external loopback packets, Format:
<1000Mbps:100Mbps:10Mbps>
- npol** : Select Negative Link Polarity in TBI test
- ref** : Run test with reference device

5 EEPROM.TXT format

A set of commands is defined to allow user to change EEPROM.BIN content. To update EEPROM.BIN, user must enter `-e <code> -geneep` options at the command prompt. A password must be entered to run this option. The 5704, Dual MAC, device use one single eeprom.bin to on both MAC channel configuration. Most of the configurations are shared expect the following commands:

PXE
PXE_SPEED
WOL
ASF

The WOL and ASF setting cannot be enabled on both channel at the same time. For example, if the primary WOL is already enabled, and the user try to enable secondary device's WOL, the primary's WOL setting will be disabled with the following message:

**** Warning, primary device WOL is disabled**

By default, all commands configure the primary channel until the command MAC is used to select other channel.

Syntax:

`<Command> = <Argument>`

xx 8-bit hex number
xxxx 16-bit hex number
xxxxxxxx 32-bit hex number
d decimal number ranges from 0 to 255
string(n) string of maximum size n.
cc 2 bytes character
n1..n2 a number ranges from n1 to n2.

MAC_PREFIX	= xx:xx:xx
POWER_DISSIPATCHED	= d:d:d:d
POWER_CONSUMED	= d:d:d:d
SYSTEM_VENDOR_ID	= xxxx
SYSTEM_DEVICE_ID	= xxxx
SUBSYSTEM_VENDOR_ID	= xxxx
SUBSYSTEM_DEVICE_ID	= xxxx
PXE	= {enable, disable}
PXE_SPEED	= {auto, 10hd, 10fd, 100hd, 100fd}
WOL	= {enable, disable}
PRODUCT_NAME	= string (48)
PART_NUMBER	= string (16)
ENGINEERING_CHANGE	= string (10)
MANUFACTURING_ID	= string (4)
ASSET_TAG	= string (16)

VOLTAGE_SOURCE = {1.3, 1.8}
FORCE_PCI = {enable, disable}
PART_REVISION = cc
LED_MODE = {Triple_link, link_speed} or {phy_mode1, phy_mode2}
PHY_TYPE = {Copper, Fiber}
PHY_ID = xxxxxxxx
MAX_PCI_RETRY = {0..7, auto}
ASF = {enable, disable}
DUAL_MAC_MODE = {normal, mac0, mac1, xbar, swap, swapxbar}
 normal: Ch.0 and Ch. 1 enabled
 mac0: Ch.0 enabled, Ch.1 disabled
 mac0: Ch.0 disabled, Ch.1 enabled
 xbar: Both MACs shares one function in PCI configuration space
MBA_BOOT_PROTOCOL = { pxe, rpl, bootp}
MBA_BOOTSTRAP_TYPE = {auto, bbs, int18, int19}
MBA_DELAY_TIME = {0..15}
EXPANSION_ROM_SIZE = {64K, 128K, 256K, 512K, 1M, 2M, 4M, 8M, 16M}
DESIGN_TYPE = {nic, lom}
MAC = {0, 1}
VENDOR_SPECIFIC0 = string (16)
VENDOR_SPECIFIC1 = string (16)
DISABLE_POWER_SAVING = {yes, no}
WOL_LIMIT_10 = {yes, no}
FIBER_WOL_CAPABLE = {yes, no}
hide_mba_setup_prompt = {enable, disable}
mbs_setup_hot_key = {Ctrl-S, Ctrl-B}
enable_auto_powerdown = {yes, no}

All reserved words are not case sensitive. A ‘;’, ‘//’ can be used at the beginning of line as comment.

Example:

```
; This comment line
// This also can be used as comment line

// Blank line is also allowed

// This is Broadcom's MAC prefix
MAC_PREFIX = 00:10:18
POWER_DISSIPATCHED = 10:0:0:100
POWER_CONSUMED = 10:0:0:100
SUBSYSTEM_VENDOR_ID = 14e4
SUBSYSTEM_DEVICE_ID = 1644
pxe = disable
PXE_Speed = 100fd
WOL = enable
Product_name = Broadcom Gigabit Ethernet Controller
PART_NUMBER = BCM95700A6
ENGINEERING_CHANGE = 106679-15
MANUFACTURING_ID = 14e4
Asset_Tag = XYZ1234567
```

DUAL_MAC_MODE = normal
MBA_BOOT_PROTOCOL = pxe
MBA_BOOTSTRAP_TYPE = bbs
MBA_DELAY_TIME = 6
EXPANSION_ROM_SIZE = 128K
DESIGN_TYPE = nic
; select other channel
MAC = 1
PXE = enable

6 User Interface Commands

The commands are summarized in the following groups: vpd, nvram, cpu, dma, packet, mii, mem, test, power, irq, mac, misc and bridge.

Command Group vpd

vpdwrite	Write VPD Memory
vpdread	Read VPD Memory

Command Group nvram

semode	same as flshmode command
seread	Read NVRAM
sewrite	Write NVRAM
secfg	Configure NVRAM
seprg	Program NVRAM
upgfrm	Upgrade PXE or Boot Code from a File
sever	Display Serial NVRAM Version
sechksum	Check/Update Serial NVRAM checksum
sedump	Dump NVRAM content to a file
asfcfg	Configure ASF in NVRAM
flshmode	Configure NVRAM mode
flshread	same as seread
chkpxe	Check PXE code image
dir	display file directory in NVRAM
erase	erase file from directory in NVRAM
pxeprg	Upgrade PXE from a File
flshdev	Select flash device to access
bitbang	Generate bitbang pattern to seeprom bus
seclock	set NVRAM config1 content value after reset
setorture	NVRAM reset torture test
seinit	Initialize NVRAM block
searb	set/report current NVRAM arbitration bit
seprotect	set gpio pin for NVRAM write protect
selclock	set Legacy EEPROM clock value (bit 16-24 of EEPROM addr reg)
semap	Display NVRAM usage
setwol	Enable/Disable WOL
setpxe	Enable/Disable PXE
setasf	Enable/Disable ASF
secomp	compare eeprom content against the file
dreset	double reset test for EEPROM debug
userblock	create a userblock in NVRAM
setmba	Enable Multiple Boot Agent
segenrcr	Append a CRC to the specified block
secfg1	Configure NVRAM Group1
secfg2	Configure NVRAM Group2
secfg3	Configure NVRAM Group3
secfg4	Configure NVRAM Group4

Command Group cpu

loadfw	Load Firmware to Tx/RX CPUs
--------	-----------------------------

cpudtt	Dump Debugging Trace of TX CPU
cpudrt	Dump Debugging Trace of RX CPU
cputrace	toggles cpu trace mode
haltcpu	Halt CPU
loadbootcode	execute bootcode from file instead of NVRAM
disasm	Disassemble MIP instructions
step	Step MIP instructions
go	start CPU
showgpr	toggles showing cpu gpr mode
pc	set current CPU PC
breakpoint	set current CPU break point
select	select current CPU
u	Alias of disasm command
trap	trap cpu memory
cpuinfo	display cpu information
cpugprstatus	Display internal CPU GPR test status
cpugprrestart	Restart internal CPU GPR test

Command Group dma

dmaw	DMA from NIC to Host Memory
dmar	DMA from Host to NIC Memory
dma_h	Dump DMA Entries
dma_d	Dump DMA Entries with Decode
dma_alloc	Allocate number of DMAD

Command Group packet

maclpk	Configure MAC loopback
nicstats	Display NIC Statistics
ringindex	Dump Ring Index
blast	Blast Packets in Poll Mode
phyctrl	Configure Speeds/Duplex
txpkt	Transmit Packet
statusblk	Dump Status Block
stsbk	Dump Statistics Block
txcfg	Configure protocol packets for transmission
rxcfg	Configure Rx parameters
tprot	Blast with TPROT Packets
qstat	Get a quick NIC statistic
drvrcfg	configure driver parameters
irt	Test an individual register
macmrd	Test an individual register
miimrd	Test an individual register
pcimrd	Test an individual register

Command Group mii

mwrite	Write PHY registers via MII Management interface
mread	Read PHY registers via MII Management interface
mdev	Select current PHY to be accessed
miimode	Select Auto Mode of MII Access
lbertram	Load data to PHY BIST RAM
dbertram	Dump PHY BIST RAM
bertstats	Dump PHY BIST Statistics
rm	Read MII Registers

mrloop	loop on MII read
phymse	PHY mean square error
initphy	Initialize phy

Command Group mem

memsearch	Search a Data Pattern in Memory
read	Read Memory
write	Write Memory
poll	poll Memory
setbit	Read-Modify Memory by ored with <bits>
clearbit	Read-Modify Memory by anded with ~<bits>
readbit	Read-Modify Memory by ored with <bits>
cread	Read PCI configuration Space of specified device
cwrite	Write PCI configuration Space of specified device

Command Group test

vpdtest	Run VPD Memory Test
regtest	Run Register Test
miitest	Run MII Memory Test
msi	Run MSI Test Manually
memtest	Run Memory Test
setest	Run NVRAM Test
bist	Run BIST
nictest	Run a set of NIC Tests
intrtest	Run Interrupt Test
pktttest	Run Packet Tests
cputest	Run CPU Test
dmatest	Run DMA Test
teste	Enable Test
testd	Disable Test
asftest	ASF Test
bustest	PCI Bus Test
sramtest	sram test
msitest	Run MSI Test
romtest	ROM Test
gpiotest	do GPIO test
cpudiag	run diagnostic from internal CPU
pcicfgtest	Run PCI Config. Reg. Test
petest	Perform parity error test on a bridge
errctrl	Configure Error Control Setting
sedvt	Perform NVRAM dvt test
miimiscstest	Run MII Misc. Tests
cpugprtest	Run CPU GPR test

Command Group power

pmdcfg	Dump Power Management Info
pmpcfg	Add/Del Pattern
pmpd	Power Down MAC

Command Group irq

intr	Dump Interrupt Info
intrctrl	Mask/Unmask Current Interrupt
intt	Interrupt Tracer

Command Group mac

mbuf	Dump Content of MBUFs
loaddrv	Load Driver
unloaddrv	Unload Driver
machalt	Halt MAC Controller
ftq	Dump FTQ
addmc	Add Multicast MAC
delmc	Delete Multicast MAC
txmacdes	Program Destination address to UUT
txmacsrc	Program Source address to UUT
chklddrv	Check to see if driver is loaded
vlangtag	Display/Clear vlanTag information

Command Group misc

reg	register wizard
exit	Exit the System
debug	debug functions
gpiowrite	Write a Value into GPIO pin
gpioread	Read GPIO Value
pxecpy	Load PXE Code to MBUF Memory
device	Show or Switch Device
version	Display Program Version
help	Display the Commands Available
?	Alternate Help Command
radix	Change System Radix
nolog	Close the Current Logfile
log	Open Logfile
pciinit	Initialize PCI Configuration Registers
pciscan	Scan for All PCI Devices
dos	Execute DOS command
diagcfg	Configure Diagnostics
reset	Reset Chip
quit	Exit the System
smbus	ASF terminal
cls	Clear Screen
loop	loop on command
dbmode	Set DEBUG Mode to On or Off Mode
asf	run asf monitor program with option to Load asf firmware image
new	Display new command available
asfprg	Program asf firmware into NVRAM
sleep	suspense process for Excute command from a file
fillpattern	Fill WOL matching pattern into Misc. Memory Location
inp	input port
outp	output port
switch	Altinate 'device' command
do	Excute command from a file
txfill	Fill tx buffer with pattern and packet length (14-9018)
wbuf	Write tx rx buffer with specified data at offset
rbuf	Read tx rx bistin bistout bistex buffer
cpbuf	Copy the content of rx buffer into tx buffer
echo	echo <string> to screen
pause	Pause for user to hit a key

q	Exit the System, alias name for quit
verbose	change verbose setting
beep	Create a beep sound
var	Display current variables
meminfo	report the memory information
delvar	Delete local variables
regdump	Dump register content to a file
regcomp	Compare register content to a file
regrestore	Restore register content from a file

Command Group bridge

readbr	Read bridge's configuration space
writebr	Write bridge's configuration space
findbridge	Find all bridges in the system
bridge	Switch to specified bridge
pere	Enable parity error response on a bridge.
perd	Disable parity error response on a bridge
peclr	Clear parity error on bridge
pechk	Clear parity error on a bridge

7 Special Instruction

1. Mac register test:

Unload MAC driver before running test.

2. Memory test:

Unload MAC driver before running test.

3. DMA test:

Unload MAC driver before running test.

4. TX RX packets:

TX sides need to be configured (txcfg).

RX sides need to be configured (rxcfg).

Configure MAC and PHY loop back.

Call txpkt to transmit packets.

5. The following tests need to setup test configuration before running.

To setup test configuration, run "diagcfg". Diag config can be saved in system for future use.

Test:

Memory test

NIC test

6. Unload driver before power down NIC card.

7. Load driver after power up NIC card.

8. Blast Test:

Load MAC driver before running test.

8 Same System Send/Respond Test

During a send/respond test two Broadcom Ethernet devices in the same system are connected via a CAT5 (RJ45) cable and data is transmitted and received across the cable. In the above setup one device is the device under test (DUT) and the other is the reference device. Any Broadcom device that is supported by diagnostics can be used as the DUT or the reference device.

8.1 Identifying a reference device

A reference device needs to be identified in order to test a DUT against the reference device. The user can use the “b57diag –dids” command to display all the devices in the system. Each device is assigned a number that is displayed on the screen in the first column just before the device type. A user selects the number of the device that is to be used as the reference and uses this number to test the DUT as described in the next section.

8.2 Testing the DUT against the reference device

After identifying the reference device, as described in the previous section, the user can test the DUT by running “b57diag –rf 0 –c 1 –t abcd –T d3”. Each of the previous options are described in the table below (details of each option are provided in the “Command line option parameters” section above).

-rf 0	Identifies the reference device as device 0.
-c 1	Identifies the DUT as device 1.
-t abcd	Disables all tests (Disable all tests in group a, b, c, and d).
-T d3	Perform the external loopback test that will transmit data from the DUT to the reference device, via the CAT5 cable, then the reference device will receive the data and transmit it back, via the CAT5 cable, to the DUT which will verify the received data.

8.3 Other Options for the Send/Respond test

The following options can be used with the send/respond test (details of each option are provided in the “Command line option parameters” section above).

-lbspd t/h/g	Selects any combination of line speed to run the loopback test (by default runs all line speeds).
-lbe g:h:t	Selects the number of packets to send during the loopback test (g, h & t are the 1000/100/10 megabit packet counts respectively) (default values are g=2000, h=1000, t=600). It is mandatory that all packets counts are entered with this command line switch.

9 Test and Functions Description

9.1 vpdwrite

cmd: vpdwrite

Description: Write data to VPD storage.

Syntax: vpdwrite <start[-end | len] value> | <filename>

File format:

Address range: 0x00 – 0xFF

num_bytes: 256 (max)

If only one argument is entered, filename is assumed. Otherwise, 'start [len] value' format must be used.

Example:

9.2 vpdread

cmd: vpread (Not support in A0)

Description: Read data from VPD storage

Syntax: vpdread start[-end | len]

Address range : 0x00 – 0xFF

num_byte : 256 (max)

Example:

9.3 semode

cmd: semode

Description: Configure Serial EEPROM to either Auto (I²C) or Manual (Bit-Bang) Mode.

Syntax: semode [auto | bitbang | passthru | legacy | new]

Example:

1. Set Serial EEPROM mode to Auto (I²C).

0:> semode auto

2. Set Serial EEPROM mode to Bit-Bang.

```
0:> semode bitbang
```

3. Display Current mode

```
0:> semode
```

Current mode : New NVRAM Access, Auto
device: Flash – ATMEL (with buffer)

9.4 seread

cmd: seread

Description: Read NVRAM

Syntax: seread start[-end | len]

Options:

-a : force auto read

-m : force manual bit-bang read

Example:

1. Set number base to hex, then read and display serial eeprom locations from 0x00 to 0x20

```
0:> radix 16
0:> seread 0-20
*** Dump Serial EEPROM (Auto Mode) ***
000000: 669955aa 08000000 00000069 00000200 d97b07d0 00000000 00000000 00000000
000020: 00000000
```

2. Set number base to hex then read location 0x18 of serial eeprom.

```
0:> radix 16
0:> seread 18 1
*** Dump Serial EEPROM (Auto Mode) ***
000018: 000000ff
```

9.5 sewrite

cmd: sewrite

Description: Write NVRAM

Syntax: sewrite start[-end | len] data

Options:

-a : force auto write

-m : force manual bit-bang write

Example:

1. Set number base to hex, write 0x55AA to serial eeprom from locations 0x30 to 0x35

```
0:> radix 16
0:> sewrite 30-35 55AA
*** Write Serial EEPROM (Auto Mode) ***
```

2. Set number base to hex, write 0x2 to serial eeprom location 0x25

```
0:> radix 16
0:> sewrite 25 2
*** Write Serial EEPROM (Auto Mode) ***
```

9.6 secfg

cmd: secfg

Description: Configure NVRAM

If selected program with defaults (-f=1), eeprom.bin must be found in the same directory of b57diag.exe.

Syntax: secfg

Options:

-v<n> : verbose level (0,1,2) (def=0)

-f : force to program with defaults

Example:

1 Program Serial EEPROM with defaults value and set verbose level to 0.

0:> secfg

Reading current NVRAM ... OK

Validating content...

```
1. MAC Address : 00:10:18:04:1a:36
2. Power Dissipated (D3:D2:D1:D0) : 10:0:0:100
3. Power Consumed (D3:D2:D1:D0) : 10:0:0:100
4. Vendor ID : 14E4
5. Vendor Device ID : 1653
6. Subsystem Vendor ID : 14E4
7. Subsystem Device ID : 1653
8. PXE { Enable(1), Disable(2) } : Disable
9. PXE Link Speed { Auto(0),10HD(1),10FD(2),
100HD(3),100FD(4)} : Auto
10. Magic Packet WoL { Enable(1), Disable(2) } : Disable
11. Product Name : Broadcom NetXtreme Gigabit Ethernet Controller
12. Part Number : BCM95705A50
13. Engineering Change : 106679-15
14. Serial Number : 0123456789
15. Manufacturing ID : 14e4
16. Asset Tag : XYZ01234567
17. Part Revision : A0
18. Voltage { 1.3V(0), 1.8V(1) } : 1.8V
19. Force PCI Mode { Enable(1),Disable(2) } : Disable
20. PHY Type { Copper(1),Fiber(2) } : Copper
21. Led Mode { Mac Mode(0), Phy Model (1), Phy Mode2 (2),
Shasta Mac Mode (3), SharedTraffic (4),
Wireless Combo (5)} : Phy Model
22. PHY ID ([PHY#2][PHY#3]) : 00206160
23. Max PCI Retry {0-7, 8=auto} : 8
24. ASF { Enable(1), Disable(2) } : Disable
25. Dual MAC mode {Normal(0), MAC_B only(1),
MAC_A only(2), XBAR(3), swap(4), swapXBAR(7)}: 0
26. MBA Boot Protocol {PXE(0), RPL(1), BOOTP(2)} : 0
27. MBA Bootstrap Type
{Auto(0), BBS(1), Int18(2), Int19(3)}: 0
28. MBA Delay Time (0-15) : 0
29. Expansion ROM size { 64k(0), 128k(1), 256k(2),
512k(3), 1M(4), 2M(5), 4M(6), 8M(7), 16M(8) }: 0
30. Design Type: {NIC(0), LOM(1)} : NIC
31. Read only VPD Vendor Specific Data (V0) :
32. Read/Write VPD Vendor Specific Data (V1) :
33. Reversed Nway {No(0), Yes(1)} : No
34. Limit WoL Speed to 10 {No(0), Yes(1)} : No
35. Fiber WoL Capable {No(0), Yes(1)} : No
36. Clock-Run Setting {Disable(0), Enable(1)} : Disable
37. Enable PHY Auto Powerdown {No(0), Yes(1)} : No
38. Disable PowerSaving capability {No(0),Yes(1)}: No
39. Hide MBA Setup Prompt {Disable(0), Enable(1)}: Disabled
40. MBA Setup Hot Key {Ctrl-S(0),Ctrl-B(1)} : 0
```

Enter your choice (option=paramter/save/cancel) ->

Description of above parameters:

To enter the 'secfg' menu shown above a user type in 'secfg' at the diagnostics command line. A menu is present to the user showing the 'secfg' options shown above. A user can change the 'secfg' parameter by entering the option number, followed by an equal sign, and then followed by the parameter selected. To enable ASF (option 24) a user would enter "24=1" at the DOS diagnostics 'secfg' command line, which would look like the following: "Enter your choice (option=paramter/save/cancel) -> 24=1".

The tables below provide details for each parameter of the 'secfg' options. The top right of each table has the word "Configure" or "Reference". "Configure" signifies that the option is used to configure the operating characteristics of the device or default values of registers in the device. "Reference" signifies that the option is use for display purposes and does not affect the operating characteristics of the device or default values of registers in the device.

1	MAC Address	Configure
Description: MAC address of the device.		
2	Power Dissipated (D3:D2:D1:D0)	Reference
Description: Power dissipated in D3-0 states.		
3	Power Consumed (D3:D2:D1:D0)	Reference
Description: Power consumed in D0-2 states.		
4	Vendor ID	Configure
Description: PCI Vendor ID. Default 0x14e4.		
5	Device ID	Configure
Description: PCI Device ID.		
6	Subsystem Vendor ID	Configure
Description: PCI Subsystem PCI Vendor ID.		
7	Subsystem Device ID	Configure
Description: PCI Subsystem PCI Device ID.		
8	PXE	Configure
Description: Enable the Pre-Boot Execution Environment (PXE) by using this option. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
Enable(1)	When PXE is enable the expansion ROM enable bit in the PCI configuration space is set for system boot up. The user has to make sure the PXE code is loaded into the non-volatile memory by using the "loadpxe" command.	
Disable(2)	When PXE is disable the expansion ROM enable bit in the PCI configuration space is cleared for system boot up. The PXE code does NOT have to been load into the non-volatile memory of the device.	
9	PXE Link Speed	Configure
Description: Pre-Boot Execution Environment line configuration is specified using the parameters below. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
Auto(0)	PXE auto detects the link configuration.	
10HD(1)	PXE uses a 10 Mbits/s, half duplex line configuration.	
10FD(2)	PXE uses a 10 Mbits/s, full duplex line configuration.	
100HD(3)	PXE uses a 100 Mbits/s, half duplex line configuration.	

100FD(4)		PXE uses a 100 Mbits/s, full duplex line configuration.
10	Magic Packet WoL	
Configure		
Description: A system can be configured to power-on when a Magic Packet is received.		
Enable(1)	The device will assert the pme signal, to power on the system, when a magic packet is received.	
Disable(2)	Magic packets are ignored.	
Note: A driver can setup the WoL behavior of a device and the value programmed into this location is ignored.		
11	Product Name	
Reference		
Description: VPD Produce description string.		
12	Part Number	
Reference		
Description: VPD part number..		
13	Engineering Change	
Reference		
Description: VPD engineering change.		
14	Serial Number	
Reference		
Description: VPD serial number.		
15	Manufacturing ID	
Reference		
Description: VPD manufacturing ID.		
16	Asset Tag	
Reference		
Description: VPD asset tag.		
17	Part Revision	
Reference		
Description: VPD part revision.		
18	Voltage	
Configure		
Description: Device voltage source.		
1.3V(0)	Selects a 1.3V source.	
1.8V(1)	Selects a 1.8V source.	
19	Force PCI Mode	
Configure		
Description: PCI bus operational mode configuration.		
Enable(1)	When enabled the device uses PCI mode, instead of PCI-X, independent of the capabilities of the slot the device is plugged into.	
Disable(2)	When disabled the device uses the PCI mode of the slot the device is plugged into; if the device is capable of operating in the required mode.	
20	PHY Type {option no longer supported}	
Configure		
Description: PHY line type configuration.		
Copper(1)	The communication medium is copper.	

Fiber(2)	The communication medium is fiber.	
----------	------------------------------------	--

21	Led Mode	Configure												
Description:														
A device can be configured to use one LED to indicate speed and activity or three LEDs.														
Mac Mode (0)	The LEDs are controlled by the value in the Mac LED Control Register.													
Phy Mode1 (1)	Three LEDs are used for 10/100/1000 Mbits/s and each is driven individually by the device.													
Phy Mode2 (2)	<p>One LED is used for 10/100/1000 Mbits/s and is connected as described below.</p> <p>5700/01 – The Link10 line will indicate link for all speeds. Link100 and Link1000 will encode the line speed as show in the following table:</p> <table> <tr> <th>Link 100</th><th>Link 1000</th><th>Speed</th></tr> <tr> <td>0</td><td>0</td><td>10 Mbits/s</td></tr> <tr> <td>1</td><td>0</td><td>100 Mbits/s</td></tr> <tr> <td>0</td><td>1</td><td>1000 Mbits/s</td></tr> </table> <p>For all other 57xx devices the three link lines operate in an open drain configuration and can be tied together with a pull up resistor to control a LED.</p>		Link 100	Link 1000	Speed	0	0	10 Mbits/s	1	0	100 Mbits/s	0	1	1000 Mbits/s
Link 100	Link 1000	Speed												
0	0	10 Mbits/s												
1	0	100 Mbits/s												
0	1	1000 Mbits/s												
SharedTraffic (3)	Mode specific to the 575x and 572x chips. The link LED performs a dual role: solid when there is a link and blinks when there is activity.													
Shasta Mac Mode (4)	Mode specific to the 575x and 572x chips. The link LED blinks only when traffic is for Shasta.													
Wireless Combo (5)	Mode specific to the 575x and 572x chips. When link is lost the LEDs are driven by inputs pins that are connected to the LED signals of a wireless link.													
22	PHY ID	Reference												
Description:														
Only for display purposes not used in software.														
[PHY#2][PHY#3]														

23	Max PCI Retry	Configure
Description:		
The maximum number of time to retry an aborted PCI operation.		
0-7	The number of MAX PCI retries is force by the users configuration.	
8=auto	The MAX PCI retry field is selected dynamically by firmware based on PCI bus type detected.	

24	ASF	Configure
Description:		
The functionality of Alert Standard Format (ASF) is enabled by this option.		
Enable(1)	If the ASF code is loaded in NVRAM it is loaded and executed by the device.	
Disable(2)	No ASF functionality is provided when disable.	

25	Dual MAC mode	Configure
Description:		
This option is only valid for a dual port device such as a 5704. The physical ports will be named MAC_A an MAC_B for the discussion below.		
Normal(0)	MAC_A and MAC_B are available and are supported as PCI function 0 & 1.	
MAC_B only(1)	MAC_B is available and is supported as PCI function 0. MAC_A is disable.	
MAC_A only(2)	MAC_A is available and is supported as PCI function 0. MAC_B is disable.	

XBAR mode(3)	MAC_A and MAC_B are available and are supported as PCI function 0. MAC_A is the primary device and MAC_B is mapped in the space of MAC_A. To the OS and BOIS this looks like one port. The driver will trunk the two ports together as one logical port which allows for load balancing, failover/recovers, turbo-teaming, etc.
swap(4)	Physical port MAC_A and MAC_B are available and are supported as PCI function 1 and 0 respectively.
swapXBAR(7)	MAC_A and MAC_B are available and are supported as PCI function 0. MAC_B is the primary device and MAC_A mapped in the space of MAC_B. To the OS and BOIS this looks like one port. The driver will trunk the two ports together as one logical port which allows for load balancing, failover/recovers, turbo-teaming, etc.

26	MBA Boot Protocol	Configure
Description: Select a Multiple Boot Agent. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
PXE(0)	PreBoot Execution Environment (PXE) is the boot protocol.	
RPL(1)	Remote Program Load (RPL) is the boot protocol.	
BOOTP(2)	Boot Protocol (BOOTP) is the boot protocol.	

27	MBA Bootstrap Type	Configure
Description: The BIOS bootstrap methods listed below are supported. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
Auto(0)	Automatically configured use one of the methods below.	
BBS(1)	A BIOS that supports the BIOS Boot Specification (BBS) can initiate the bootstrap method via the expansion ROMs Bootstrap Entry Vector.	
Int18(2)	A INT18 is used to initiate the bootstrap method.	
Int19(3)	A INT19 is used to initiate the bootstrap method.	

28	MBA Delay Time	Configure
Description: The amount of time the MBA boot message is displayed, in order to give a user the option to enter the BOOT parameter configuration screen.		
0-15	The number of seconds the MBA banner is displayed.	

29	Expansion ROM size	Configure
Description: This value determines the size of the expansion ROM. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
64k(0)	Advertises 64k expansion ROM size.	
128k(1)	Advertises 128k expansion ROM size.	
256k(2)	Advertises 256k expansion ROM size.	
512k(3)	Advertises 512k expansion ROM size.	
1M(4)	Advertises 1M expansion ROM size.	
2M(5)	Advertises 2M expansion ROM size.	
4M(6)	Advertises 4M expansion ROM size.	
8M(7)	Advertises 8M expansion ROM size.	
16M(8)	Advertises 16M expansion ROM size.	

30	Design Type	Configure
Description: Select NIC or LOM based Ethernet controller.		
NIC(0)	Option selected for a plug in network interface card.	
LOM(1)	Option selected for a LAN on motherboard.	

Note:

The firmware and the drivers use this to determine the operational characteristics of a device. For example, on a LOM GPIO2 is tied to the SEEPROM write protect pin and on a NIC GPIO 1 and 2 is used to switch between main and auxiliary power for wake on LAN functionality.

31	Read only VPD Vendor Specific Data (V0)	Reference
Description: VPD V0 value. Data field provided for the customer.		
32	Read/Write VPD Vendor Specific Data (V1)	Reference
Description: VPD V1 value. Data field provided for the customer.		
33	Reversed Nway	Configure
Description: Nway Negotiation.		
0	(default) Auto-negotiation is done from 1000->100->10 Mbits/s.	
1	Auto-negotiation is done from 10->100->1000 Mbits/s.	
Note: A user could set the chip for option 1 when running a laptop on battery power. The chip would auto-negotiate starting at a lower speed and lower power. The chip would only go to higher line rates and higher power if the lower line rates were unavailable.		
34	Limit WoL Speed to 10	Configure
Description: Limit Wake on LAN (WoL) line speed.		
No(0)	10 or 100 Mbits/s is used for WoL.	
Yes(1)	Only 10 Mbits/s is used for WoL.	
35	Fiber WoL Capable	Configure
Description: Fiber Wake on LAN (WoL) Capable enable.		
No(0)	Disable Fiber WoL.	
Yes(1)	Enable Fiber WoL.	
36	Clock-Run Setting	Configure
Description: Enable Clock-Run on mini-PCI/cardbus systems. This parameter is valid only for the 5705 A0-A2.		
Enable(1)	Sets the clock mode register bit 22 which will assert (active low) the clock run signal on the bus prior to any PCI configuration space activity.	
Disable(0)	The above is not performed.	
37	Enable PHY Auto Powerdown	Configure
Description: Enable GPHY auto-power down.		
No(0)	The PHY will not auto power down.	
Yes(1)	The PHY will auto power down when there is no link.	
38	Disable Power Saving capability	Configure
Description: Disable Power Saving capability		
No(0)	Power-saving capability active.	
Yes(1)	Power-saving capability inactive.	
39	Hide MBA Setup Prompt	Configure

Description: During the MBA boot, the MBA setup prompt is displayed to provide the user the option to setup and configure various MBA parameters. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
Disable (0)	Hide the MBA Setup Prompt. The user is NOT give the option to change the MBA boot parameters.	
Enable (1)	Show the MBA Setup Prompt. The user is given the option to change the MBA boot parameters.	

40	MBA Setup Hot Key	Configure
Description: Hot Key used to enter the MBA Setup. Options 8,9, 26 - 29 and 39-40 configure the boot protocol behavior.		
Ctrl-S (0)	MBA Setup entered via ctrl-s.	
Ctrl-B (1)	MBA Setup entered via ctrl-b.	

9.7 seprg

cmd: seprg

Description: Program NVRAM and ASF firmware

Syntax: seprg <file_name>

Input file need to be found in the same location as b57diag.exe.

Options:

-d	Do not perform device check
-f<string>	filename
-l<HEX>	length in bytes (Default = size of input file)
-m	Do not restore original MAC address
-o<HEX>	offset of serial nvram (def=00000000)
-s	Do not restore original Serial Number
-a	Program ASF firmware

Example:

1. Program NVRAM with contents of input file seprg.bin

```
0:> seprg seprg.bin
```

```
0:>seprg asffirmware.bin -a
```


9.8 upgfrm

cmd: upgfrm

Description: Upgrade PXE or Boot Code from a File. This command reads code from a file and program into pxe or boot area. Both parameter, the programming target 'pxe' or 'boot' and filename, must be specified.

Syntax: upgfrm <pxe | boot> filename

Options:

-b	Upgrade boot code
-d	Do not perform device check
-f<string>	Input file
-p	Upgrade PXE code

9.9 sever

cmd: sever

Description: Display Serial NVRAM Version

Syntax: sever

9.10 sechksum

cmd: sechksum

Description: Check/Update Serial NVRAM checksum

Syntax: sechksum

Options:

-v<DEC>	verbose level (0,1) (def=1)
---------	-----------------------------

9.11 sedump

cmd: sedump

Description: Dump NVRAM content to a file

Syntax: sedump <filename> [HexLen]

Options:

-a<string> no Atmel Flash address translation

-f<string> filename

-l<DEC> file length, use 0 for entire NVRAM image (def=8192)

9.12 asfcfg

cmd: asfcfg

Description: Configure ASF in NVRAM

Syntax: asfcfg [filename]

9.13 flshmode

cmd: flshmode

Description: Configure ASF in NVRAM

Syntax: flshmode [auto | bitbang | passthru | legacy | new]

9.14 flshread

cmd: flshread

Description: Same as seread

Syntax: flshread start[-end | len]

9.15 chkpxe

cmd: chkpxe

Description: Check PXE code image

Syntax: chkpxe <filename>

9.16 dir

cmd: dir

Description: display file directory in NVRAM

Syntax: dir

9.17 erase

cmd: erase

Description: erase file from directory in NVRAM

Syntax: erase <entry> | all

Options:

-y do not ask for conformation

9.18 pxeprg

cmd: pxeprg

Description: display file directory in NVRAM. This command reads PXE code from a file and program into NVRAM

Syntax: pxeprg <filename>

9.19 flshdev

cmd: flshdev

Description: Select flash device to access

Syntax: flshdev seeprom | atmelflash | sstflash

9.20 bitbang

cmd: bitbang

Description: Generate bitbang pattern to seeprom bus. Enter hex numbers to be written to seeprom bus. For serial eeprom, use 's' for start, 'p' for stop condition, 'x' with '1..9' specifies how many residual bits to send. For flash, use 's' for chipSelect, 'p' for cancel chipSelect 'r' with a number specifies how many bytes to read.

Syntax: bitbang <data>

9.21 seclock

cmd: seclock

Description: set NVRAM config1 content value after reset.

Syntax: seclock <32bitNewValue>

9.22 setorture

cmd: setorture

Description: NVRAM reset torture test

Syntax: setorture

Options:

-c	Continue on Error
-i<DEC>	Initial Delay in ms (def=0)
-m<DEC>	Maximum Delay in ms (def=3000)
-n<DEC>	iteration (def=1)
-p	Power reset
-r	Random delay
-s<DEC>	Delay incremental time (us) (def=1)

9.23 seinit

cmd: seinit

Description: Initialize NVRAM block.

Syntax: seinit

Options:

-i<DEC>	do not restore NVRAM clock default value (def=0)
---------	--

9.24 searb

cmd: searb

Description: set/report current NVRAM arbitration bit. Valid arbitraion number is 0..3.

Syntax: searb [n]

9.25 seprotect

cmd: seprotect

Description: set gpio pin for NVRAM write protect. Use 'none' to disable write protect feature.

Syntax: seprotect [0|1|2|none]

9.26 selclock

cmd: selclock

Description: set Legacy EEPROM clock value (bit 16-24 of EEPROM addr reg)

Syntax: selclock <8bitNewValue>

9.27 semap

cmd: semap

Description: Display NVRAM usage

Syntax: semap

9.28 setwol

cmd: setwol

Description: Enable/Disable WOL

Syntax: setwol [e/d]

Options:

-d	Disable WOL
-e	Enable WOL

9.29 setpxe

cmd: setpxe

Description: Enable/Disable PXE

Syntax: setpxe

Options:

-d	Disable PXE
-e	Enable PXE
-s<DEC>	Specify PXE Speed (def=0), 0. auto, 1. 10HD, 2. 10FD, 3. 100HD, 4. 100FD

9.30 setasf

cmd: setasf

Description: Enable/Disable ASF

Syntax: setasf

Options:

-d Disable ASF

-e Enable ASF

9.31 secomp

cmd: secomp

Description: compare eeprom content against the file

Syntax: secomp

Options:

-c continue on error

-f<string> filename

-l<HEX> length (def=00000000)

-o<HEX> offset (def=00000000)

9.32 dreset

cmd: dreset

Description: double reset test for EEPROM debug

Syntax: dreset

9.33 userblock

cmd: userblock

Description: create a userblock in NVRAM

Syntax: userblock

9.34 setmba

cmd: setmba

Description: Enable Multiple Boot Agent

Syntax: setmba

Options:

- d Disable MBA
- e<DEC> Enable MBA Protocol (def=0), 0. PXE, 1. RPL, 2. BOOTP
- s<DEC> Specify MBA Speed (def=0), 0. auto, 1. 10HD, 2. 10FD, 3. 100HD, 4. 100FD

9.35 loadfw

cmd: loadfw

Description: Load Firmware to Tx/RX CPUs

Syntax: loadfw

Options:

- b<HEX> set breakpoint (0=off) (def=00000000)
- d<HEX> data pattern to be used for memory init. (def=00000000)
- f<string> filename (for bcmediag compatibility)
- I don't initialize memory before loading, def=yes
- m don't turn on CPU Trace (def=on)
- s don't start cpu
- t load to tx cpu, def=rxpcu
- v disable verbose

9.36 cpudrt

cmd: cpudrt

Description: Read and display RX CPU trace (not valid for 5705)

Syntax: cpudrt <begin_addr>[- end_addr | num_bytes]

Address range: 0x00 – 0x80

Example:

1. Read and display RX CPU trace from location 0x00 to 0x04.

```
0:> cpudrt 0-5
000 MainCpuA t00000030 164414e4 e1000004 00000000 164414e4 00000000
001 *BUpCpuA t00000032 00000000 08000034 00440400 00001c40 00000000
002 *BUpCpuA t00000001 00000001 08000034 00440000 00000000 00000000
003 t00000000 00000000 00000000 00000000 00000000 00000000
004 t00000000 00000000 00000000 00000000 00000000 00000000
```

2. Read and display 4 locations of RX CPU trace from start from location 0x00.

```
0:> cpudrt 0 5
000 t00000030 164414e4 e1000004 00000000 164414e4 00000000
001 t00000032 00000000 08000034 00440400 00001c40 00000000
002 t00000001 00000001 08000034 00440000 00000000 00000000
003 t00000000 00000000 00000000 00000000 00000000 00000000
```

9.37 cpudtt

cmd: cpudtt

Description: Read and display TX CPU trace (not valid for 5705)

Syntax: cpudtt <begin_addr>[- end_addr | num_bytes]

Address range: 0x00 – 0x80

Example:

1. Read and display TX CPU trace from location 0x00 to 0x04.

```
0:> cpudtt 0-5
000 t0000002f c0000000 00000000 00000000 00000000 00000000
001 t00000000 00000000 00000000 00000000 00000000 00000000
002 t00000000 00000000 00000000 00000000 00000000 00000000
003 t00000000 00000000 00000000 00000000 00000000 00000000
004 t00000000 00000000 00000000 00000000 00000000 00000000
```

2. Read and display 4 locations of TX CPU trace from start from location 0x00.

```
0:> cpudtt 0 5
000 MainCpuB t0000002f c0000000 00000000 00000000 00000000 00000000
001 t00000000 00000000 00000000 00000000 00000000 00000000
002 t00000000 00000000 00000000 00000000 00000000 00000000
003 t00000000 00000000 00000000 00000000 00000000 00000000
```

9.38 cputrace

cmd: cputrace

Description: toggles cpu trace mode

Syntax: cputrace [1|0]

9.39 haltcpu

cmd: haltcpu

Description: Halt CPU

Syntax: haltcpu

9.40 loadbootcode

cmd: loadbootcode

Description: execute bootcode from file instead of NVRAM

Syntax: loadbootcode <filename>

Options:

-d<HEX>	data pattern to be used for memory init. (def=00000000)
-f<string>	filename
-i	don't initialize memory before loading, def=yes
-m	don't turn on CPU Trace (def=on)
-s	don't start cpu
-t	load to tx cpu, def=rxpcu
-v	disable verbose

9.41 disasm

cmd: disasm

Description: Disassemble MIP instructions

Syntax: disasm [address [line]]

9.42 step

cmd: step

Description: Step MIP instructions

Syntax: step

9.43 go

cmd: go

Description: start CPU

Syntax: go

9.44 showgpr

cmd: showgpr

Description: toggles showing cpu gpr mode

Syntax: showgpr 1|0

9.45 pc

cmd: pc

Description: set current CPU PC

Syntax: pc

9.46 select

cmd: select

Description: select current CPU

Syntax: select <r|t>

9.47 breakpoint

cmd: breakpoint

Description: set current CPU breakpoint

Syntax: breakpoint

9.48 u

cmd: u

Description: Alias of disasm command

Syntax: u [address [line]]

9.49 trap

cmd: trap

Description: trap cpu memory

Syntax: trap <low> <high> | off

9.50 cpuinfo

cmd: cpuinfo

Description: display cpu information

Syntax: cpuinfo [r|t]

9.51 cpugprstatus

cmd: cpugprstatus

Description: Display internal CPU GPR test status

Syntax: cpugprstatus

9.52 cpugprrestart

cmd: cpugprrestart

Description: Restart internal CPU GPR test

Syntax: cpugprrestart

9.53 dmaw

cmd: dmaw

Description: DMA from NIC to Host Memory

Syntax; dmaw

Options:

-3	Force to use 32-bit bus
-4	Allocate 4k-aligned buffers
-a<HEX>	NIC address to DMA data from (def=00000000)
-b	byte swap
-c	Continuously dma data
-d<HEX>	delay poll dma done polling (def=00000000)
-f<string>	filename
-h	Use high priority DMA Write

-l<HEX>	Length of DATA in bytes to DMA (def=00000100)
-n<DEC>	iteration
-o<HEX>	Buffer offset (def=00000000)
-p<HEX>	Pattern of Data. 0 - byte increment ; 1- byte decrement 2 - FF's ; 3 - 00's ; 4- AA 55 ... ; 5 - 55 AA ... 6 - FFFFFFFF 00000000 FFFFFFFF 00000000 7 - FFFFFFFF FFFFFFFF 00000000 00000000 FFFFFFFF FFFFFFFF 8 - FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF 00000000 00000000 ... 9 - 00000000 00000000 00000000 00000000 FFFFFFFF FFFFFFFF ... a - Word Increment ; b - Dword Increment c - Word Decrement ; d - Dword Decrement e - ffffffff00000000 00000000ffffffbf f - 00000000ffffffbf fffffffbf00000000 10 - 64-bit-pattern 0000000000000000 64-bit-pattern ... 11 - 64-bit-pattern ffffffffbf 64-bit-pattern ... (def=00000000)
-q<HEX>	low 32-bit of 64-bit pattern (def=FFFFFFFF)
-v<DEC>	Verbose (1..2) (def=2)
-w	word swap
-x<HEX>	high 32-bit of 64-bit pattern (def=FFFFFFFF)
-K<HEX>	DMA write to absolute address and hang the system (def=00000000)

Example:

1. Setup DMA NIC Memory to HOST memory. Using low priority DMA Read and disable byte swap and enable detail display.

```
1:> dmaw -a=0 -l=10
Device 1
Host Address : 0x0068bb38
NIC Address  : 0x00000000
Length       : 0x0010
Priority      : Low
Byte Swap    : No
Word Swap    : No
```

```
Dev 1: DMA SRAM 00000000 to Host 0068BB38
```

9.54 dmar

cmd: dmar

Description: DMA from Host to NIC Memory

Syntax: dmar

Options:

-w	word swap
-3	Force to use 32-bit
-4	Allocate 4k-aligned buffers
-a<HEX>	NIC address to DMA data to (def=00000000)
-b	Byte Swap
-c	Continuously dma
-d<HEX>	delay poll dma done polling (def=00000000)
-f<string>	File name of file that contains <length,patterns>
-h	Use high priority DMA Read
-l<HEX>	Length of DATA to do DMA (def=00000100)
-n<DEC>	iteration
-o<HEX>	Buffer offset (def=00000000)
-p<HEX>	Pattern of Data 0 - byte increment ; 1- byte decrement 2 - FF's ; 3 - 00's ; 4- AA 55 ... ; 5 - 55 AA ... 6 - FFFFFFFF 00000000 FFFFFFFF 00000000 7 - FFFFFFFF FFFFFFFF 00000000 00000000 FFFFFFFF FFFFFFFF 8 - FFFFFFFF FFFFFFFF FFFFFFFF FFFFFFFF 00000000 00000000... 9 - 00000000 00000000 00000000 00000000 FFFFFFFF FFFFFFFF... a - Word Increment ; b - Dword Increment c - Word Decrement ; d - Dword Decrement (def=00000000)
-q<HEX>	low 32-bit of 64-bit pattern (def=FFFFFFFF)
-v<DEC>	Verbose (1..2) (def=2)
-w	Word Swap
-x<HEX>	high 32-bit of 64-bit pattern (def=FFFFFFFF)

-K<HEX> DMA read from absolute address (def=00000000)

Example:

1. Sup DMA host memory to NIC memory. Using low priority DMA Read and disable byte swap.

```
1:> dmar -a=0 -l=100
Device 1
Host Address : 0x0068bb38
NIC Address  : 0x00000000
Length       : 0x0100
Priority      : Low
Byte Swap    : No
Word Swap    : No
```

Dev 1: DMA Host 0068BB38 to SRAM 00000000

9.55 dma_h

cmd: dma_h

Description: Dump DMA Entries

Syntax: dma_h <start> <end>

9.56 dma_d

cmd: dma_d

Description: Dump DMA Entries with Decode

Syntax: dma_d <start> <end>

9.57 maclpk

cmd: maclpk

Description: Configure MAC loopback, 0 to disable, otherwise enable MAC loopback

Syntax: maclpk <n>

0 to disable. Otherwise enable

Example:

1. Driver must be loaded before configure.

```
0:> loaddrv
```

2. Enable MAC loop back.

```
0:> mcaclpb 1
Enabling MAC loopback ... OK
```

2. Disable MAC loop back.

```
0:> maclpb 0
Disabling MAC loopback ... OK
```

9.58 nicstats

cmd: nicstats

Description: Display NIC Statistics

Syntax: nicstats <-c>

-c : Clear Statistics

Example: Load driver if driver is not loaded.

```
0:> loaddrv
Reinitializing PCI Configuration Space
Bus Number      : 1
Device/Funtion   : 11/0
Base Address     : 0xfb010000
IRQ             : 9
Bringing up MAC driver ... OK
PHY calculated ID: 60008162
BCM5702/03 Internal Phy Rev#2
Configuring BCM54xx ... Done
Determining Link Speed ... 1000Base-T Full Duplex
0:> nicstats
```

	Total	Rate
	=====	=====
Txed Packets (Ring#0) :	0	0
Txed Packets (Ring#1) :	0	0
Txed Packets (Ring#2) :	0	0
Txed Packets (Ring#3) :	0	0
Tx Packets Enqed (Ring#0) :	0	0
Tx Packets Enqed (Ring#1) :	0	0
Tx Packets Enqed (Ring#2) :	0	0
Tx Packets Enqed (Ring#3) :	0	0
Rxed Packets (Ring00) :	0	0
Rxed Packets (Ring01) :	0	0
Rxed Packets (Ring02) :	0	0
Rxed Packets (Ring03) :	0	0
Rxed Packets (Ring04) :	0	0
Rxed Packets (Ring05) :	0	0
Rxed Packets (Ring06) :	0	0
Rxed Packets (Ring07) :	0	0
Rxed Packets (Ring08) :	0	0
Rxed Packets (Ring09) :	0	0

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

Total	Rate
	=====
Rxed Packets (Ring#10) :	0
Rxed Packets (Ring#11) :	0
Rxed Packets (Ring#12) :	0
Rxed Packets (Ring#13) :	0
Rxed Packets (Ring#14) :	0
Rxed Packets (Ring#15) :	0

Rxed CRC-32 Errors	:	0	0
Out of Memory	:	0	0
Too Many Frag Pkt	:	0	0

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

CHIP Statistics

```
=====
ifHCInOctets      :      0  etherStatsFragments      :      0
ifHCInUcastPkts   :      0  ifHCInMulticastPkts    :      0
ifHCInBroadcastPkts :      0  d3StatsFCSErrors      :      0
d3StatsAlignmentErrors :      0  xonPauseFramesReceived :      0
xonPauseFramesReceived:      0  macControlFramesReceived:      0
xonStateEntered    :      0  dot3StatsFramesTooLong :      0
etherStatsJabbers   :      0  etherStatsUndersizePkts :      0
inRangeLengthError :      0  outRangeLengthError    :      0
etherStatsPkts64Octets :      0  etherStatsPkts65-127   :      0
etherStatsPkts128-255 :      0  etherStatsPkts256-511  :      0
etherStatsPkts512-1023 :      0  etherStatsPkts1024-1522 :      0
etherStatsPkts1523-2047:      0  etherStatsPkts2048-4095 :      0
etherStatsPkts4096-8191:      0  etherStatsPkts8192-9022 :      0
ifHCOctets         :      0  etherStatsCollisions    :      0
outXonSent          :      0  outXoffSent              :      0
flowControlDone     :      0  d3StatsInt1MacTxErrors  :      0
d3StatsSingleColFrames :      0  d3StatsMultipleColFrames:      0
dt3StatsDeferredTx   :      0  d3StatsExcessiveCol     :      0
=====
```

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

CHIP Statistics

```
=====
d3StatsLateCol      :      0  d3Collided2Times      :      0
d3Collided3Times    :      0  d3Collided4Times      :      0
d3Collided5Times    :      0  d3Collided6Times      :      0
d3Collided7Times    :      0  d3Collided8Times      :      0
d3Collided9Times    :      0  d3Collided10Times     :      0
d3Collided11Times   :      0  d3Collided12Times     :      0
d3Collided13Times   :      0  d3Collided14Times     :      0
d3Collided15Times   :      0  ifHCOctets            :      0
d3StatsCarSenseErrors :      0  ifOutDiscards          :      0
COSIfHCInPkts[00]    :      0  COSIfHCInPkts[01]     :      0
COSIfHCInPkts[02]    :      0  COSIfHCInPkts[03]     :      0
COSIfHCInPkts[04]    :      0  COSIfHCInPkts[05]     :      0
COSIfHCInPkts[06]    :      0  COSIfHCInPkts[07]     :      0
COSIfHCInPkts[08]    :      0  COSIfHCInPkts[09]     :      0
COSIfHCInPkts[10]    :      0  COSIfHCInPkts[11]     :      0
COSIfHCInPkts[12]    :      0  COSIfHCInPkts[13]     :      0
COSIfHCInPkts[14]    :      0  COSIfHCInPkts[15]     :      0
COSFrmsDxDueToFilters :      0  nicDmaWriteQueueFull   :      0
nicDmaWrHiPQFull    :      0  nicNoMoreRxBDs         :      0
=====
```

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

CHIP Statistics

```
=====
ifInDiscards        :      0  ifInErrors              :      0
nicRecvThresholdHit  :      0  nicDmaReadQueueFull     :      0
COSIfHCOutPkts[00]   :      0  COSIfHCOutPkts[01]     :      0
COSIfHCOutPkts[02]   :      0  COSIfHCOutPkts[03]     :      0
=====
```



```

COSIfHCOutPkts[04]      :          0    COSIfHCOutPkts[0
Rxed Packets (Ring#05)   :              0              0
Rxed Packets (Ring#06)   :              0              0
Rxed Packets (Ring#07)   :              0              0
Rxed Packets (Ring#08)   :              0              0
Rxed Packets (Ring#09)   :              0              0

```

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

9.59 ringIndex

cmd:

Description: Dump Ring Index. Load Mac driver before running.

Syntax: ringindex t | r

Options:

-n<DEC> Number of Rx Ring to dump (Default=1) (def=1)

-r Dump Rx Ring Index

-t Dump Tx Ring Index

Example:

1 Load MAC driver and display TX and RX Ring Index.

```

0:> loaddrv
Bus Number      : 1
Device/Funtion  : 11/0
Base Address    : 0xfb010000
IRQ             : 9
Bringing up MAC driver ... OK
PHY calculated ID: 60008162
BCM5702/03 Internal Phy Rev#2
Configuring BCM54xx ... Done
Determining Link Speed ... 1000Base-T Full Duplex
0:> ringindex rt

```

	Mailbox	RBDI	RBDC	HC	StsBlk	Driver
	=====	=====	=====	=====	=====	=====
RxStdPidx	100	100	100	---	---	100
RxStdCidx	---	---	---	000	000	000
RetRPidx#00	---	---	---	000	---	---
RetRCidx#00	000	---	---	---	---	000

	Mailbox	SBDI	SBDSEL	HC	StsBlk	Driver
	=====	=====	=====	=====	=====	=====
SendHostPidx#00	000	000	---	---	---	000
SendHostCidx#00	---	---	000	000	000	000
SendHostPidx#01	000	000	---	---	---	000
SendHostCidx#01	---	---	000	000	000	000
SendHostPidx#02	000	000	---	---	---	000
SendHostCidx#02	---	---	000	000	000	000
SendHostPidx#03	000	000	---	---	---	000

SendHostCidx#03 --- --- 000 000 000 000

9.60 blast

cmd: blast

Description: Blast Packets in Poll Mode and display statistics. Load MAC driver before running the test.

Syntax: blast

Options:

- a<DEC> IP total length (def=0)
- c<DEC> Number of Tx buffer (def=100)
- d<DEC> Interpacket GAP in microseconds (def=0)
- e<DEC> Upper Limit of Tx buffer in incremental packet size (def=1514)
- f<string> Sniffer file containing contents of Tx packets
- g<DEC> Rx Threshold (def=5)
- h Enable Host Loopback
- I Increment length
- j Regenerate CRC-32 in host loopback mode
- k Applies CRC-32 check on Rx path
- l<DEC> Length of Tx packet (def=60)
- m Generate TPROT packets
- n<DEC> Number of packets to be transmitted (def=0)
- o<DEC> Number of Rx Rings (def=1)
- p Send protocol packets configured with txcfg command.
- q Use software CRC-32 on Tx Path
- r Enable Rx
- s Stop on Failure

-t	Enable Tx
-w<DEC>	Low watermark max RxFrame value (0-65535)
-x	Check length of received packet
-z<DEC>	Tx Threshold (def=5)
-P	Pause
-R	Enable RS232 statistic update
-S	TCP segment test
-T<DEC>	Packet Type, 0:None, 1:Eth2, 2:802.3, 4:SNAP
-W	Check DMA_Write error status

Example:

1. Load MAC driver and enable transmission.

```
0:packet> loaddrv
Reinitializing PCI Configuration Space
Bus Number      : 1
Device/Funtion   : 11/0
Base Address     : 0xfb010000
IRQ              : 9
Bringing up MAC driver ... OK
PHY calculated ID: 60008162
BCM5702/03 Internal Phy Rev#2
Configuring BCM54xx ... Done
Determining Link Speed ... 1000Base-T Full Duplex
0:packet> blast -t
PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit
```

	Total	Rate
	=====	=====
Txed Packets (Ring#0) :	1007609	507523
Txed Packets (Ring#1) :	0	0
Txed Packets (Ring#2) :	0	0
Txed Packets (Ring#3) :	0	0
Tx Packets Enqed (Ring#0) :	0	0
Tx Packets Enqed (Ring#1) :	0	0
Tx Packets Enqed (Ring#2) :	0	0
Tx Packets Enqed (Ring#3) :	0	0
Rxed Packets (Ring#00) :	0	0
Rxed Packets (Ring#01) :	0	0
Rxed Packets (Ring#02) :	0	0
Rxed Packets (Ring#03) :	0	0
Rxed Packets (Ring#04) :	0	0
Rxed Packets (Ring#05) :	0	0
Rxed Packets (Ring#06) :	0	0
Rxed Packets (Ring#07) :	0	0
Rxed Packets (Ring#08) :	0	0
Rxed Packets (Ring#09) :	0	0

PageUP/PageDN to scroll. Ins/Del toggles refresh. ESC to exit

9.61 phyctrl

cmd: phyctrl

Description: Configure Phy Speed

Syntax: phyctrl

Options:

- f<string> file contains initialization scripts
- h force half duplex
- r reset PHYs
- s<HEX> 0:10 Mbps, 1:100 Mbps, 2:1000 Mbps, 3 - Auto (def=00000002)

9.62 txpkt

cmd: txpkt

Description: Transmit Packets. Driver must be loaded.

Syntax: txpkt

Options:

- a<DEC> Specify number of IP fragment count (def=0)
- b<DEC> Burst length (def=0)
- c Clear Statistics (always on: kept for bcmediag compatibility)
- d<DEC> Interpacket delay in microseconds (def=txcfg)
- e Insert raw checksum into the packet
- f<DEC> Max number of fragments (def=1)
- g<HEX> Tx Flags (def=txcfg)
- h<DEC> Specifies IP total length (Default: correct IP length)
- I Incremental length
- j Random number of fragments
- k Use random packet length

- l<DEC> Start packet length (def=txcfg)
- m Use multiple Tx ring test (def=txcfg)
- n<DEC> Number of packet to transmit (def=0)
- o<HEX> Buffer Offset (def=00000000)
- p<DEC> Number of Tx rings to use in multiple ring test (def=txcfg)
- q<DEC> Number of Packets per ring (def=txcfg)
- r<DEC> Tx ring number (def=txcfg)
- v Insert fragment count and fragment size into the packet
- x Display Statistics (always on: kept for bcmediag compatibility)
- u Standard Fragmentation
- w<DEC> Low watermark max RxFrame value (0-65535)
- z<DEC> Minimum fragment size, -1=disable (def=-1)
- A Use static buffer
- L Don't initialize packets
- R Enable RS232 statistic update
- S TCP segmentation test

9.63 statusblk

cmd: statusblk

Description: Display Status Block

Syntax: statusblk

Example:

0:> statusblk

```
***** STATUS Block @ 0x0027c040 *****
Status : 0x0000
Rx Standard CIdx : 0     Rx Jumbo CIdx : 0     Rx Mini CIdx : 0
Rx PIdx[00]    : 0            Send CIdx[00]    : 0
Rx PIdx[01]    : 0            Send CIdx[01]    : 0
Rx PIdx[02]    : 0            Send CIdx[02]    : 0
Rx PIdx[03]    : 0            Send CIdx[03]    : 0
Rx PIdx[04]    : 0            Send CIdx[04]    : 0
```

Rx PIdx[05]	:	0	Send CIdx[05]	:	0
Rx PIdx[06]	:	0	Send CIdx[06]	:	0
Rx PIdx[07]	:	0	Send CIdx[07]	:	0
Rx PIdx[08]	:	0	Send CIdx[08]	:	0
Rx PIdx[09]	:	0	Send CIdx[09]	:	0
Rx PIdx[10]	:	0	Send CIdx[10]	:	0
Rx PIdx[11]	:	0	Send CIdx[11]	:	0
Rx PIdx[12]	:	0	Send CIdx[12]	:	0
Rx PIdx[13]	:	0	Send CIdx[13]	:	0
Rx PIdx[14]	:	0	Send CIdx[14]	:	0
Rx PIdx[15]	:	0	Send CIdx[15]	:	0

9.64 stsblk

cmd: stsblk

Description: Display Statistics Block.

Syntax: stsblk

Example:

```
0:> stsblk
***** STATISTICS Block @ 0x0027c0c0 *****
ifHCInOctets      : 0 etherStatsFragments      : 0
ifHCInUcastPkts   : 0 ifHCInMulticastPkts     : 0
ifHCInBroadcastPkts : 0 d3StatsFCSErrors      : 0
d3StatsAlignmentErrors : 0 xonPauseFramesReceived : 0
xonPauseFramesReceived : 0 macControlFramesReceived : 0
xonOffStateEntered : 0 dot3StatsFramesTooLong : 0
etherStatsJabbers  : 0 etherStatsUndersizePkts : 0
inRangeLengthError : 0 outRangeLengthError   : 0
etherStatsPkts64Octets : 0 etherStatsPkts65-127 : 0
etherStatsPkts128-255 : 0 etherStatsPkts256-511 : 0
etherStatsPkts512-1023 : 0 etherStatsPkts1024-1522 : 0
etherStatsPkts1523-2047 : 0 etherStatsPkts2048-4095 : 0
etherStatsPkts4096-8191 : 0 etherStatsPkts8192-9022 : 0
ifHCOutOctets      : 0 etherStatsCollisions    : 0
outXonSent         : 0 outXoffSent             : 0
flowControlDone    : 0 d3StatsInt1MacTxErrors  : 0
d3StatsSingleColFrames : 0 d3StatsMultipleColFrames : 0
dt3StatsDeferredTx  : 0 d3StatsExcessiveCol   : 0
d3StatsLateCol      : 0 d3Collided2Times      : 0
d3Collided3Times    : 0 d3Collided4Times      : 0
d3Collided5Times    : 0 d3Collided6Times      : 0
d3Collided7Times    : 0 d3Collided8Times      : 0
d3Collided9Times    : 0 d3Collided10Times     : 0
d3Collided11Times   : 0 d3Collided12Times     : 0
d3Collided13Times   : 0 d3Collided14Times     : 0
d3Collided15Times   : 0 ifHCOutUcastPkts     : 0
d3StatsCarSenseErrors : 0 ifOutDiscards      : 0
COSIfHCInPkts[00]   : 0 COSIfHCInPkts[01]   : 0
COSIfHCInPkts[02]   : 0 COSIfHCInPkts[03]   : 0
COSIfHCInPkts[04]   : 0 COSIfHCInPkts[05]   : 0
COSIfHCInPkts[06]   : 0 COSIfHCInPkts[07]   : 0
COSIfHCInPkts[08]   : 0 COSIfHCInPkts[09]   : 0
COSIfHCInPkts[10]   : 0 COSIfHCInPkts[11]   : 0
COSIfHCInPkts[12]   : 0 COSIfHCInPkts[13]   : 0
COSIfHCInPkts[14]   : 0 COSIfHCInPkts[15]   : 0
COSFrmsDxDueToFilters : 0 nicDmaWriteQueueFull : 0
nicDmaWrHiPQFull    : 0 nicNoMoreRxBds      : 0
ifInDiscards        : 0 ifInErrors          : 0
nicRecvThresholdHit  : 0 nicDmaReadQueueFull : 0
COSIfHCOutPkts[00]  : 0 COSIfHCOutPkts[01]  : 0
COSIfHCOutPkts[02]  : 0 COSIfHCOutPkts[03]  : 0
COSIfHCOutPkts[04]  : 0 COSIfHCOutPkts[05]  : 0
COSIfHCOutPkts[06]  : 0 COSIfHCOutPkts[07]  : 0
```

COSIfHCOutPkts[08]	:	0	COSIfHCOutPkts[09]	:	0
COSIfHCOutPkts[10]	:	0	COSIfHCOutPkts[11]	:	0
COSIfHCOutPkts[12]	:	0	COSIfHCOutPkts[13]	:	0
COSIfHCOutPkts[14]	:	0	COSIfHCOutPkts[15]	:	0
nicDmaRdHPQueueFull	:	0	nicSendDataCompQueueFull	:	0
nicRingSetSdPIIdx	:	0	nicRingStatusUpdate	:	0
nicInterrupts	:	0	nicAvoidedInterrupts	:	0
nicSendThresholdHit	:	0			
Phy CRC counter	:	0			

9.65 txcfg

cmd: txcfg

Description: Configure protocol packets for transmission

Syntax: txcfg

Example:

```
0:> txcfg
1. Source MAC                      : 10:11:12:13:14:15
2. Destination MAC                 : 00:01:02:03:04:05
3. Length (14-65535)               : 1514
4. Packet Type {Non(0),EthV2(1),802.3(2),SNAP(3)}: Ethernet II
5. Protocol Field {Non(0),IP(1),ARP(2),BRM(3)}   : IP
6. Source IP                       : 10.2.1.1
7. Destination IP                  : 10.2.1.2
8. IP Protocol Field { UDP(17), TCP(6) }        : UDP
   80. Source Port                  : 100
   81. Destination Port            : 200
9. IP Option Length (32-bit Words) : 0
10. TCP Option Length (32-bit Words) : 0
11. Pattern { As-is(0), Inc(1), Random(2), 0s(3), FFs(4),
    AA55(5), 55AA(6),IP_Iden-Inc(7),Load from file(8)
    00ff8(9) 00ff16(10), 00ff32(11), 00ff(12)}   : Increment (00,01,02 ...)
12. IP Checksum Offload{ YES(1), NO(0) }        : NO
13. TCP/UDP Checksum Offload { YES(1), NO(0) }  : NO
14. TCP/UDP Pseudo Checksum Only { YES(1), NO(0) } : NO
15. Insert VLAN Tag { YES(1), NO(0) }          : NO
16. VLAN Tag                               : 1
17. Random IP header field { YES(1), NO(0) }   : NO
18. Random TCP/UDP header field { YES(1), NO(0) } : NO
0. Exit
```

Enter your choice (option=paramter) ->

9.66 rxcfg

cmd: rxcfg

Description Configure RX parameters.

Syntax: rxcfg

Example:

```
0:> rxcfg
1. Host Loopback { Enable(1), Disable(0) }      : Disable
2. Modify Rx Packet { Enable(1), Disable(0) }    : Disable
3. Dump Rx Packet { None(1),Hex(2), Decode(3) }  : None
```

```
4. Dump Rx Length           : 64
5. Tx Fragment Length       : 1518
6. Tx Flags                  : 0000
7. Tx VLAN Tag              : 0000
8. Tx Ring Number           : 0
9. Tx Generate CRC { Enable(1), Disable(0) } : Enable
10. Capture Rx Pacpket { Enable(1), Disable(0) } : Enable
11. Rx Mask
0. Exit
```

Enter your choice (option=paramter) ->

9.67 tprot

cmd: tprot

Description: Blast with TPROT Packets. This command is same as command 'blast -trm'

Syntax: tprot

Options:

-d<DEC> Interpacket gap in microseconds (def=10)

9.68 qstat

cmd: qstat

Description: Get a quick NIC statistic. [qstat string] used to select specific statistic.

Syntax: qstat [qstat string]

Options:

-c Clear statistic

-l List all qstat string

9.69 drvrcfg

cmd: drvrcfg

Description: configure driver parameters

Syntax: drvrcfg

Options:

-a<DEC> Turn on/off autolink capability (def=0)

-q<DEC> Configure Rx ring size (def=0)

-r<DEC> Turn on/off rxflow capability (def=0)

-t<DEC> Turn on/off txflow capability (def=0)

-x<DEC> Configure Tx ring size (def=0)

9.70 irt

cmd: irt

Description: Test an individual register. Test an individual register with a specified number of reads/writes.

Syntax: irt

Options:

-n<DEC> Number of read/write accesses (def=1)

-r<string> Register offset

9.71 macmrd

cmd: macmrd

Description: Test an individual register. Test an individual register with a specified number of reads/writes.

Syntax: macmrd

Options:

-d<DEC> Delay in uS (def=0)

-n<DEC> Number of read/write accesses (def=1)

-r<string> Register offset

9.72 miimrd

cmd: miimrd

Description: Test an individual register. Test an individual register with a specified number of reads/writes.

Syntax: miimrd

Options:

- d<DEC> Delay in uS (def=0)
- n<DEC> Number of read/write accesses (def=1)
- r<string> Register offset

9.73 pcimrd

cmd: pcimrd

Description: Test an individual register. Test an individual register with a specified number of reads/writes.

Syntax: pcimrd

Options:

- d<DEC> Delay in uS (def=0)
- n<DEC> Number of read/write accesses (def=1)
- r<string> Register offset

9.74 mwrite

cmd: mwrite

Description: Write PHY registers via MII Management interface

Syntax: mwrite <addr > <data>

Address range: 0x00 – 0x1F

Example:

1. Write 0x15 to MII register 2

```
0:> mwrite 2 15
```

9.75 mread

cmd: mread

Description: Read PHY registers via MII Management interface

Syntax: mread <begin>[-<end> | <len>]

Address range: 0x00 – 0x1F

Example:

1. Read MII register 0

```
0:> mread 0
00: 1100
```

2 Read MII registers 0 to 10

```
0:> mread 0-10
00: 1100 7949 0020 6051 01e1 0000 0004 2001
08: 0000 0300 0000 0000 0000 0000 0000 3000
10: 0002
```

3. Read 5 MII registers start from register 0

```
0:> mread 0 5
00: 1100 7949 0020 6051 01e1
```

9.76 mdev

cmd: mdev

Description: Select current PHY to be accessed. The default device ID is 0x01. If no parameter is entered, it displays current phy address setting.

Syntax: mdev [<phy_id>]

Example:

```
0:> mdev 1
Phy Address = 1
```

9.77 miimode

cmd: miimode

Description: Select Auto Mode of MII Access. 0:disable, 1:enable

Syntax: miimode <1|0>

Example:

```
0:> miimode 0
Setting MII auto mode to OFF
0:> miimode 1
Setting MII auto mode to ON
0:> miimode
```

9.78 lbertram

Command: lbertram

Description: Load data to PHY BIST RAM

Syntax: lbertram [filename]

Options:

-c<DEC> channel number (def=0)

-e enable BIST

-f<string> File name containing BIST data

9.79 dbertram

Command: dbertram

Description: Dump PHY BIST RAM

Syntax: dbertram

Options:

-b<HEX> Begin of BIST RAM (def=00000000)

-c<DEC> channel number (def=0)

-e<HEX> End of BIST RAM (def=000000FF)

-r Dump Rx BIST RAM

-t Dump Tx BIST RAM

9.80 bertstats

Command: bertstats

Description: Dump PHY BIST statistics

Syntax: bertstats

9.81 rm

Command: rm

Description: Read MII Registers

Syntax: rm

9.82 mrloop

Command: mrloop

Description: loop on MII read. This is special test routine for MII read. It loops on MII register read until user abort or if value is zero.

Syntax: mrloop <addr>

9.83 phymse

Command: phymse

Description: PHY mean square error.

Syntax: phymse

Options:

-p Polling continuously at 100ms interval

9.84 initphy

Command: initphy

Description: Initialize phy.

Syntax: initphy

9.85 memsearch

Command: memsearch

Description: Search a Data Pattern in Memory. The default, begin address = 0, and len = 0x20000. The data pattern must be specified.

Syntax: memsearch begin[-end | len] data

9.86 read

cmd: read

Description: Read Memory

Syntax: read [!#*\$~^!ImSsxX]<begin> [-end | len]

! = Configuration space (32)

S = Configuration space (16)

X = Configuration space (8)

= Registers (32) (default)

* = SRAM (32)

\$ = NVRAM (SEEPROM/FLASH) (32)

m = MII registers (16)

~ = VPD Access (32)

I = indirect access (32)

^ = internal scratchpad (32)

l = direct access (32)

s = direct access (16)

x = direct access (8)

Example:

1. Read from Configuration space

```
0:> read !10
000010: f4000004
```

2. Read from Register

```
0:> read #10
000010: f4000004
```

3. Read from SRAM

```
0:> read *10
000010: 00010001
```

4. Read from internal scratchpad

```
0:> read ^00
000000: 000312ae
```

9.87 write

cmd: write

Description: Write Memory

Syntax: write [!#*\$~^lImSsxX]<address> [-end | len] data

! = Configuration space (32)

S = Configuration space (16)

X = Configuration space (8)

= Registers (32) (default)

* = SRAM (32)

\$ = NVRAM (EEPROM/FLASH) (32)

m = MII registers (16)

~ = VPD Access (32)

I = indirect access (32)

^ = internal scratchpad (32)

l = direct access (32)

s = direct access (16)

x = direct access (8)

Example:

1. Write to configuration space.

```
0:> write !10 f4000004
```

2. Write to register.

```
0:> write #10 f4000004
```

3. Write to SRAM

```
0:> write *10 10001
```

4. Write to internal scratchpad

```
0:> write ^10 f4000004
```

9.88 poll

cmd: poll

Description: poll Memory

Syntax: poll [!#*\$~^lImSsxX]<addr> [[!#*\$~^lImSsxX]<addr>...]

! = Configuration space (32)

S = Configuration space (16)

X = Configuration space (8)

= Registers (32) (default)

* = SRAM (32)

\$ = NVRAM (SEEPROM/FLASH) (32)

m = MII registers (16)

~ = VPD Access (32)

I = indirect access (32)

^ = internal scratchpad (32)

l = direct access (32)

s = direct access (16)

x = direct access (8)

Options:

-n<DEC> Number of changes to print before stop (def=0)

9.89 setbit

cmd: setbit

Description: Read-Modify Memory by ored with <bits>

Syntax: setbit [!#*\$~^lImSsxX]<addr> <bit#> [<bit#>] ...

! = Configuration space (32)

S = Configuration space (16)

X = Configuration space (8)

= Registers (32) (default)

* = SRAM (32)

\$ = NVRAM (EEPROM/FLASH) (32)

m = MII registers (16)

~ = VPD Access (32)

I = indirect access (32)

^ = internal scratchpad (32)

l = direct access (32)

s = direct access (16)

x = direct access (8)

9.90 clearbit

cmd: clearbit

Description: Read-Modify Memory by anded with ~<bits>

Syntax: clearbit [!#\$~^lImSsxX]<addr> <bit#> [<bit#>] ...

! = Configuration space (32)

S = Configuration space (16)

X = Configuration space (8)

= Registers (32) (default)

* = SRAM (32)

\$ = NVRAM (SEEPROM/FLASH) (32)

m = MII registers (16)

~ = VPD Access (32)

I = indirect access (32)

^ = internal scratchpad (32)

l = direct access (32)

s = direct access (16)

x = direct access (8)

9.91 readbit

cmd: readbit

Description: Read the bit specified by <bit#>

Syntax: readbit [!#\$~^lImSsxX]<addr> <bit#>

! = Configuration space (32)

S = Configuration space (16)

X = Configuration space (8)

= Registers (32) (default)

* = SRAM (32)

\$ = NVRAM (EEPROM/FLASH) (32)

m = MII registers (16)

~ = VPD Access (32)

I = indirect access (32)

^ = internal scratchpad (32)

l = direct access (32)

s = direct access (16)

x = direct access (8)

9.92 cread

Command: cread

Description: Read PCI configuration Space of specified device. default - 32 bits read, S - 16 bits read, X - 8 bits read

Syntax: cread <bus> <dev> <func> [S|X]<begin> [-end | len]

9.93 cwrite

Command: cwrite

Description: Write PCI configuration Space of specified device. default - 32 bits read, S - 16 bits read, X - 8 bits read

Syntax: cwrite <bus> <dev> <func> [S|X]<begin> [-end | len] data

9.94 vpdtest

cmd: vpdtest

Description: Run VPD Memory Test. Write designed pattern to VPD storage. Then read back and compare with designed pattern.

Syntax: vpdtest

Options:

-d Force destructive test

-n<DEC> iteration

-p<DEC> Pattern to test (def=0)
 0 - Increment; 1 - Decrement ; 1 - 0's 2 - FF's ; 3 - AA55; 4 - 55AA

-r Random address test

-w Force write test enable

9.95 regtest

cmd: regtest

Description: MAC registers read/write test. Driver must be unloaded.

Syntax: regtest [<iteration>]

Options:

-i Also run indirect memory test

-n<DEC> iteration (The default iteration is 1. 0 means run forever)

-r<DEC> repeat count for each register test (def=1)

-I Do not perform reset before test

9.96 miitest

cmd: miitest

Description: Run MII Memory Test. PHY registers read write test

Syntax: miitest [iteration]

Options:

-n<DEC> iteration (The default iteration is 1. 0 means run forever)

9.97 msi

cmd: msi

Description: Run MSI Test Manually

Syntax: msi

Options:

-c<HEX> message count (2 to powered of c) (def=00000003)

-d option removed, kept for bcmediag compatibility

-I initializing MSI block

-o<DEC> offset (def=0)

9.98 memtest

cmd: memtest

Description: Test memory blocks such as scratch pad, BD sram, DMA sram, Mbuf, external SRAM. Running “diagcfg” can configure memory block ranges. See “diagcfg” for detail. Driver must be unloaded.

Syntax: memtest [iteration]

Options:

-b	Test BD SRAM
-c	Test MBUF special
-d	Test DMA SRAM
-e	Test External Memory
-m	Test MBUF SRAM
-n<DEC>	iteration (The default iteration is 1. 0 means run forever)
-p	Test CPU GPRs
-s	Test Scratch Pad
-x	Test MBUF SRAM via DMA

9.99 setest

cmd: setest

Description: Run NVRAM Test

Syntax: setest [iteration]

Options:

-e	extensive test
-d<HEX>	ending offset (with -e option) (def=FFFFFFFF)
-n<DEC>	iteration
-q	quiet mode

-r read only test

-s<HEX> start offset (with -e option) (def=00000000)

9.100 bist

cmd: bist

Description: Run BIST. The default iteration is 1. 0 means run forever.

Syntax: bist [iteration]

9.101 nicetest

cmd: nicetest

Description: Run a set of NIC Tests. NIC test can include memory test, serial eeprom test, interrupt test, packet exchange, MAC registers test, Mii registers test, cpu test, dma test. This test can to be configured by running “diagcfg”. See “diagcfg” for details. If a “test list” is not entered below then a set of default tests are run.

Syntax: nicetest [test list]

abcd -- runs all tests

b -- runs all test in group B

a3 b1 -- runs test a3 and b1 only

a124b2 -- runs test a1,a2,a4 and b2

Options:

-e run NVRAM verification also

-n<DEC> iteration

9.102 intrtest

cmd: intrtest

Description: Interrupt Test

Syntax: intrtest [iteration]

Options:

-n<DEC> iteration (The default iteration is 1. 0 means run forever.)

9.103 pkttest

Command: pkttest

Description: Perform MAC and/or PHY loopback test. This test will send 100 packets in incremental length and check for contents of loopbacked packets.

Syntax: pkttest [<iteration>]

Options:

- e run external loopback test
- m run mac loopback test
- n<DEC> iteration (The default iteration is 1. 0 means run forever.)
- p run phy loopback test

9.104 cputest

cmd: cputest

Description: TX / RX CPU Test. This test needs an input CPU file in the same location as b57diag.exe. The default file name is cpu.bin or cpu05.bin unless specified by -f option.

Syntax: cputest [iteration]

Options:

- f<string> input filename
- n<DEC> iteration (The default iteration is 1. 0 means run forever)

9.105 dmatest

cmd: dmatest

Description: DMA Test

Syntax: dmatest [iteration]

Options:

- 4 Allocate 4k-aligned buffers
- a<HEX> NIC address (def=00002100)
- d Display DMA info.

-f Force to use 32-bit bus

-l<HEX> Length of DATA to do DMA (def=00000400)

-n<DEC> iteration

-o<HEX> Buffer offset (def=00000000)

9.106 teste

Command: teste

Description: The command enables tests. It effects nicetest, regtest, pkttest, and memtest commands. The test must starts with test group alpha (a-d). If no number is entered, all tests in that group are enabled.

Syntax: teste [<tests> [<tests>...]]

Example: teste a12bc -- Enable test a1, a2, all tests in group b and c
 teste ab cd -- Enables all tests
 teste -- Display enabled tests

9.107 testd

Command: testd

Description: The command disables tests. It effects nicetest, regtest, pkttest, and memtest commands. The test must starts with test group alpha (a-d). If no number is entered, all tests in that group are disabled.

Syntax: testd [<tests> [<tests>...]]

Example: testd a12bc -- Disable test a1, a2, and all tests in group b and c.
 testd ab cd -- Disables all tests.
 testd -- Display disabled tests.

9.108 asftest

cmd: asftest

Description: ASF Test

Syntax: asftest

Options:

-n<DEC> iteration

9.109 bustest

Command: bustest

Description: PCI Bus Test

Syntax: bustest

Options:

-a<HEX> NIC address to DMA data to. (def=00002100)

-d<HEX> delay poll dma done polling (def=00000000)

-e<DEC> End of test case (def=259)

-g Insert debugging information

-h<DEC> Maxmum length (def=1024)

-i<DEC> Number of transactions per pattern (def=10)

-l<DEC> Minimum length (def=256)

-n<DEC> iteration

-o<DEC> Number of consecutive patterns (def=1)

-p<DEC> DMA priority (def=0)

-s<DEC> Start of test case (def=0)

-t<DEC> Transient fixed pattern (def=0)

-v<DEC> Verbose level (0..2) (def=1)

-L Loop

There are total 260 test cases (258 unique tests cases) which are described as follows:

Test case#	Pattern
=====	=====
0	ffffffff ffffffff 00000000 00000000
1	ffffffff fffffffe 00000000 00000000
2	ffffffff ffffffff 00000000 00000000
.	.
.	.


```
.
.
64      7fffffff ffffffff 00000000 00000000
65      00000000 00000000 ffffffff ffffffff
66      00000000 00000000 ffffffff ffffffff
67      00000000 00000000 ffffffff ffffffff

.
.
.
129     00000000 00000000 7fffffff ffffffff
130     00000000 00000000 ffffffff ffffffff (repeat)
131     00000000 00000001 ffffffff ffffffff
132     00000000 00000002 ffffffff ffffffff

.
.
.
194     80000000 00000000 ffffffff ffffffff
195     ffffffff ffffffff 00000000 00000000 (repeat)
196     ffffffff ffffffff 00000000 00000001
197     ffffffff ffffffff 00000000 00000002

.
.
.
259     ffffffff ffffffff 80000000 00000000
```

If you run `bustest` command without any parameters, it will perform DMA testing on all 260 patterns with 10 iterations per pattern and different data length in each iteration. First eight bytes of data are used to store the following info for debug:

```
byte 0-4 : length
byte 5-6 : iteration#
byte 6-7 : test case#
```

9.110 sramtest

cmd: sramtest

Description: SRAM Test

Syntax: sramtest <begin> [<len> |<-end>]

9.111 msitest

cmd: msitest

Description: MSI Test

Syntax: msitest

Options:

-c<HEX> message count (2 to powered of c) (def=00000003)
-I initializing MSI block
-n<DEC> iteration

9.112 romtest

cmd: romtest

Description: ROM Test

Syntax: romtest

Options:

-n<DEC> iteration

9.113 gpiotest

cmd: gpiotest

Description: do GPIO test

Syntax: gpiotest

Options:

-n<DEC> iteration

9.114 cpudiag

cmd: cpudiag

Description: run diagnostic from internal CPU

Syntax: cpudiag

Options:

-b Test BD SRAM (0x0000-0x0fff and 0x4000-0x7fff)
-d Test DMA SRAM (0x2000-0x3fff)

-m	Test MBUF SRAM (0x8000-0x00000005)
-n<DEC>	Iteration
-r	Register Test
-T	Test with Tx CPU
-R	Test with Rx CPU

9.115 pcicfgtest

cmd: pcicfgtest

Description: Run PCI Config. Reg. Test

Syntax: pcicfgtest

Options:

-I	Do not perform reset before test
-r<DEC>	repeat count for each register test (def=1)
-n<DEC>	iteration

9.116 petest

cmd: petest

Description: Perform parity error test on a bridge

Syntax: petest <bridge>

9.117 errctrl

cmd: errctrl

Description: Configure Error Control Setting

Syntax: errctrl [w|c|a|l]

- w - Wait on Error
Program will pause and wait for user's action (eng. default)
- c - Continue on Error
Program will continue even if the error is detected
- a - Abort on Error (Manufacturing default)
Program stops
- l - Loop on Error
Program will retry the same test

9.118 sedvt

cmd: sedvt

Description: Perform NVRAM dvt test. When 'init' subcommand is entered, the NVRAM is initialized into pseudo random pattern. The original content is DESTROYED.

Syntax: sedvt [init]

Options:

-a	Access test
-e	Erase with reset
-f	force
-l<HEX>	size (def=00000100)
-n<DEC>	iteration (def=0)
-p	pause
-r	Read Test with reset
-s	skip checking entire NVRAM
-w	Read/Write Test with reset

9.119 miimisctest

cmd: miimisctest

Description: Run MII Misc. Tests.

Syntax: miimisctest

Options:

-n<DEC>	iteration
---------	-----------

9.120 cpugprtest

cmd: cpugprtest

Description: Run CPU GPR test.

Syntax: cpugprtest

Options:

-r run rx_cpu only
-t run tx cpu only
-u run Address Up

9.121 pmdcfg

cmd: pmdcfg

Description: Display Power Management Info

Syntax: pmdcfg

Options:

-a<HEX> 0 to add a pattern; otherwise delete (def=00000000)
-l<HEX> length (def=00000000)
-p<HEX> pattern. 0 - Increment; 1 - Increment (def=00000000)

9.122 pmpd

cmd: pmpd

Description: Power Down MAC. Input file wol.txt should be found in the same location of b57diag.exe. The input file contains patterns. If the file name is not specified, data zero will be used.

Syntax: pmpd [filename]

Options:

-a<HEX> 1 enables ACPI Packet Match (def=00000000)
-c<HEX> 0 to add a pattern; otherwise delete (def=00000000)
-f<string> File name which contains patterns
-m<HEX> 1 enables Magic MAC detection (def=00000000)
-o<HEX> offset (def=00000000)
-v<HEX> Versbose level (default=0) (def=00000000)

9.123 intr

cmd: intr

Description: Dump Interrupt Info

Syntax: intr

Example:

```
0:> intr
Interrupt Count      : 48337
IPC MASK             : 0xb8 0x0c
IPC IS1 IS2          : 0x00 0x00
IPC IRR1 IRR2        : 0x18 0x00
IPC ILCR1 ILCR2       : 0x20 0x0e
Worst Intr. Latency  : 54476 CPU clocks/50 uS
```

9.124 intrctrl

cmd: intrctrl

Description: Control Interrupt Controller

Syntax: intrctrl u|m

u : unmask current interrupt
m : mask current interrupt

Example:

1. Mask current interrupt
0:irq> intrctrl m
Masking Interrupt 10
2. Unmask current interrupt
0:irq> intrctrl u
Unmasking Interrupt 10

9.125 intt

cmd: intt

Description: Interrupt Tracer. This is special function to monitor interrupt functions.

Syntax: intt

9.126 mbuf

cmd: mbuf

Description: Dump Content of Mbufs. The display command must be specified by -c option or 'chain', 'info', 'cluster', 'hdr', and 'ckhdr'.

Syntax: mbuf [chain|info|cluster|hdr|ckhdr]

Options:

-c<HEX> command

- 0 - displays a MBUF
- 1 - displays a MBUF chain
- 2 - displays general MBUF information
- 3 - displays MBUF Cluster
- 4 - Check MBUF header corruption
- 5 - Dump all MBUF headers

-m<HEX> display mode, 0: decode, 1: in hex (def=00000000)

-n<DEC> MBUF number to display/decode (def=256)

-w MBUF workaround

Example:

1. Display MBUF chain.

```
0:> mbuf chain
->143->144->145->146->147->148->149->14a->14b->14c->14d->14e->14f->150
->151->152->153->154->155->156->157->158->159->15a->15b->15c->15d->15e
->15f->160->161->162->163->164->165->166->167->168->169->16a->16b->16c
->16d->16e->16f->170->171->172->173->174->175->176->177->178->179->17a
```

9.127 loaddrv

cmd: loaddrv

Description: Load Driver

Syntax: loaddrv

Options:

-4<HEX> Enable 4k-aligned memory (def=00000000)

-o<HEX> Allocate memory with specified offset (def=00000000)

-j Allocate memory for Jumbo packet

-t Allocate memory for TCP Segmentation

Example:

```
0:> loaddrv
Reinitializing PCI Configuration Space
Bus Number        : 1
Device/Funtion    : 11/0
Base Address      : 0xfb010000
IRQ               : 9
Bringing up MAC driver ... OK
PHY calculated ID: 60008162
BCM5702/03 Internal Phy Rev#2
Configuring BCM54xx ... Done
```

Determining Link Speed ... 1000Base-T Full Duplex

9.128 unloaddrv

cmd: unloaddrv

Description: Unload NIC driver

Syntax: unloaddrv

Example:

```
0:> unloaddrv
```

```
Unloading MAC driver ... OK
```

9.129 machalt

cmd: machalt

Description: Halt MAC controller

Syntax: machalt

Example:

```
0:> machalt
```

```
Halting MAC ... OK
```

9.130 ftq

cmd: ftq

Description: Dump FTQ

Syntax: ftq

Example:

```
0:> ftq
```

```
***** Dump FTQ Peak/Write (Control,Full Counter, Write/Peak) *****
DMA Read FTQ (1)      : 00000000 00000000 20000000
DMA High Read FTQ (2) : 00000000 00000000 60002160
DMA Write FTQ (6)     : 00000000 00000000 20000000
DMA High Write FTQ (7) : 00000000 00000000 20000000
DMA Complete Dx FTQ (3) : 00000000 00000000 20000000
Send BD Comp. FTQ (4) : 00000000 00000000 20000000
Send Data Init FTQ (5) : 00000000 00000000 20000000
Send Data Comp. FTQ (9) : 00000000 00000000 20000000
Rx BD Complete FTQ (13) : 00000000 00000000 60002160
Rx Data Complete FTQ (16) : 00000000 00000000 20000000
S/W Type 1 FTQ (8)    : 00000000 00000000 20000000
Host Coalescing FTQ (10) : 00000000 00000000 2000:00000000
MAC TX FTQ (11)       : 00000000 00000000 2000:00000000
Mbuf Cluster Free FTQ (12) : 00000000 00000000 2000:00000000
RX List Placement FTQ (14) : 00000000 00000000 2000:00000000
RX Data Initiator FTQ (15) : 00000000 00000000 2000:00000000
```


S/W Type 2 FTQ (17) : 00000000 00000000 2000:00000000

9.131 addmc

cmd: addmc

Description: Add Multicast MAC

Syntax: addmc <xx:xx:xx:xx:xx:xx>

Example:

0:> addmc FF:FF:00:0A:00:00

9.132 delmc

cmd: delmc

Description: Delete Multicast MAC

Syntax: delmc <xx:xx:xx:xx:xx:xx>

Example:

0:> delmc FF:FF:00:0A:00:00

9.133 txmacdes

cmd: txmacdes

Description: Program Destination address to UUT

Syntax: txmacdes <xx:xx:xx:xx:xx:xx>

9.134 txmacsrc

cmd: txmacsrc

Description: Program Source address to UUT

Syntax: txmacsrc <xx:xx:xx:xx:xx:xx>

9.135 chklddrv

cmd: chklddrv

Description: Check to see if driver is loaded. Returns 1 if driver is loaded, returns 0 otherwise.

Syntax: chklddrv

9.136 vlantag

cmd: vlantag

Description: Display/Clear vlanTag information.

Syntax: vlantag

Options:

-c clear vlanTag info

9.137 reg

cmd: reg

Description: register wizard. This command allows user to view edit registers.

Syntax: reg [pci|mii] [offset]

9.138 debug

cmd: debug

Description: Display debugs information

Syntax: debug <n>

- 1: Dump TX / RX Stats
- 2: Dump Clock Scale info
- 3: Clear worst interrupt latency
- 4: Toggle indirect access flag
- 5: Toggle PCI-X workaround

Example:

1. Display debug information.

```
0:> debug 1
Tx Packets Enqueued      :      0
Tx Packet Complete       :      0
Tx Packet Complete Error :      0
Rx Packets                :      0
Rx Unknown Packets       :      0
Rx Bad Packets           :      0
Rx Good Packets          :      0
```

9.139 gpiowrite

cmd: gpiowrite

Description: Write a Value into GPIO pin

Syntax: gpiowrite <GPIO_num> <value>

Valid value for <GPIO_num> is 0-2, <value> is 0 or 1.

Example:

1. Write 1 to GPIO#1 Pin

```
0:> gpiowrite 1 1
```

```
Writing 1 to GPIO#1
```

9.140 gpioread

cmd: gpioread

Description: Read GPIO Value

Syntax: gpioread

Example:

1. Read GPIO Pins

```
0:> gpioread
GPIO#0 : 1
GPIO#1 : 1
GPIO#2 : 0
```

9.141 pxecpy

cmd: pxecpy

Description: Load PXE Code to MBUF Memory. The file name must be specified in the parameter.

Syntax: pxecpy <file>

Options:

-f<string> filename

9.142 device

cmd: device

Description: Show or Switch Device. If no parameter is entered, it will display all device available.

Syntax: device <dev>

Options:

- n<HEX> Device Number (def=00000000)
- r Remove all current devices and re-scan available devices
- s Silent mode - do not display devices

9.143 version

cmd: version

Description: Display Program Version

Syntax: version

9.144 help

cmd: help

Description: Enter command group for the list of available commands. If no parameter is entered, all commands are displayed. Example: help vpd. For each command help, type the command and then '?'. Example: memtest ?

Syntax: help [vpd|nvram|cpu|dma|packet|mii|mem|test|power|irq|mac|misc]

9.145 ?

cmd: ?

Description: Alternate Help Command. This is same command as 'help' command.

Syntax: ? [vpd|nvram|cpu|dma|packet|mii|mem|test|power|irq|mac|misc]

9.146 radix

cmd: radix

Description: Change System Radix. Radix must be 2-16. Radix used for number entry. 16 means enter number in hex, and 10 means in decimal.

Syntax: radix <2 | 8 | 10 | 16>

9.147 nolog

cmd: nolog

Description: Close the Current Logfile

Syntax: nolog

9.148 log

cmd: log

Description: Save all output to log file

Syntax: log

Options:

-f<string> filename (for bcmediag compatibility only)

-a Append to existing file

9.149 pciinit

cmd: pciinit

Description: Initialize PCI configuration registers

Syntax: pciinit

9.150 pciscan

cmd: pciscan

Description: Scan for all PCI Devices

Syntax: pciscan

Example:

```
0:> pciscan
Scanning PCI devices ...
Bus Dev Func Vendor ID Device ID Class Base/IO Address IRQ
=== === ===
0 0 0 8086 7190 06:00:00 00000000:F8000008 0
0 1 0 8086 7191 06:04:00 00000000:00000000 0
0 7 0 8086 7110 06:01:00 00000000:00000000 0
0 7 1 8086 7111 01:01:80 00000000:00000000 0
0 7 2 8086 7112 0C:03:00 00000000:00000000 9
0 7 3 8086 7113 06:80:00 00000000:00000000 0
0 14 0 12AE 0003 02:00:00 00000000:F4000004 10
1 0 0 1002 4742 03:00:00 00009001:F5000000 11
```

9.151 dos

cmd: dos

Description: Execute DOS command. If no parameter is entered, DOS shell is entered.

Syntax: dos <dos command>

9.152 diagcfg

cmd: diagcfg

Description: Configure diagnostics parameter for Memory tests and Manufacturing test (NIC test).

Syntax: diagcfg

Example:

```
0:misc> diagcfg
```

Diagnostics Configuration Menu

1. Memory Test Configuration Menu
2. Test Configuration Menu
3. Driver Configuration Menu
4. Abort On Failure is enabled
5. Save Configuration

Enter your choice or ESC to exit -> 1

Memory Test Configuration Menu

1. SRAM BD1 Start (0x00000000-0x00000fff) : 00000000
2. SRAM BD1 End (0x00000000-0x00000fff) : 00000fff
3. SRAM BD2 Start (0x00004000-0x00007fff) : 00004000
4. SRAM BD2 End (0x00004000-0x00007fff) : 00007fff
5. SRAM DMA Start (0x00002000-0x00003fff) : 00002000
6. SRAM DMA End (0x00002000-0x00003fff) : 00003fff
7. SRAM MBUF Start (0x00008000-0x00015fff) : 00008000
8. SRAM MBUF End (0x00008000-0x00015fff) : 00000000
9. SRAM SPAD Start (0x00030000-0x00037fff) : 00030000
10. SRAM SPAD End (0x00030000-0x00037fff) : 00037fff
11. Ext. SRAM Start (0x00020000-0x00ffffff) : 00020000
12. Ext. SRAM End (0x00020000-0x00ffffff) : 00ffffff
13. MBUF Bank (1 - Odd ; 2 - Even ; 3 - Both) : 3
0. Exit to previous menu

Enter your choice (option=parameter) -> 0

Diagnostics Configuration Menu

1. Memory Test Configuration Menu
2. Test Configuration Menu
3. Driver Configuration Menu

4. Abort On Failure is enabled
5. Save Configuration

Enter your choice or ESC to exit -> 2

Test Configuration Menu

```
A1. Indirect Register.....: Enabled
A2. Control Register.....: Enabled
A3. Interrupt.....: Enabled
A4. Built In Self.....: Enabled
A5. PCI Cfg Register.....: Enabled
B1. Scratch Pad.....: Enabled
B2. BD SRAM.....: Enabled
B3. DMA SRAM.....: Enabled
B4. MBUF SRAM.....: Enabled
B5. MBUF SRAM via DMA.....: Enabled
B6. External SRAM.....: Disabled
B7. CPU GPR.....: Enabled
C1. NVRAM.....: Enabled
C2. CPU.....: Enabled
C3. DMA.....: Enabled
C4. MII.....: Enabled
C5. VPD.....: Enabled
C6. ASF Miscellaneous.....: Enabled
C7. Expansion ROM.....: Enabled
D1. MAC Loopback.....: Enabled
D2. PHY Loopback.....: Enabled
D3. External Loopback.....: Disabled
D5. MII Miscellaneous.....: Enabled
D6. MSI.....: Enabled
```

Enter test number to toggle or ESC to exit ->

Diagnostics Configuration Menu

1. Memory Test Configuration Menu
2. Test Configuration Menu
3. Driver Configuration Menu
4. Abort On Failure is enabled
5. Save Configuration

Enter your choice or ESC to exit -> 3

Driver Configuration Menu

```
1. Rx Coalescing Ticks                : 1000
2. Rx Coalescing Ticks During Intr    : 0
3. Rx Coalescing Frames                : 1
4. Rx Coalescing Frames During Intr    : 0
5. Tx Coalescing Ticks                : 1000
6. Tx Coalescing Ticks During Intr    : 0
7. Tx Coalescing Frames                : 1
8. Tx Coalescing Frames During Intr    : 0
9. Statistics Coalescing Ticks         : 1000000
10. Tx Packet Descriptor Count         : 50
11. Rx Standard Packet Count           : 100
12. Rx Jumbo Packet Count              : 50
13. Enable Mini Ring {Yes(1),No(0)}    : 1
14. Mini Ring Packet Size (64-512)     : 64
15. External Memory Exists {Yes(1), No(0)} : 0
16. MBUF Base                          : 0x008000
17. MBUF Length                        : 0x018000
```

```
18. Tx Flow Control { Enable(1),Disable(2) } : Disable
19. Rx Flow Control { Enable(1),Disable(2) } : Disable
20. Auto Link Speed { Enable(1),Disable(2) } : Enable
21. Send Ring Size { 32, 64, 128, 256, 512 } : 512
22. Rx Ring Size { 32, 64, 128, 256, 512 } : 512
0. Exit to previous menu
```

Enter your choice (option=paramter) -> 0

Diagnostics Configuration Menu

```
1. Memory Test Configuration Menu
2. Test Configuration Menu
3. Driver Configuration Menu
4. Abort On Failure is enabled
5. Save Configuration
```

Enter your choice or ESC to exit ->

9.153 reset

cmd: reset

Description: Reset Chip

Syntax: reset

Options:

-c	Simulate cold reset
-t	Display time from reset to firmware invert signature
-w	Wait for firmware signature

9.154 smbus

cmd: smbus

Description: ASF terminal. Run this command to access SMBus, the parameter a1 and a2 are one byte value to specify the NIC SMBus Addresses. It sets to 0 by default.

Syntax: smbus [a1 a2]

Options:

-s	Run in slave mode
----	-------------------

9.155 cls

cmd: smbus

Description: Clear Screen.

Syntax: cls

9.156 loop

cmd: loop

Description: loop on command.

Syntax: loop [iteration] <cmd> [<parameter> ...]

9.157 dbmode

cmd: dbmode

Description: Set DEBUG Mode to On or Off Mode.

Syntax: dbmode on|off

9.158 asf

cmd: asf

Description: run asf monitor program with option to Load asf firmware image. This routine loads firmware images into CPU memory and execute the RXCPU. The default files names are asfinit.bin, asfcputa.bin, and asfcpub.bin, which can be over written by parameters.

Syntax: asf [init_img [rx_img [tx_img]]]

Options:

-l	Load firmware only
-m	Enter asf mode only
-w	Simulate warm boot

9.159 new

cmd: new

Description: Display new command available. The default parameter for [n] is 10

Syntax: new [n]

9.160 asfprg

cmd: asfprg

Description: Program asf firmware into NVRAM. The default files names are asfinit.bin, asfcua.bin, and ascpub.bin, which can be over written by parameters.

Syntax: asfprg [init_img [rx_img [tx_img]]]

Options:

-v<HEX> verbose level (0,1,2) (def=00000001)

9.161 sleep

cmd: sleep

Description: suspense process for Excute command from a file

Syntax: sleep [miliseconds]

9.162 fillpattern

cmd: fillpattern

Description: Fill WOL matching pattern into Misc. Memory Location.

Syntax: fillpattern [filename]

Options:

-e<HEX> (end address + 1) of the first block (def=00020000)

-f<string> filename which contains data pattern

-o<HEX> sram first block offset to be loaded (def=00000000)

-s<HEX> sram second block offset to be loaded (def=00000000)

9.163 inp

cmd: inp

Description: input port

Syntax: inp <addr>

Options:

-l long word size

-w word size

9.164 outp

cmd: outp

Description: input port

Syntax: outp <addr> <value>

Options:

-l long word size

-w word size

9.165 switch

cmd: switch

Description: Alternate 'device' command. If no parameter is entered, it will display all device available.

Syntax: switch <dev>

Options:

-n<HEX> Device Number (def=00000000)

-r Remove all current devices and re-scan available devices

-s Silent mode - do not display devices

9.166 do

cmd: do

Description: Excute commands from a file.

Syntax: do <filename> [with <parameter1>, ...]

Options:

-c continue on error

-e echo command

-p<DEC> pause between each command. If a value is entered, it delays for # of ms (def=0)

9.167 txfill

cmd: txfill

Description: Fill tx buffer with pattern and packet length (14-9018).

Syntax: txfill [-f=<file>] [-x=<load length>] [-p=<pattern>] [-l=<packet length>]

Options:

- f<string> filename
- l<DEC> packet length in bytes (14-9018) (def=1514)
- p<DEC> pattern selection (0-8) (def=0)
- x<DEC> length to load in bytes (default to EOF)

Pattern:

- 0. Use buffer as is
- 1. Increment data
- 2. Random
- 3. all 0
- 4. all FF
- 5. AA55
- 6. 55AA
- 7. IP_Iden-Inc
- 8. Load from file
- 9. 8 bytes of 0 and f
- 10. 16 bytes of 0 and f
- 11. 32 bytes of 0 and f
- 12. 64 bytes of 0 and f

9.168 wbuf

cmd: wbuf

Description: Write tx|rx buffer with specified data at offset. Only works with static buffer selection -A.

Syntax: wbuf tx|rx <offset> <data>

9.169 rbuf

cmd: rbuf

Description: Read tx|rx|bistin|bistout|bistex buffer. Read tx|rx|bistin|bistout|bistex buffer with specified at offset with a specified length. Only works with static buffer selection -A.

Syntax: rbuf tx|rx|bistin|bistout|bistex <offset> <len>

9.170 cpbuf

cmd: cpbuf

Description: Copy the content of rx buffer into tx buffer. Only works with static buffer selection –A.

Syntax: cpbuf <offset> <length>

9.171 echo

cmd: echo

Description: echo <string> to screen.

Syntax: echo <string>

9.172 pause

cmd: pause

Description: Pause for user to hit a key. If no parameter is entered, 'press any key to continue...' will be displayed

Syntax: pause < message>

9.173 verbose

cmd: verbose

Description: change verbose setting

Syntax: verbose

Options:

- | | |
|----|---------------------------|
| -c | toggles CONSOLE |
| -e | toggles ERROR |
| -i | toggles IO |
| -d | toggles DEBUG |
| -p | toggles PRINTER |
| -w | toggles WARNING |
| -r | toggles Interrupt Verbose |

9.174 beep

cmd: beep

Description: Create a beep sound. The default to beep once. If parameter 'n' is entered, it beeps n times

Syntax: beep [<n> | on | off]

9.175 var

cmd: var

Description: Display current variables

Syntax: var

9.176 meminfo

cmd: meminfo

Description: report the memory information

Syntax: meminfo

9.177 delvar

cmd: delvar

Description: Delete local variables

Syntax: delvar

9.178 regdump

cmd: regdump

Description: Dump register content to a file

Syntax: regdump

Options:

- c PCI Config Reg.
- f<string> filename
- m MII Registers
- r<DEC> Mac Registers (def=1)

9.179 regcomp

cmd: regcomp

Description: Compare register content to a file. This command may be used together with regdump to find out any register got changed.

Syntax: regcomp <filename>

Options:

-c	PCI Config Reg.
-f<string>	filename
-m	MII Registers
-r<DEC>	Mac Registers (def=1)

9.180 regrestore

cmd: regrestore

Description: Restore register content from a file. This command may be used together with regdump to restore register got changed.

Syntax: regrestore <filename>

Options:

-c	PCI Config Reg.
-f<string>	filename
-m	MII Registers
-r<DEC>	Mac Registers (def=1)

9.181 readbr

cmd: readbr

Description: Read bridge's configuration space.

Syntax: readbr

9.182 writebr

cmd: writebr

Description: Write bridge's configuration space.

Syntax: writebr

9.183 writebr

cmd: writebr

Description: Write bridge's configuration space.

Syntax: writebr

9.184 findbridge

cmd: findbridge

Description: Find all bridges in the system.

Syntax: findbridge

9.185 bridge

cmd: bridge

Description: Switch to specified bridge.

Syntax: bridge

9.186 pere

cmd: pere

Description: Enable parity error response on a bridge. Defaults to current bridge.

Syntax: pere <bridge>

9.187 perd

cmd: perd

Description: Disable parity error response on a bridge. Defaults to current bridge.

Syntax: perd <bridge>

9.188 peclr

cmd: peclr

Description: Clear parity error on bridge. Defaults to current bridge.

Syntax: peclr <bridge>

9.189 pechk

cmd: pechk

Description: Check parity error on bridge. Defaults to current bridge.

Syntax: pechk <bridge>

9.190 secfg1

cmd: secfg1

Description: Configure NVRAM Group 1

Syntax: secfg1

Options:

-m	Mac address xx:xx:xx:xx:xx:xx
-r	Power Dissipated D3:D2:D1:D0
-c	Power Consumed D3:D2:D1:D0
-v	Vendor ID
-d	Vendor Device ID
-s	SubSystem Vendor ID
-i	SubSystem Device ID
-p	PXE 1:Enable 2:Disable
-x	PXE SP 0:Auto 1:10HD 2:10FD 3:100HD 4:100FD 6:1000FD (TBI)
-w	Magic Packet WOL 1:Enable 2:Disable

9.191 secfg2

cmd: secfg2

Description: Configure NVRAM Group 2

Syntax: secfg2

Options:

-p	Product Name
-n	Part Number
-e	Engineering Change
-s	Serial Number
-m	Manufacturing ID
-a	Asset Tag
-r	Part Rev
-v	Voltage
-f	Force PCI Mode 1:Enable 2:Disable

9.192 secfg3**cmd:** secfg3**Description:** Configure NVRAM Group 3**Syntax:** secfg3**Options:**

-l	Led Mode 0:Mac 1:Phy1 2:Phy2 3:S Traffic 4:Shasta Mac 5:Wireless Combo
-r	Max PCI Retry 0-7, 8:Auto
-a	ASF 1:Enable 2:Disable
-d	Dual Mac 0:Norm 1:MacB 2:MacA 3:XBAR 4:Swap 7:SwapXBAE
-m	MBA Boot Protocol 0:PXE 1:RPL 2:BOOTP
-b	MBA Bootstrap Type 0:Auto 1:BBS 2:Int18 3:Int19
-t	MBA Delay Time 0-15
-e	Exp ROM 0:64K 1:128K 2:256K 3:512K 4:1M 5:2M 6:4M 7:8M 8:16M
-n	Design Type 0:NIC 1:LOM

9.193 secfg4

cmd: secfg4

Description: Configure NVRAM Group 4

Syntax: secfg4

Options:

-v	Read VPD Vendor Data V0
-w	Read/Write VPD Vendor Data V1
-n	Reversed Nway 0:No 1:Yes
-s	Limit WOL Speed to 10 0:No 1:Yes
-f	Fiber WOL Capable 0:No 1:Yes
-c	Clock-Run 0:Disable 1:Enable
-p	Enable Phy Auto Power Down 0:No 1:Yes
-d	Disable Power Saving 0:No 1:Yes
-h	Hide MBA Setup Prompt 0:Disable 1:Enable
-k	MBA Setup Hot Key 0:Ctrl-S 1:Ctrl-B

9.194 cpufetch

cmd: cpufetch

Description: Test CPU Instruction fetch logic with 1.1V and 1.3 V setting

Syntax: cpufetch

9.195 exit

cmd: exit

Description: Exit System

Syntax: exit

9.196 quit

cmd: quit

Description: Exit System

Syntax: quit

10 ERROR MESSAGES

```
/* NO_ERROR                0 */ "",
/* ERR_IND_REG_ERR         1 */ "Got 0x%08X @ 0x%08X. Expected 0x%08X",
/* ERR_CHIP_RUNNING       2 */ "Cannot perform task while chip is running",
/* ERR_BAD_NIC            3 */ "Invalid NIC device",
/* ERR_READ_ONLY_CLEAR    4 */ "Read only bit %s got changed after writing zero at
offset 0x%X",

/* ERR_READ_ONLY_SET      5 */ "Read only bit %s got changed after writing one at
offset 0x%X",
/* ERR_READ_WRITE_NOT_CLEAR 6 */ "Read/Write bit %s did not get cleared after writing
zero at offset 0x%X",
/* ERR_READ_WRITE_NOT_SET  7 */ "Read/Write bit %s did not get set after writing one at
offset 0x%X",
/* ERR_BIST                8 */ "BIST failed",
/* ERR_INTERRUPT           9 */ "Could not generate interrupt",

/* ERR_ABORT              10 */ "Aborted by user",
/* ERR_DMA_TXDATA         11 */ "Tx DMA:Got 0x%08X @ 0x%08X. Expected 0x%08X",
/* ERR_DMA_RXDATA        12 */ "Rx DMA:Got 0x%08X @ 0x%08X. Expected 0x%08X",
/* ERR_TXDMA             13 */ "Tx DMA failed",
/* ERR_RXDMA            14 */ "Rx DMA failed",

/* ERR_MEM               15 */ "Data error, got 0x%08X at 0x%08X, expected 0x%08X",
/* ERR_MEM2              16 */ "Second read error, got 0x%08X at 0x%08X, expected
0x%08X",
/* ERR_EEP_WRITE         17 */ "Failed writing NVRAM at 0x%04X",
/* ERR_EEP_READ          18 */ "Failed reading NVRAM at 0x%04X",
/* ERR_EEP_DATA          19 */ "NVRAM data error, got 0x%08X at 0x%04X, expected
0x%08X",

/* ERR_FILE_OPEN         20 */ "Cannot open file %s",
/* ERR_BAD_CPU_CFG       21 */ "Invalid CPU image file %s",
/* ERR_IMAGE_SIZE        22 */ "Invalid CPU image size %d",
/* ERR_MALLOC            23 */ "Cannot allocate memory for size %d",
/* ERR_CPU_RESET         24 */ "Cannot reset %cX CPU",

/* ERR_CPU_NO_RESP       25 */ "%cx CPU does not respond",
/* ERR_CPU_TEST          26 */ "%cx CPU test failed",
/* ERR_DMA_RANGE         27 */ "Invalid Test Address Range\nValid NIC address is
0x%08X-0x%08X and exclude 0x%08X-0x%08X",
/* ERR_DMA_DATA          28 */ "DMA:Got 0x%02X @ 0x%08X. Expected 0x%02X\nSRAM
data=0x%02X @ 0x%08X",
/* ERR_PHY_ID           29 */ "Unsupported PhyId %04X:%04X",

/* ERR_PHY_TOO_MANY_REG  30 */ "Too many registers specified in the file, max is %d",
/* ERR_VPD_WRITE         31 */ "Cannot write to VPD address %04X",
/* ERR_VPD_DATA          32 */ "VPD data error, got %08X @ 0x%04X, expected %08X",
/* ERR_NO_LINK           33 */ "No good link! Check Loopback plug",
/* ERR_DATA_TX           34 */ "Cannot TX Packet!",

/* ERR_DATA_TX_MISSING   35 */ "Requested to Tx %d. Only %d is transmitted",
/* ERR_DATA_RX_MISSING   36 */ "Expected %d packets. Only %d good packet(s) have been
received\n%d unknown packets have been received.\n%d bad packets have been received.",
/* ERR_INVALID_TEST      37 */ "%c%d is an invalid Test",
/* ERR_EEPROM_CHECKSUM   38 */ "NVRAM checksum error",
/* ERR_READING_WOL_PXE   39 */ "Error in reading WOL/PXE",

/* ERR_READING_WOL_PXE   40 */ "Error in writing WOL/PXE",
/* ERR_NO_EXT_SRAM       41 */ "No external memory detected",
/* ERR_DMA_LEN           42 */ "DMA buffer %04X is too large, size must be less than
%04X",
/* ERR_FILE_TOO_BIG      43 */ "File size %d is too big, max is %d",
/* ERR_INVALID           44 */ "Invalid %s",

/* ERR_WRITE             45 */ "Failed writing 0x%x to 0x%x",
/* CMD_QUIT              46 */ "",
/* ERR_CPU_MEM_ERR       47 */ "%s CPU access error @ %08X, expected %08X but got
%08X",
/* ERR_ENDIF             48 */ "",
/* ERR_ROM_D_DATA        49 */ "ROM disable error, data returned while disabled",
```

```

/* ERR_CHIP_NOT_RUNNING      50 */ "Cannot perform task while chip is not running. (need
driver)",
/* ERR_NO_REG_DEF            51 */ "Cannot open register define file or content is bad",
/* ERR_ASF_RST              52 */ "ASF Reset bit did not self-cleared",
/* ERR_ASF_ATTN_LOC         53 */ "ATTN_LOC %d cannot be mapped to %cX CPU event bit %d",
/* ERR_ASF_RST_VAL          54 */ "%s Register is not cleared to zero after reset",

/* ERR_ASF_PA_TIMER         55 */ "Cannot start poll_ASF Timer",
/* ERR_ASF_PA_CLEAR         56 */ "poll_ASF bit did not get reset after acknowledged",
/* ERR_ADF_NO_STAMP         57 */ "Timestamp Counter is not counting",
/* ERR_ADF_NO_TIMER         58 */ "%s Timer is not working",
/* ERR_ASF_EVENT            59 */ "Cannot clear bit %s in %cX CPU event register",

/* ERR_EEP_FILESIZE         60 */ "Invalid %s file size, expected %d but only can read %d
bytes",
/* ERR_MAGIC_VALUE          61 */ "Invalid magic value in %s, expected %08x but found
%08x",
/* ERR_EEP_FMT              62 */ "Invalid manufacture revision, expected %c but found %c",
/* ERR_EEP_BOOTVER          63 */ "Invalid Boot Code revision, expected %d.%d but found
%d.%d",
/* ERR_EEP_CANNOT_WRITE     64 */ "Cannot write to NVRAM",

/* ERR_EEP_CANNOT_READ      65 */ "Cannot read from NVRAM",
/* ERR_BAD_CHECKSUM         66 */ "Invalid Checksum",
/* ERR_BAD_MAGIC_VALUE      67 */ "Invalid Magic Value",
/* ERR_MAC                  68 */ "Invalid MAC address, expected %02X-%02X-%02X-%02X-%02X-
%02X",
/* ERR_BUS                  69 */ "Slot error, expected an UUT to be found at location
%02X:%02X:00",

/* ERR_SPEC_MEM             70 */ "Adjacent memory has been corrupted while testing block
0x%08x-0x%08x\nGot 0x%08x @ address 0x%08x. Expected 0x%08x",
/* ERR_NOT_SUPPORT          71 */ "The function is not Supported in this chip",
/* ERR_BAD_CRC              72 */ "Packets received with CRC error",
/* ERR_MII_ERR_BITS_SET     73 */ "MII error bits set: %04x",
/* ERR_INIT_MAC             74 */ "CPU does not initialize MAC address register
correctly",

/* ERR_FW_FILE_FORMAT       75 */ "Invalid firmware file format",
/* ERR_RESET_TX_CPU         76 */ "Resetting TX CPU Failed",
/* ERR_RESET_RX_CPU         77 */ "Resetting RX CPU Failed",
/* ERR_INVALID_MAC_ADDR     78 */ "Invalid MAC address",
/* ERR_MAC_REG              79 */ "Mac address registers are not initialized correctly",

/* ERR_BOOTCHECKSUM         80 */ "NVRAM Bootstrap checksum error",
/* ERR_VPD_READONLY         81 */ "Write operation changed VPD read only data from %08X to
%08X at %04X",
/* ERR_VPD_READ             82 */ "Cannot read data from VPD address %04X",
/* ERR_MEM_READ             83 */ "Memory read and compare error",
/* ERR_MEM_WRITE            84 */ "Memory write error", /* no longer in use */

/* ERR_PXE_PGM              85 */ "PXE Programming Error",
/* ERR_PXE_VFY              86 */ "PXE Verification Error",
/* ERR_EXT_MEM_EXE_TIMEOUT  87 */ "Cannot execute code from external memory, pc=%08X",
/* ERR_EXT_MEM_SIZE         88 */ "External memory size detection error",
/* ERR_RESET_TIMEOUT        89 */ "Reset Time",

/* ERR_MSI_ERR_NOTCLEAR     90 */ "MSI Error bits are not cleared after reset",
/* ERR_MSI_DATA             91 */ "MSI expected %04X, but read %04X at %08X",
/* ERR_MEM_INIT             92 */ "mem pool initialization failed",
/* ERR_MEM_UNINIT           93 */ "mem pool un-initialization failed",
/* ERR_PCI_REGS_WIDTH       94 */ "Read/Write PCI regs width %d affects wider than
expected at offset 0x%X",

/* ERR_LINK_STATUS          95 */ "Link status error in auto-polling mode",
/* ERR_PHY_INTERRUPT        96 */ "Phy interrupt did not happen",
/* ERR_EEP_BIT_BANG         97 */ "EEPROM test fails in bit-bang mode at address %X",
/* ERR_ROM_SIZE             98 */ "ROM size error\nExpected %08X but read %08X at\nROM Bar
(0x30) register with %d written to ROM size reg.(0x88)",
/* ERR_ROM_DATA             99 */ "Data Error\nExpected %08X but read %08X at %08X",

/* ERR_ROM_ENABLE          100 */ "Expansion ROM Desired bit is not set after loading
firmware",
/* ERR_GPIO                 101 */ "GPIO%d Error, write=%d, read=%d",

```

```
/* ERR_GPIO5704          102 */ "Dev:%d Expected GPIO 0/1/2 = %d/%d/%d, but read as
%d/%d/%d",
/* ERR_BIST_NOT_DONE     103 */ "Bist test did not complete internally",
/* ERR_BIST_DATA_MISCOMP 104 */ "Bist data miscompared at bit: %d out: %d exp: %d",

/* ERR_CPU_NO_RESPONSE   105 */ "No Response from firmware",
/* ERR_CPU_ERR_CODE       106 */ "%s CPU returned result %d, key = %d",
/* ERR_LOOP               107 */ "",
/* ERR_SKIP               108 */ "",
/* CMD_ELSE,              109 */ "",

/* CMD_ELSEIF,           110 */ "",
/* CMD_BREAK,            111 */ "",
/* CMD_ENDWHILE,          112 */ "",
/* ERR_BYTE,              113 */ "Byte access error: expected %02x at %08x but got %02x",
/* ERR_WORD,              114 */ "Word access error: expected %04x at %08x but got %04x",

/* ERR_NO_LINK_DOWN      115 */ "No link down found",
/* ERR_MISMATCHED_DEVICEID 116 */ "bootcode Image file belongs to %d family, does not
match with board %d",
/* ERR_INVALID_DATA_SIZE  117 */ "Invalid data size",
/* ERR_MAC_ADDR_ENDED     118 */ "Runs out of Mac Address",
/* ERR_ILLEGAL_MAC_ADDR   119 */ "Illegal Mac Address",

/* ERR_BIST_DATA_INVALID  120 */ "Invalid bist data from buffer at %d",
/* ERR_INVALID_BOND_ID    121 */ "Invalid bond id",
/* ERR_BAD_CPU_RESET      122 */ "CPU reset failed, register 5034 is 0x%x",
/* ERR_INCORRECT_VERSION  122 */ "Incorrect version",
/* ERR_MISMATCH_CFG_VERSION 123 */ "Mismatched CFG and FW Image version",
/* ERR_NOT_SUPP_CFG_BW    124 */ "Not support ASF_T_VERSION backward compatible",
/* ERR_POST_1G_LB         125 */ "1G Tx/Rx Lines Have A Short/Open",
/* ERR_NO_LINK10          126 */ "No good link! Check Loopback plug",
/* ERR_NO_LINK100         127 */ "No good link! Check Loopback plug",
/* ERR_NO_LINK1000        128 */ "No good link! Check Loopback plug",
/* ERR_DATA_TX10          129 */ "Cannot TX Packet!",
/* ERR_DATA_TX100         130 */ "Cannot TX Packet!",
/* ERR_DATA_TX1000        131 */ "Cannot TX Packet!",
/* ERR_DATA_TX_MISSING10  132 */ "Requested to Tx %d. Only %d is transmitted",
/* ERR_DATA_TX_MISSING100 133 */ "Requested to Tx %d. Only %d is transmitted",
/* ERR_DATA_TX_MISSING1000 134 */ "Requested to Tx %d. Only %d is transmitted",
/* ERR_DATA_RX_MISSING10  135 */ "Expected %d packets. Only %d good packet(s) have been
received\n%d unknown packets have been received.\n%d bad packets have been received.",
/* ERR_DATA_RX_MISSING100 136 */ "Expected %d packets. Only %d good packet(s) have been
received\n%d unknown packets have been received.\n%d bad packets have been received.",
/* ERR_DATA_RX_MISSING1000 137 */ "Expected %d packets. Only %d good packet(s) have been
received\n%d unknown packets have been received.\n%d bad packets have been received.",
```