

AN50R

Socket 754

**AMD Athlon™ 64 Processor
with 200 MHz FSB**

Based DDR MAINBOARD

User's Manual

Shuttle® AN50R

Socket 754

AMD Athlon™ 64 Processor

Based DDR Mainboard

Manual Version 1.0

Copyright

Copyright© 2003 by Shuttle® Inc. All Rights Reserved.

This publication, including all photos, illustrations, and software, is protected under international copyright laws, with all rights reserved. Reproducing any of the material contained herein is prohibited without the consent of the publisher.

Disclaimer

Shuttle® Inc. shall not be liable for any incidental or consequential damages resulting from the performance or use of this product.

This company makes no representations or warranties regarding the contents of this manual. Information in this manual has been carefully checked for reliability; however, no guarantee is given as to the correctness of the contents. In the interest of continued product improvement, this company reserves the right to revise the manual or include changes in the specifications of the product described within it at any time without notice and without obligation to notify any person of such revision or changes. The information contained in this manual is provided for general use by the customers.

Trademarks

Shuttle is a registered trademark of Shuttle Inc.

NVIDIA is a registered trademark of NVIDIA Corporation.

AMD, Athlon™ 64 is registered trademarks of AMD Corporation.

PS/2 is a registered trademark of IBM Corporation.

AWARD is a registered trademark of Award Software Inc.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

General Notice: Other product names used in this manual are ascribed to their respective owners and acknowledged.

Statement of Shuttle Mainboard via the EMI Test

Shuttle mainboards have been via the EMI test in terms of series of regulations: EN55022/ CISPR22/AS/NZS3548 Class B, EN55024 (1998/AS/NZS), EN4252.1 (1994), EN61000, ANSI C63.4 (1992), CFR47 Part 15 Subpart B, and CNS13438 (1997). The items tested are illustrated as follows:

(A) Voltage: AC 110V/60HZ & AC 230V/50HZ

(B) Tested Product Information:

Product Name: PC Mainboard

Status: Sample

Model Name: AN50R

S/N: N/A

CPU:

External Frequency: 200 MHz

AMD Athlon™ 64 3100+

External Frequency: 200 MHz

AMD Athlon™ 64 3400+

Mouse Port: one port with 6 pins

Keyboard Port: one port with 6 pins

Parallel Port: one port with 25 pins

Serial Port: two ports with 9 pins respectively

1394 Port: three port with 6 pins

Line-Out & Line-In & Mic-In Ports : one port for each

Giga LAN Port: one port with 9 pins

LAN Port: one port with 9 pins

USB 2.0 Port: four ports with 4 pins respectively

All CPUs have completely been tested, and values offered by the worst EMI combination of CPU external frequency are listed as follows:

Test Mode	External Frequency	CPU	Case Open/Closed
1	200 MHz	K8 3400+	Closed
2	200 MHz	K8 3400+	Open

(C) Remedy for the Tested Product & Its EMI Interference:

Remedy: N/A

EMI Interference:

Crystal: 14.318MHz(X1)/32.768 KHz(X2)/25.000 MHz(X4)/25.000 MHz(X5)/

25.000 MHz(X6)/24.576 MHz(X7)

Clock Generator: N/A

(D) Supported Host Peripherals:

Host Peripheral	Product Name	Model Name	S/N	FCC ID
#1	Case	KF45A	N/A	
#2	Power Supply (300W)	ENP-0730 (ATX12V)	1000002885	
#3	IBM HDD (30.7GB)	91024UB	YKFY7981	38921168
#4	MITSUMI FDD	D353M		
#5	SONY VCD Player	CDU4811		3892A291
#6	AGP Card	Winfast Geforce 2 MX		3892C520
#7	Power Cable	Detachable and Shielded		

(E) Notices for Assembling Computers:

1. Cases should be made of iron or other metal that has good electric conductivity.
2. Cylinders in a case should be made of metal, and as having a mainboard mounted in a case, make sure screws are all utilized and fastened on a mainboard.
3. An I/O shielding should be contacted with I/O metallic parts of a mainboard.
4. Cables should appropriately be arranged and fixed in a case. Follow instructions:
 - Leave IDE cables not crossed upon CPU and SDRAM;
 - Leave power cables minimum in length, and not crossed upon a mainboard;
 - Leave CPU fan cables minimum in length, and not near CPU;
 - Leave cables on panels and other spare cables tied in a computer case.
5. Make sure an EMI shielding attached to a case has properly been installed.
6. Make sure a 5.25" or 3.5" FDD and screws are fastened to an EMI shielding.
7. Make sure a case is closely in contact with EMI connected points.
8. Make sure there is no cleft in a case which is not deformed.
9. Make sure a PCI or AGP door is bound to a case.
10. Make sure cables of other devices (fans or some others) are fixed in a case.

TABLE OF CONTENTS

WHAT'S IN THE MANUAL	4
Quick Reference	4
About This Manual	4
1 INTRODUCTION	5
1.1 TO DIFFERENT USERS	5
FIRST-TIME DIY SYSTEM BUILDER	5
EXPERIENCED DIY USER	5
SYSTEM INTEGRATOR	5
1.2 ITEM CHECKLIST:	6
2 FEATURES	8
2.1 SPECIFICATIONS	8
3 HARDWARE INSTALLATION	11
3.1 STEP-BY-STEP INSTALLATION	11
STEP 1 Install the CPU	12
STEP 2 Set Jumpers	13
STEP 3 Install DDR SDRAM System Memory	13
STEP 4 Install Internal Peripherals in System Case	14
STEP 5 Mount the Mainboard on the Computer Chassis	15
STEP 6 Connect Front Panel LEDs/Switches/USBs	16
STEP 7 Connect IDE ,Floppy Disk and Serial ATA Drives	17
STEP 8 Connect Other Internal Peripherals	18
STEP 9 Connect the Power Supplies	20
STEP 10 Install Add-on Cards in Expansion Slots	20
STEP 11 Connect External Peripherals to Back Panel	21
STEP 12 System Boot Up For the First-Time	22
STEP 13 Install Drivers & Software Components	23
3.2 JUMPER SETTINGS	24
JUMPERS & CONNECTORS GUIDE	25
<i>Jumpers</i>	
Clear CMOS Setting (JP18)	28

Back Panel Connectors

PS/2 Mouse & PS/2 Keyboard Port Connectors	29
Parallel Port Connector	29
COM1 Port Connector	29
SPDIF-Out Connector	29
IEEE 1394 Connector	30
10/100 base-T LAN Port Connector	30
USB Port Connectors	30
Gigabit LAN Port Connector	30
Line-Out Port Connector	31
Line-In (Rear-Out) Port Connector	31
Mic-In (Center/Bass-Out) Port Connector	31

Front Panel Connectors

HDD LED Connector (HLED)	32
Green LED Connector (GLED)	32
Hardware Reset Connector (RST)	33
ATX Power On/Off Switch Connector (PWON)	33
EPMI Connector (EPMI)	34
Power LED Connector (PLED)	34
Speaker Connector (Speaker)	34

Internal Peripheral Connectors

Enhanced IDE and Floppy Connectors (IDE1/IDE2 & FLP1)	35
Serial ATA Connectors (ATA1/ATA2)	35

Other Connectors

ATX Power Supply Connectors (ATX1/CN8)	36
CPU and System Fan Connectors (FAN1/2/3)	37
IR Header (JP8)	37
Audio CD_IN Connectors (CN4/CN5)	38
Audio AUX_IN Connector (CN6)	38
Center/Bass & Rear_Out Header (JP9/JP20)	39
Front Panel Audio Header (JP11)	39
SPDIF IN Header (JP10)	40

Extended USB Header (JP7)	40
IEEE 1394 Connector (JP15/JP16)	41
Wake-On-Lan Connector (WOL1)	41
Power Botton and Reset Botton (SW1/SW2)	42
3.3 SYSTEM MEMORY CONFIGURATION	43
INSTALL MEMORY	43
UPGRADE MEMORY	44
4 SOFTWARE UTILITY	45
4.1 Mainboard CD Overview	45
4.2 Install mainboard software Driver	46
4.2.A Install nVIDIA Chipset Driver	47
4.2.B Install Intel LAN Driver	47
4.2.C Install Silicon RAID Driver	48
4.2.D Install Silicon Utility Driver	48
4.2.E Install nVIDIA USB2.0 Driver	49
4.3 View the User's Manual	50
5 BIOS SETUP	51
5.1 ENTER BIOS	51
5.2 THE MAIN MENU	52
STANDARD CMOS FEATURES	54
ADVANCED BIOS FEATURES	56
ADVANCED CHIPSET FEATURES	59
INTEGRATED PERIPHERALS	62
POWER MANAGEMENT SETUP	66
PNP/PCI CONFIGURATIONS	68
PC HEALTH STATUS	69
CPU Ratio/Voltage Control	70
LOAD FAIL-SAFE DEFAULTS	71
LOAD OPTIMIZED DEFAULTS	71
SET SUPERVISOR/USER PASSWORD	71
SAVE & EXIT SETUP	72
EXIT WITHOUT SAVING	72

WHAT'S IN THE MANUAL

Quick Reference

Hardware Installation >> Step-by-Step	Page 11
Jumper Settings >> A Closer Look	Page 24
Software Utility >> How to Install	Page 45
BIOS Setup >> How to Configure	Page 51

About This Manual

For First-Time DIY System Builder	Page 5
For Experienced DIY User	Page 5
For System Integrator	Page 5

1 INTRODUCTION

1.1 To Different Users

First-Time DIY System Builder

Welcome to the DIY world! Building your own computer system is not as difficult as you may think. To make your first computer DIY experience successful, right from the start, we have designed Chapter 3 Hardware Installation in a step-by-step fashion for all the first-time DIY system builders. Prior to installation, we suggest you read the whole manual to gain a complete understanding of your new AN50R mainboard.

Experienced DIY User

Congratulate on your purchase of the AN50R mainboard. You will find installing your new AN50R mainboard is quite easy. Bundled with an array of onboard functions, the highly-integrated AN50R mainboard provides you with a total solution to build the stablest and most reliable system. Referring to section 3.2 Jumper Settings and Chapter 4 Software Utility, you will find how to work out your new mainboard. Chapter 5 BIOS Setup also contains the relevant information on how to tune up your system to achieve higher performance.


System Integrator

You have wisely chosen AN50R to construct your system. AN50R incorporates all the state-of-the-art technology of the nVIDIA nForce3 150 chipset from NVIDIA. incorporates all the state-of-the-art technology of the nForce3 150 chipset from NVIDIA. Each integrates the most advanced functions you've ever found in a compact ATX board.


1.2 Item Checklist:

Check all items with your AN50R mainboard to make sure nothing is missing. A complete package should include:


- ★ One Shuttle AN50R Mainboard




- ★ One ATA 133/100/66 Ribbon Cable




- ★ One Floppy Ribbon Cable



- ★ One piece of twin ports 1394 Cable



- ★ One Twin-Port USB Cable




- ★ Two pieces of Serial ATA Cable



- ★ Two pieces of Serial ATA Power Cord




✱ I/O Shielding



✱ AN50R User's Manual



- ✱ One Bundled CD-ROM, including:
- AN50R user's manual in PDF format
 - NVIDIA Chipset Driver
 - Intel Giga Lan Driver
 - Silicon Image SATA Raid Driver
 - Silicon Image SATA Raid Utility
 - USB 2.0 Driver (for WinXP/2K only)
 - Award Flashing Utility



2 FEATURES

AN50R mainboard is dedicatedly designed for demanding PC users who desire high performance and maximum intelligent features in a compact package.

2.1 Specifications

★ CPU Support

AMD Athlon™ 64, 754-pin processors with 200 MHz FSB.

★ Chipset

Features NVIDIA nForce3 150 Chipset .

Onboard 1394

VIA VT6306, support 400Mbps, 200Mb/s or 100Mb/s data transfer rate.

Onboard Gigabit Ethernet controller

82540EM, support 10/100/1000 Mbps operation rate and Wake-on-Lan(WOL) function.

★ Jumperless CPU Configuration

Soft-configuration FSB (The FSB speed is software configurable from 200MHz to 250MHz).

★ SATA RAID Controller (Sil3112A)

Support 2 Serial-ATA connector with Raid0/ Raid1 function.

SATA Host controller support Generation 1 up to 1.5 Gb/s (150MB/s)

★ AC'97 Audio

Realtek ALC650 Supports 18-bit ADC and DAC resolutions, and 6 channel selectable DAC output for multi-channel applications.

Compliant with AC'97 2.2 specifications.

★ Versatile Memory Support

Three 184-pin DDR SDRAM DIMM slots maximumly accommodate 3GB of PC1600/2100/2700/3200 DDR for AN50R.

★ PCI Expansion Slots

Provide five 32-bit PCI slots. Support Sil3112A SATA Raid/ 82540EM Gigabit Lan (GbE)/ VT6306 3 ports IEEE 1394 firewire on board.

★ AGP Expansion Slot

Provides one AGP3.0 compliant slot that supports up to 8X AGP device.

★ 6 USB 2.0 Interface Onboard

- 4 x USB ports on back panel and one extended USB headers (2 ports) on front panel.

★ I/O Interface

Provides a variety of I/O interfaces:

- 1 x PS/2 Mouse
- 1 x PS/2 Keyboard
- 1 x Serial port
- 1 x Parallel port
- 1 x SPDIF-Out port
- 1 x 1394 port
- 1 x 10/100 Lan port
- 1 x Gigabit Lan port
- 1 x Front-Out port
- 1 x Rear-Out (shared with Line-In) port
- 1 x Center/Bass (shared with Mic-In) port
- 4 x USB ports

★ PCI Bus Master IDE Controller Onboard

Two Ultra DMA 133 bus master dual-channel IDE ports support up to four IDE devices (one Master and one Slave per channel).

The IDE bus implements data transfer speeds to 133/100/66MB/sec and supports enhanced PIO modes.

80-pin cable backward compatible legacy ATAPI devices, ATAPI IDE CD-ROM, CD-R, CD-RW, and LS-120 supports.

★ ATX Power Supply Connector

ATX power supply unit can be connected to the onboard 20-pin ATX power connector, and 4-pin ATX power connector. The unit supports Suspend and Soft-On/Off modes by the dual-function power button.

★ **Advanced Configuration and Power Interface**

Features four power-saving modes: S1 (Snoop), S3 (Suspend to RAM), S4 (Suspend to DISK), and S5 (Soft-Off). ACPI provides more efficient energy-saving features controlled by your operating system that supports OS Direct Power Management (OSPM) functionality.

★ **System BIOS**

Provides licensed Award BIOS V6.0 PG on the 4Mb Flash ROM, and supports Green PC, Desktop Management Interface (DMI).

★ **Form Factor**

System board conforms to the ATX specification.

Board dimension: 305mm x 244mm.

★ **Advanced Features**

- Low EMI - Built in spread spectrum. Unused PCI/SDRAM slots are shut off by the automatic clock for reducing EMI.
- Dual Function Power Button - The system can be in any of the two states: one is Suspend mode and the other is Soft-Off mode. Pushing the power button for less than 4 seconds places the system into Suspend mode. When the power button is pressed for longer than 4 seconds, the system will enter Soft-Off mode.
- Modem Ring Power-On - The system can be powered on automatically by the activation of modem ringing.
- CPU Multiplier Setting - This item allows users to adjust CPU Multiplier in BIOS.
- CPU/RAM/AGP Voltage Setting - These items allow users to adjust CPU/RAM/AGP Voltage in BIOS.

★ **Intelligent Features**

- Voltage Monitoring - Monitors various voltages of key elements, such as the CPU, and other critical system voltage levels to ensure a stable current passing through mainboard components.
- Fan Status Monitoring - To prevent the CPU from overheating, the CPU fan is monitored by RPM, with which the cooling fan is required.
- Temperature Monitoring - This item allows users to make sure whether the CPU or system runs under a suitable temperature.


3 HARDWARE INSTALLATION

Before removing/installing any of these devices: CPU, DIMMs, Add-On Cards, and Cables, please unplug the onboard power connector.

This section outlines how to install and configure your mainboard. Referring to the following mainboard layout helps you identify various jumpers, connectors, slots, and ports.

3.1 Step-by-Step Installation


Accessories Of AN50R



Step 1

Install the CPU:

1. Locate the CPU ZIF (Zero Insertion Force) socket on the upper-right sector of your mainboard (between the back panel connectors and the DIMM memory slots).
2. Pull the CPU ZIF socket lever slightly sideways away from the socket to unlock the lever, and then bring it to an upwardly vertical position.
3. Place your AMD Athlon™ 64 processor in the socket. Note that the CPU's edges have been purposely designed non-symmetrically to prevent from inserting the processor in the wrong direction. The following diagram demonstrates the correct placement of the CPU in the ZIF socket.



4. Slightly push the AMD Athlon™ 64 processor into the socket without applying excessive force while making sure there is no gap between CPU and socket. Then lower the socket-lever all the way down to its horizontal position and lock it to secure the CPU in place.
5. The AMD Athlon™ 64 processor requires a set of heatsink/fan to ensure proper cooling of the processor. If heatsink/fan have not been already mounted on your CPU, you must purchase the heatsink/fan separately and have it installed. Plug the cable through the heatsink/fan in the CPU fan power connector located nearby. Note that there are several types of CPU fan connectors. Normally, if your mainboard supports the hardware monitoring function, a 3-pin fan power connector should allow your system to detect the CPU fan's speed. The CPU fan can also run with a 2-pin fan power connector, however, detection of CPU fan's speed is not supported. Another type of CPU fan may feature a large 4-pin fan power connector, which does not support CPU fan's speed detection and must be directly connected to the system's power supply unit. Please refer to the following diagram.

Step 2.

Set Jumpers

The default jumper settings have been set for the common usage standard of this mainboard. Therefore, you need not to reset the jumpers unless you require special adjustments as the following case:

Clear CMOS Setting


For first-time DIY system builders, we recommend that you not change the default jumper settings if you are not quite familiar with the mainboard configuration procedures. The factory-set default settings are tuned for optimum system performance. For advanced users who prefer to customize their system, section 3.2 Jumper Settings provides the detailed information on how to configure your mainboard manually.

Step 3

Install DDR SDRAM System Memory

To install memory, insert DDR SDRAM memory module(s) in the DIMM banks. Note that DDR SDRAM modules are directional and will not go in the DIMM banks if they are not properly oriented. After the module is fully inserted into the DIMM bank, lift the clips of both sides of the DIMM bank to lock the module in place.

DDR SDRAM



Step 4

Install Internal Peripherals in System Case

Before you place the mainboard into your system case, we recommend that you first assemble all the internal peripheral devices into the computer housing, including, but not limited to, the hard disk drive (IDE/HDD), floppy disk drive (FDD), CD-ROM drive, and ATX power supply unit.


To install IDE & FDD drives, follow these procedures:

1. Set the required jumpers on each device according to the instructions provided by the manufacturer. (IDE, HDD, and CD-ROM have to set jumpers to Master or Slave mode depending on whether you install more than one device of each kind.)
2. Connect the IDE cable and FDD cable on the back panel of the internal peripheral devices to the corresponding headers on board. Note that the cable should be oriented with its colored stripe (usually red or magenta) connected to pin#1 of the IDE or FDD connector on the mainboard and on the device as well.
3. Connect an available power cable from your system power supply unit to the back panel of each peripheral device. Note that the power cable is directional and cannot fit in if not properly positioned.

Step 5

Mount the Mainboard on the Computer Chassis

1. You may find there are a lot of mounting holes on your computer chassis and mainboard. To match the holes on both properly, the key point is to make the back panel of the mainboard in a close fit with your system case, as shown below.




2. Position the studs between the chassis and the mainboard. The studs are used to fix the mainboard and to keep a certain distance between them, for avoiding any electrical shorts in-between.
(If your computer case is already equipped with mounting studs, you need to tighten the screws to attach the mainboard.)

Note: In most computer housings, you can find 4 or more holes to place studs for fixing the mainboard. If there aren't enough matching holes, screw at least 4 studs to ensure the proper attachment of the mainboard.


Step 6

Connect Front Panel LEDs/Switches/Speaker/USBs

You can find there are several cables existing in the system case and originating from the front panel devices (HDD LED, Green LED, Reset switch, PC Speaker, and USB devices etc.). These cables serve to connect the front-panel LEDs, switches, speaker, and USB connectors to the mainboard's front-panel connectors group, as shown below.



1. Green LED (GLED)
2. HDD LED (HLED)
3. ATX Soft Power On/Off (PWON)
4. Hardware Reset Switch (RST)
5. Power LED (PLED)
6. Hardware System Management Interface (EPMI)
7. PC Speaker (SPEAKER)
8. Extended USB Headers (JP7-USB 5&6)




- | | |
|------------|------------|
| 1 = VCC | 2 = VCC |
| 3 = DATA0- | 4 = DATA1- |
| 5 = DATA0+ | 6 = DATA1+ |
| 7 = GROUND | 8 = GROUND |
| 9 = KEY | 10 = N/C |


Step 7

Connect IDE and Floppy Disk Drives


1. IDE cable connectors



2. Floppy cable connector




3. Serial ATA Connectors (ATA1/ATA2)




Step 8

Connect Other Internal Peripherals


1. IR header (JP8)




2. Audio CD_IN connectors (CN4/CN5);
Audio AUX_IN connector (CN6)




3. SPDIF IN header (JP10)




4. 1394 header (JP15/JP16)



5. Wake On LAN Connector (WOL1)



6. Front Panel Audio Header (JP11)




7. Center/Bass & Rear-Out Header (JP9/JP20)

Step 9

Connect the Power Supplies


1. System power connectors (ATX1/CN8)




Step 10

Install Add-On Cards in Expansion Slots

1. Accelerated Graphics Port (AGP) Card




2. PCI Card




Step 11

Connect External Peripherals to Back Panel

You are now ready to connect the external peripherals to your system's back panel.



1. PS/2 Mouse Port
2. PS/2 Keyboard Port
3. LPT1 Port
4. COM1 Port
5. SPDIF-Out
6. 1394 Port
7. 10/100 Lan Port
8. Gigabit Lan Port
9. USB1.1/2.0 Port
10. 5.1-Channel Center/Bass (shared with Min-in) Port
11. 5.1-Channel Rear-Out (shared with Line-In) Port
12. 5.1-Channel Front-Out Port



Step 12

System Boot Up For the First-Time

To ensure your system completely and correctly installed, please refer to the above installation steps once again before first booting up your system.

1. Insert a system-bootable floppy disk (DOS 6.2X, Windows 9X/NT, or others), which contains the FDISK and FORMAT utilities.
2. Turn on the system power.
3. First, you need to use the FDISK utility to create a primary partition of the hard disk. You can also add an extended partition if your primary partition does not use all of the available hard disk space. If you choose to add an extended partition, you will have to create one or more logical partitions to occupy all the space available to the extended partition. The FDISK utility will assign a drive letter (i.e. C:, D:, E:,.....) to each partition shown in the FDISK program. After the FDISK procedure, reboot your system by using the same disk.

Note: DOS 6.2X and Windows 95A can only support up to 2.1GB of HDD partition. If you use the FDISK utility with one of the operating systems mentioned above, you can only install your HDD into any partitions no larger than 2.1GB.

4. Now, use the FORMAT utility to format all the partitions you've created. When formatting the primary partition (C:), key in the command, "FORMAT C:/S."

Note: FORMAT C:/S can transfer all the necessary system files into the primary partition of your hard disk. Afterwards, your HDD will become a bootable drive.

5. Install all the necessary drivers for CD-ROM, Mouse, etc.
6. Setup the complete operating system according to your OS installation guide.

Step 13

Install Drivers & Software Components

Please note that all the system utilities and drivers are designed for Win 9x/2000/ME/NT/XP operating systems. Make sure your operating system is already installed before running the installation programs on CD-ROM.

1. Insert the AN50R bundled CD-ROM into your CD-ROM drive. The auto-run program will display the main installation window on screen.
2. Choose "Install Mainboard Software Driver."
3. Choose "Install nVIDIA Chipset driver" and complete it.
4. Choose "Install Intel GigaLAN driver" and complete it.
5. Choose "Install Silicon RAID driver" and complete it.
6. Choose "Install SilCfg Utility" and complete it.
7. Choose "Install nVIDIA USB 2.0 Driver" and complete it. (for WinXP/2K only)
8. Exit from the autorun drivers installation program.

3.2 Jumper Settings

Several hardware settings are made through the use of mini jumpers to connect jumper pins on the mainboard. Pin #1 could be located at any corner of jumpers, and the corner with a white right angle stands for Pin #1. There are several types of Pin #1 as shown below:

3-pin and multi-pin (> 3) jumpers shown as follows:

Pin #1 to the left:



Pin #1 on the top:





Pin #1 to the right:



Pin #1 on the bottom:




Jumpers with two pins capped are shown as  for Close [On] or  for Open [Off]. To do this, please place a plastic mini cap on the desired pair of pins.

Caution!

1. Do not remove the mainboard from its antistatic protective packaging until you are ready to install it.
2. Carefully hold the mainboard by its edges and avoid touching its components. When putting the mainboard down, place it on top of its original packaging film, with the component side up.
3. Wear an antistatic wrist strap or take other suitable measures to prevent electrostatic discharge (ESD) as handling this equipment.

Jumpers & Connectors Guide

Refer to the mainboard layout on page 11 and this section to help you identify jumpers, slots, and connectors along with their assigned functions.



CPU/Memory/Expansion Slots

Socket 754 : CPU socket for AMD Athlon™ 64, 754-pins processors

DIMM1/2/3 : Three DIMM slots for 128, 256, 512 MB, and 1GB of 2.5V/2.6V DDR SDRAM

(The total installed memory does not exceed 3GB.)

AGP : One AGP slot supports up to 8X AGP device.

PCI : Five 32-bit PCI expansion slots

Jumpers

- Ⓐ1 JP18 : Clear CMOS setting

Back Panel Connectors

- Ⓑ1 MS : PS/2 mouse port
Ⓑ1 KB : PS/2 keyboard port
Ⓑ2 LPT 1 : Parallel port
Ⓑ3 COM1 : Serial ports1
Ⓑ4 SPDIF-Out : SPDIF-Out port
Ⓑ5 1394 : 1394 Port
Ⓑ6 10/100 Lan Port : 10/100 Lan Port
Ⓑ7 USB : USB ports 1/2/3/4
Ⓑ8 Gigabit Lan Port : Gigabit Lan Port
Ⓑ9 LINE-OUT : Line-Out port
Ⓑ10 LINE-IN : Line-In (shared with Rear-Out) port
Ⓑ11 MIC-IN : Mic-In (shared with Center/Bass-Out) port

Front Panel Connectors

- Ⓒ1 HLED : HDD LED
Ⓒ2 GLED : Green LED
Ⓒ3 Reset : Hardware reset switch
Ⓒ4 PWON : ATX power on/off switch
Ⓒ5 EPMI : EPMI connector
Ⓒ6 PLED : Power LED
Ⓒ7 Speaker : Speaker connector

Internal-Peripheral Connectors

- Ⓓ1 IDE1 : IDE primary interface (dual-channel)
Ⓓ1 IDE2 : IDE secondary interface (dual-channel)
Ⓓ1 FLP1 : Floppy disk drive interface
Ⓓ2 Serial ATA1/2 : Serial ATA1/2 interface

Other Connectors

E1	ATX1/CN8	: ATX power supply connectors
E2	FAN1	: CPU fan connector
E2	FAN2	: System fan connector
E2	FAN3	: System fan connector
E3	JP8	: IR header
E4	CN4/CN5	: Audio CD_IN connectors
E5	CN6	: Audio AUX_IN connector
E6	JP9/JP20	: Center/Bass & Rear-Out header
E7	JP11	: Front-Panel Audio header
E8	JP10	: SPDIF IN header
E9	JP7	: Dual USB header
E10	JP15/JP16	: 1394 header
E11	WOL1	: Wake-On-LAN connector
E12	SW1	: PWRON BUTTON
E13	SW2	: RESET BUTTON





Jumpers

A1 Clear CMOS Setting (JP18)

JP18 is used to clear CMOS data. Clearing CMOS will result in permanently erasing previous system configuration settings and the original factory-set system settings.

1  Pin 1-2 (Default)

1  Pin 2-3 (Clear CMOS)



- Step 1. Turn off the system power (PC--> Off).

Step 2. Remove the ATX power cable from the ATX power connector.

Step 3. Remove the jumper cap from pins 1-2.

Step 4. Place the jumper cap on pins 2-3 for a few seconds.

Step 5. Restore the jumper cap to pins 1-2.


Step 6. Plug the ATX power cable into the ATX power connector.

Step 7. Turn on the system power (PC--> On).

Back Panel Connectors


B1 PS/2 Mouse & PS/2 Keyboard Port Connectors

Two 6-pin female PS/2 Mouse & Keyboard connectors are located on the rear panel of the mainboard. In a desktop computer, the PS/2 Mouse connector is situated on the top of the PS/2 Keyboard connector. In a tower computer, the PS/2 Mouse connector is located on the rightside of the PS/2 Keyboard connector.




B2 Parallel Port Connector

One DB25 female parallel connector is located on the rear panel of the mainboard. Plug the cable from your parallel device (printer, scanner, etc.) into this connector.




B3 COM1 Port Connector

Attach serial device cables to the DB9 serial ports COM1 at the back panel of your computer.




B4 SPDIF-Out Connector

SPDIF-Out connector can convey digital audio data from optic filber.



B5 IEEE 1394 Port Connector


This mainboard offers one 1394 port on back-panel. Plug device jack into an available 1394 connector.



B6 10/100 base-T LAN Port Connector


This mainboard can accommodate one device on LAN.

Attach a CAT-5 cable to the LAN port at the back-panel of your computer.



B7 USB Port Connectors


This mainboard offers 4 USB ports on back panel. Plug each USB device jack into an available USB1 ~ USB4 connector.



B8 Gigabit LAN Port Connector


This mainboard can accommodate one device on Gigabit LAN.

Attach a CAT-5 or CAT-6 cable to the LAN port at the back-panel of your computer.




B9 Line-Out Port Connector

Line-Out is a stereo output port through which the combined signal of all internal and external audio sources on the board is output. It can be connected to 1/8-inch TRS stereo headphones or to amplified speakers.




B10 Line-In (Rear-Out) Port Connector

Line-In is a stereo line-level input port that accepts a 1/8-inch TRS stereo plug. It can be used as a source for digital sound recording, and a source to be mixed with the output, or both.



B11 Mic-In (Center/Bass-Out) Port Connector


Mic-In is a 1/8-inch jack that provides a mono input. It can use a dynamic mono or stereo microphone with a resistance of not more than 600 Ohms.



Front Panel Connectors


HDD LED Connector (HLED)

Attach a connector cable from the IDE device LED to the 2-pin (HLED) header. The HDD LED lights up whenever an IDE device is active.




Green LED Connector (GLED)

The Green LED (GLED) indicates that the system is currently in one of the power saving modes (Doze/Standby/Suspend). When the system resumes to the normal operation mode, the Green LED will go off. Attach a 2-pin Green LED cable to the (GLED) header.




③ Hardware Reset Connector (RST)

Attach a cable to the 2-pin (RST) header. Pressing the reset switch causes the system to restart.



④ ATX Power On/Off Switch Connector (PWON)


The Power On/Off Switch is a momentary type switch used for turning on or off the ATX power supply. Attach a connector cable to the 2-pin (PWON) header on the mainboard.



Note : Please notice all the LED connectors are directional. If your chassis's LED does not light up during running, please change it to the opposite direction.


⑥ EPMI Connector (EPMI)

A Hardware System Management Interface (EPMI) header may be attached to a 2-pin momentary switch. Press the switch to force the system into a power saving mode; press it again to resume it to a normal operation situation.




⑥ Power LED Connector (PLED)

Attach a 3-pin Power LED connector cable to the (PLED) header. The power LED stays light while the system is on.



⑦ Speaker Connector (Speaker)

Attach a PC speaker cable to the 4-pin speaker connector (Speaker).



Internal Peripherals Connectors


D1 Enhanced IDE, Floppy Connectors

The mainboard features two 40-pin dual-channel IDE device connectors (IDE1/IDE2) providing support for up to four IDE devices, such as CD-ROM and Hard Disk Drives (H.D.D.).

This mainboard also includes one 34-pin floppy disk controller (FDC) to accommodate the Floppy Disk Drive (FDD). Moreover, this mainboard comes with one 80-pin ATA 100/66/33 ribbon cable to connect to IDE H.D.D. and one 34-pin ribbon cable for F.D.D. connection.

Important:


Ribbon cables are directional, therefore, make sure to always connect with the red cable stripe on the same side as pin #1 of the IDE1/IDE2 or FDC connector on the mainboard.



D2 Serial ATA Connectors

The Serial ATA is an evolutionary replacement for the Parallel ATA physical storage interface. Serial ATA is scalable and will allow future enhancements to the computing platform. The Serial ATA supports all ATA and ATAPI device, including CDs, DVDs, tapes devices, high capacity removeable devices, zip drivers, and CDRW's.


The Serial ATA interface supports data transfer rates up to 150MB/s.



Other Connectors

ATX Power Supply Connectors (ATX1/CN8)

This motherboard uses 20-pin ATX power header (ATXPWR, ATX1), and comes with the other one header (ATX12V, CN8). Please make sure you plug each in the right direction. It is essential to have these two power supply connectors plugged or your system won't boot up.





A traditional ATX system remains in the power-off stage when AC power resumes from power failure. However, it is inconvenient for a network server or workstation if there is not an UPS to execute power-on. Thus, this motherboard supports an AC Power Auto Recovery function to solve this problem. You may enable the function, "PWRON After PWR-Fail," in the sub-menu of "Power Management Setup" within the BIOS setup program.

- | | |
|---------|---|
| Note 1: | The ATX power connector is directional and will not go in unless the guides match perfectly, making sure that pin#1 is properly positioned. |
| Note 2: | Make sure the latch of the ATX power connector clicks into place to ensure a solid attachment. |
| Note 3: | Your ATX power supply must be supplied to ACPI + 5V stand-by power and at least 720mA compatible. |
| Note 4: | Make sure your power supply have enough power for higher speed processor installed. |

CPU and System Fan Connectors (FAN1/2/3)


The mainboard provides three onboard 12V cooling fan power connectors to support the CPU (FAN1) and the system (FAN2/FAN3).

Note: Both cable wiring and type of plug may vary, which depend on the fan maker. Keep in mind that the red wire should always be connected to the +12V header and the black wire to the ground (GND) header.




IR Header (JP8)

If you have an Infrared device, this mainboard can implement IR transfer function. This mainboard supports Normal, IrDA, ASKIR, or SCR transfer mode. To enable this function, attach a 6-pin infrared device cable to the IR (JP8) header. Please note that every pin is properly allocated. If not, your IR device may be damaged.



Pin Assignments:


1 = NC	2 = KEY
3 = VCC	4 = GND
5 = IRTX	6 = IRRX



E4 Audio CD_IN Connectors (CN4/CN5)

Ports CN4 (Black)/CN5 (White) can be used to connect stereo audio inputs from CD-ROM, TV-tuner or MPEG card.


CN 4



Pin Assignments:


- 1 = CD In-Left
- 2 = Ground
- 3 = Ground
- 4 = CD IN-Right

CN 5



Pin Assignments:


- 1 = Ground
- 2 = CD-IN-Right
- 3 = Ground
- 4 = CD In-Left



E5 Audio AUX_IN Connector (CN6)


Port CN6 (White) can be used to connect a stereo audio input from CD-ROM, TV-tuner or MPEG card.

CN 6





Pin Assignments:

- 1 = AUX-IN-Left
- 2 = Ground
- 3 = Ground
- 4 = AUX-IN-Right




Ⓔ Center/Bass & Rear_Out Header (JP9/JP20)

Port JP9/JP20 can be used to connect a cable attached to Center/Bass & Rear-Out amplified speakers.




Ⓕ Front Panel Audio Header (JP11)

This header allows users to install an auxiliary Front-Oriented Audio port for easier access. Either the Line-Out port connector on back panel or the front panel Audio header is available at the same time. If you would like to use this header on front panel, please remove all jumpers from it and install your special extra audio cable instead. Two mini jumpers must be setted on pins 5-6 and pins 9-10 when this header is not used.




Pin Assignments:

1 = AUD_MIC	2 = AUD_GND
3 = AUD_MIC_VCC	4 = RESERVE
5 = AUD_FRONT_R	6 = AUD_RET_R
7 = HP_ON	8 = KEY
9 = AUD_FRONT_L	10 = AUD_RET_L




E8 SPDIF IN Header (JP10)

Port JP10 can be used to connect to a device with digital audio inputs.




Pin Assignments:

- 1 = + 12V
- 2 = VCC
- 3 = RESERVE
- 4 = RESERVE
- 5 = SPDIF_IN
- 6 = GND
- 7 = RESERVE
- 8 = RESERVE
- 9 = KEY
- 10 = GND




E9 Extended USB Headers (JP7)

Headers JP7 (USB 5&6) are used to connect cables to USB connectors mounted on front panel or back panel. The USB cable is optional at the time of purchase.



Pin Assignments:


- | | |
|-------------|-------------|
| 1 = VCC | 2 = VCC |
| 3 = Data0- | 4 = Data1- |
| 5 = Data0 + | 6 = Data1 + |
| 7 = Ground | 8 = Ground |
| 9 = KEY | 10 = N/C |



E10 IEEE1394 Connector (JP15,JP16)



The header are used to connect the cable attached to 1394 connector which are mounted on front panel or back panel. But the 1394 cable is optional at the time of purchase.

JP 15/JP 16




Pins Assignment:

1 = TPA +	2 = TPA-
3 = GND	4 = GND
5 = TPB +	6 = TPB-
7 = + 12V(fused)	8 = + 12V(fused)
9 = KEY	10 = GND




E11 Wake-On-LAN Connector (WOL1)

Attach a 3pin connector through the LAN card which supports the Wake-On-LAN(WOL) function. This function lets users wake up the connected system through the LAN card.




Pin Assignments:


- 1 = 5VSB
- 2 = GND
- 3 = WOL



E12 Power Button (SW1)



E13 Reset Button (SW2)



3.3 System Memory Configuration

The AN50R mainboard has three 184-pin DIMM slots that allow you to install from 128MB up to 3GB of system memory. Each 184-pin DIMM (Dual In-line Memory Module) slot can accommodate 128MB, 256MB, 512MB, and 1GB compliant 2.5V/2.6V single or double side 64-bit wide data path with or without ECC DDR SDRAM modules. You do not need to set any jumper to configure memory since the BIOS utility can detect the system memory automatically. You can check the total system memory value in the BIOS Standard CMOS Setup menu.

Note: The total installed memory does not exceed 3GB.

1. Install Memory:

Install memory in any or all of the banks. The combination shown as follows.

Total 3 DIMM up to 3GB max and 1GB per DIMM								
Density	64Mbit		128Mbit		256Mbit		512Mbit	
Device Width	x8	x16	x8	x16	x8	x16	x8	x16
Single Side	64MB	64MB	128MB	128MB	256MB	256MB	512MB	512MB
Double Side	128MB	128MB	256MB	256MB	512MB	512MB	1024MB	NA

Note: 1.X4 DDR-SDRAM chips are not supported.
2.Registered DIMM are not supported.
3.ECC DDR-SDRAM are supported.

Memory Support Mode					
DIMM MODE	DIMM 1 (A Group)		DIMM2 / DIMM3 (B Group)		
	x8 SS or x16	x8 DS	x8 SS or X16	x8 DS	Mixed x8 DS and x8 SS or x16
DDR200	One	One	Two	One	One Only
DDR266	One	One	Two	One	One Only
DDR333	One	One	Two	One	One Only
DDR400	One	One	One	One	One Only

SS = Single Side DIMM module.

DS = Double Side DIMM module.

Note: You do not need to set any jumper to configure memory since the BIOS utility can detect the system memory automatically. You can check the total system memory value in the BIOS Standard CMOS Setup menu.

2. Upgrade Memory:

You can easily upgrade the system memory by inserting additional DDR SDRAM modules in available DIMM banks. The total system memory is calculated by simply adding up the memory in all DIMM banks. After upgrade, the new system memory value will automatically be computed and displayed in the field "Standard CMOS Setup" of BIOS setup program.

4 SOFTWARE UTILITY

4.1 Mainboard CD Overview

Note: The CD contents attached in AN50R mainboard are subject to change without notice.

To start your mainboard CD disc, just insert it into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click or run D:\Autorun.exe (assuming that your CD-ROM drive is drive D:).

Navigation Bar Description:

- ☞ Install Mainboard AN50R Series Driver - Installing NVIDIA Chipset driver, Intel LAN driver, Silicon RAID driver, Silicon SiLCfg and nVIDIA USB 2.0 driver (for WinXP/2K only).
- ☞ Install Utility - Installing Acrobat Reader and Winflash Utility.
- ☞ Manual - AN50R series user's manuals in PDF format.
- ☞ Link to Shuttle Homepage - Link to shuttle website homepage.
- ☞ Browse this CD - Allows you to see contents of this CD.
- ☞ Quit - Close this CD.



4.2 Install Mainboard Software

Insert the attached CD into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on Autorun icon in My Computer to bring up Shuttle Mainboard Software Setup screen.

Select using your pointing device (e.g. mouse) on the "Install Mainboard Software" bar to run into sub-menu.

The Mainboard AN50R Software include:

- [4.2.A] Install nVIDIA Chipset Driver
- [4.2.B] Install Intel LAN Driver
- [4.2.C] Install Silicon RAID Driver
- [4.2.D] Install Silicon SiCfgr
- [4.2.E] Install nVIDIA USB 2.0 Driver



4.2.A Install nVIDIA Chipset System Driver

Select using your pointing device (e.g. mouse) on the "Install nVIDIA Chipset Driver" bar to install chipset system driver.



Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.B Install Intel LAN Driver

Select using your pointing device (e.g. mouse) on the "Install Intel LAN Driver" bar to install LAN driver.



Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.C Install Silicon RAID Driver

Select using your pointing device (e.g. mouse) on the "Install Silicon RAID Driver" bar to install raid driver.



Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.D Install SilCfG Utility

Select using your pointing device (e.g. mouse) on the "Install SilCfG Utility" bar to installation Silicfg Utility .



Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

Under Windows 98/ME, if the system doesn't have Serial-ATA haddisk, please don't install this RAID Utility.

4.2.E Install nVIDIA USB2.0 Driver

Select using your pointing device (e.g. mouse) on the "Install nVIDIA USB2.0 Driver" bar to install USB2.0 driver.




Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.3 View the User's Manual

Insert the attached CD into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on AutoRun icon in My Computer to bring up Shuttle Mainboard Software Setup screen.

Select using your pointing device (e.g. mouse) on the "Manual" bar.



Then Online Information windows will appear on your screen. Click on the "Install Acrobat Reader" bar if you need to install acrobe reader.



Then click on "Manual" bar to view user's manual.

5 BIOS SETUP

AN50R BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in battery-backed RAM so that it retains the Setup information even if the system power is turned off.

The system BIOS is managing and executing a variety of hardware related functions in the system, including:

- System date and time
- Hardware execution sequence
- Power management functions
- Allocation of system resources

5.1 Enter BIOS

To enter the BIOS (Basic Input /Output System) utility, follow these steps:

- Step 1. Power on the computer, and the system will perform its POST (Power-On Self Test) routine checks.
- Step 2. Press key immediately, or at the following message: Press DEL to enter SETUP, or simultaneously press <Ctrl>, <Alt>, <Esc> keys.

Note1. If you miss trains of words mentioned in step2 (the message disappears before you can respond) and you still wish to enter BIOS Setup, restart the system and try again by turning the computer OFF and ON again or by pressing the <RESET> switch located at the computer front panel. You may also reboot by simultaneously pressing the <Ctrl>, <Alt>, keys.


Note2. If you do not press the keys in time and system does not boot, the screen will prompt an error message, and you will be given the following options:

"Press F1 to Continue, DEL to Enter Setup"

- Step 3. As you enter the BIOS program, CMOS Setup Utility will prompt you the Main Menu, as shown in the next section.

5.2 The Main Menu

Once you enter the Award BIOS(tm) CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.



Note that a brief description of each highlighted selection appears at the bottom of the screen.

Setup Items

The main menu includes the following main setup categories. Recall that some systems may not include all entries.

Standard CMOS Features

This menu displays the basic information about your system.

Advanced BIOS Features

Use this menu to set the advanced features available on your system.

Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance.

Integrated Peripherals

Use this menu to specify your settings for integrated peripherals.

Power Management Setup

Use this menu to specify your settings for power management.

PnP/PCI Configurations

This option configures how PnP (Plug and Play) and PCI expansion cards operate in your system.

PC Health Status

This entry shows the current system temperature, voltage, and fan speed.

CPU Ratio/Voltage Control

Use this menu to specify your settings for the ratio/voltage control.

Load Fail-Safe Defaults

Use this menu to install fail-safe defaults for all appropriate items in the setup utility.

Load Optimized Defaults

Use this menu to install optimized defaults for all appropriate items in the setup utility.

Set Supervisor/User Password

Use this menu to change, set, or disable supervisor/user password. It allows you to limit access to the system and Setup, or only to Setup.

Save & Exit Setup

Save the changes that you have made in the Setup Utility and exit the Setup Utility.

Exit Without Saving

Abandon all changes that you have made in the Setup Utility and exit the Setup Utility.



Standard CMOS Features

Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

Phoenix - AwardBIOS CMOS Setup Utility		
Standard CMOS Features		
Date <mm:dd:yy>	Fri, Jul 25 2003	Item Help Menu Level ▶ Change the day, month, year and century
Time <hh:mm:ss>	6 : 3 : 7	
▶ IDE Primary Master	[None]	
▶ IDE Primary Slave		
▶ IDE Secondary Master		
▶ IDE Secondary Slave	[None]	
Drive A	[1.44M, 3.5 in.]	
Drive B	[None]	
Video	[EGA/VGA]	
Halt On	[All , But Keyboard]	
Base Memory	640K	
Extended Memory	64512K	
Total Memory	65536K	
↑↓←→:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Date (mm : dd : yy)

Set the system date. Note that if you are running a Windows OS, this items are automatically updated whenever you make changes to the Windows Date.

Time (hh : mm : ss)

Set the system time. The time is converted based on the 24-hour military-time clock. For example, 5:00:00 p.m. is 17:00:00.

IDE Primary/Secondary Master/Slave

Press <Enter> to enter the sub-menu of detailed options.

Drive A/DriveB

Select the type of floppy disk drive installed in your system.

- The choice: None, 360K, 5.25 in, 1.2M, 5.25 in, 720K, 3.5 in, 1.44M, 3.5 in, or 2.88M, 3.5 in.

Video

This item defines the video mode of the system. Leave this item at the default value.

- The choice: EGA/VGA, CGA 40, CGA 80, or MONO.

Halt On

This item defines the operation of the system POST (Power-On Self Test) routine. You can use this item to select which situation you want the BIOS to stop the POST process and notify you.

- The choice: All Errors, No Errors, All, But Keyboard, All, But Diskette, or All, But Disk/Key.

Base Memory/Extended Memory/Total Memory

These items are automatically detected by the system at start up time.
These are display-only fields. You can't make change to these fields.

IDE Adapters

The IDE adapters control the hard disk drive. Use a separate sub-menu to configure each hard disk drive.

IDE HDD Auto-Detection

Press <Enter> to auto-detect HDD on this channel. If detection is successful, it fills the remaining fields on this menu.

IDE Primary Master

Selecting 'Manual' lets you set the remaining fields on this screen and select the type of fixed disk.

- The choice: None, Auto, or Manual.

Access Mode

Choose the access mode for this hard disk.

- The choice: CHS, LBA, Large, or Auto.

Capacity

Note that the disk drive capacity (approx.) is usually slightly greater than the size of a formatted disk given by a disk checking program.

The following options are selectable only if the 'IDE Primary Master' item is set to 'Manual', and the 'Access Mode' item is set to 'CHS'.

Cylinder

Set the number of cylinders for this hard disk.

- Min = 0, Max = 65535

Head

Set the number of read/write heads.

- Min = 0, Max = 255

Precomp

Warning: Setting a value of 65535 means no hard disk.

- Min = 0, Max = 65535

Landing Zone

Set the Landing Zone size.

- Min = 0, Max = 65535

Sector


Number of sector per track.

- Min = 0, Max = 255



Advanced BIOS Features

This section allows you to configure your system for basic operation.



BIOS Write Protect

This item let you enable or disable the BIOS Write Protect.

- The choice: Enabled or Disabled.

Virus Warning

Allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. Enable this item to prevent someone from writing data into this area.

Enabled Activates automatically when the system boots up, causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.

Disabled No warning message will appear when anything attempts to access the boot sector or hard disk partition table.

- The choice: Enabled or Disabled.

CPU Internal Cache

All processors that can be installed in this mainboard use internal level 1 (L1) cache memory to improve performance. Leave this item at the default value for better performance.

- The choice: Enabled or Disabled.

External Cache

Most processors that can be installed in this system use external level 2 (L2) cache memory to improve performance. Leave this item at the default value for better performance.

- The choice: Enabled or Disabled.

Quick Power On Self Test

Enable this item to shorten the power on testing (POST) and have your system start up faster. You might like to this item after you are confident that your system hardware is operating smoothly.

- The choice: Enabled or Disabled.

First/Second/Third Boot Device

Use these three items to select the priority and order of the devices that your system searches for an operating system at start-up time.

- The Choice: Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, USB-FDD, USB-ZIP, USB-CDROM, USB-HDD, LAN, or Disabled.

Boot Other Device

If you enable this item, the system searches all other possible locations for and operating system if it fails to find one in the devices specified under the First, Second, and Third boot devices.

- The choice: Enabled or Disabled.

Swap Floppy Drive

If you have two floppy diskette drives in your system, this item allows you to swap the assigned drive letters so that drive A becomes drive B, and drive B becomes drive A.

- The choice: Enabled or Disabled.

Boot Up Floppy Seek

If this item is enabled, it checks the size of the floppy disk drives at start-up time. You don't need to enable this item unless you have a legacy diskette drive with 360k capacity.

- The choice: Enabled or Disabled.

Boot Up NumLock Status

This item defines if the keyboard Num Lock key is active when your system is started.

- The choice: Off or On.

Gate A20 Option

This item defines how the system handles legacy software that was written for an earlier generation of processors. Leave this item at the default value.

- The choice: Normal or Fast.

Typematic Rate Setting

If this item is enabled, you can use the following two items to see the typematic rate and the typematic delay settings for your keyboard.

- The choice: Enabled or Disabled.

Typematic Rate (Chars/Sec)

This item sets how many times the keystroke will be repeated in a second when you hold a key down.

- The choice: 6, 8, 10, 12, 15, 20, 24, or 30.

Typematic Delay (Msec)

Sets the delay time after a key is held down.

- The choice: 250, 500, 750, or 1000.

Security Option

If you have installed password protection, this item defines if the password is required at system start up, or if it is only required with a user tries to enter the Setup Utility.

- The choice: Setup or System.

APIC Mode

This option is used to enable or disable APIC (Advanced Programmable Interrupt Controller) functionality.

- The choice: Enabled or Disabled.

MPS Version Control For OS

Selects the operating system multiprocessor support version.

- The choice: 1.1 or 1.4

OS Select For DRAM > 64MB

This item is only required if you have installed more than 64 MB of memory and you are running the OS/2 operating system. Otherwise, leave this item at the default.

- The choice: Non-OS2 or OS2.

Small Logo(EPA) Show

This item allows you to enable or disable the EPA Logo.

- The choice: Enabled or Disabled.



Advanced Chipset Features

This section allows you to configure the system based on the specific features of the installed chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM and the external cache. It also coordinates communications between the conventional PCI bus. It states that these items should never need to be altered.

The default settings have been chosen because they provide the best operating conditions for your system. If you discovered that data was being lost while using your system, you might consider making any changes.

Phoenix - AwardBIOS CMOS Setup Utility Advanced Chipset Features		
▶ DRAM Configuration	[Press Enter]	Item Help
CPU OverClock in MHz	[200]	Menu Level ▶
AGP OverClock in MHz	[66]	
AGP Aperture Size (MB)	[64M]	
x AGP 3.0 Speed	Auto	DRAM timing and control
AGP 2.0 Speed	[Auto]	
AGP Fast Write	[Auto]	
AGP Sideband Address	[Auto]	
Clock Spread Spectrum	[Enabled]	
LDT Downstream Width	[Auto]	
LDT Speed	[3x]	
Special I/O for PCI Card	[Disabled]	
x Base I/O Address	0000	
x I/O Length	1 Byte	
System BIOS Cacheable	[Disabled]	

↑↓:Move Enter:Select +/-PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

DRAM Configuration

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

DDR Timing Setting by

This item allows you to select the value in this field, depending on whether the board using which kind of DDR DRAM.

➤ The choice: Manual or Auto.

Max Memclock (Mhz)

Places an artificial memory clock limit on the system.

Memory is prevented from running faster than this frequency.

➤ The choice: 100,133,166 or 200.

CPU OverClock in MHz

This item selects the CPU OverClock in MHz.

➤ The choice: 200 ~ 250.

AGP OverClock MHz

This item selects the AGP OverClock MHz.

- The choice: 66 ~ 100.

AGP Aperture Size(MB)

Select the size of Accelerated Graphics Port (AGP) aperture.

The aperture is a portion of the PCI memory address range dedicated to graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.

- The choice: 32M, 64M, 128M, 256M or 512M.

AGP 3.0 Speed

This item allows you to set the AGP 3.0 Speed.

- The choice: Always Auto.

AGP 2.0 Speed

This item allows you to set the AGP 2.0 Speed.

- The choice: Auto, 1x, 1x2x or 1x2x4x.

AGP Fast Write

This item allows you to set the AGP Fast Write.

- The choice: Auto or Disabled.

AGP Sideband Address

This item auto/disable the AGP sideband addressing capability for AGP Card.

- The choice: Auto or Disabled.

Clock Spread Spectrum

This item allows you to set the spread spectrum modulation.

- The choice: Enabled or Disabled.

LDT Downstream Width

This item allows you to set the LDT Downstream Width.

- The choice: Auto or 8bits.

LDT Speed

This item allows you to set the LDT Speed.

- The choice: 1x, 2x, 2.5x, 3x or 4x.

Special I/O for PCI Card

This item enable/disable the Special I/O for PCI Card.

- The choice: Enabled or Disabled.

Base I/O Address

This item allows you to set the Base I/O Address.

- The choice: Enabled or Disabled.

I/O Length

This item allows you to set the I/O Length.

- The choice: 0000 ~ FFFF.


System BIOS Cacheable

Select Enable allows caching of the system BIOS ROM at F000h ~ FFFFFh, resulting in better system performance. However, if any program is written to this memory area, a system error may result.

- The choice: Enabled or Disabled.



Integrated Peripherals



Onboard IDE Device

Press <Enter> to enter the sub-menu of detailed options.

OnChip IDE Channel0/Channel1

The chipset contains a PCI IDE interface with support to two IDE channels. Select Enabled to activate the primary/secondary IDE interface. select Disabled to deactivate the primary/secondary interface.

➤ The Choice: Enabled or Disabled.

Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

➤ The choice: Auto, Mode 0, Mode 1, Mode 2, Mode 3, or Mode 4.

Primary/Secondary Master/Slave UDMA

Ultra DMA implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If both of your hard drive and your system software support Ultra DMA, select Auto to enable BIOS support.

➤ The choice: Auto or Disabled.

IDE Prefetch Mode

The onboard IDE drive interface support IDE prefetching for faster drive access. If you install a primary and/or secondary add-on IDE interface, set this field to Disabled if the interface does not support prefetching.

➤ The Choice: Enabled or Disabled.

IDE HDD Block Mode

Block mode is also called block transfer, multiple commands, or multiple sector read/write. If your IDE hard drive supports block mode (most new drives do), select Enabled for automatic detection of the optimal number of block read/write per sector the drive can support.

➤ The Choice: Enabled or Disabled.

Onboard PCI Device

Press <Enter> to enter the sub-menu of detailed options.

Init Display First

This item is used to determine initial device when system power on.

➤ The choice: PCI Slot or AGP Slot.

OnChip USB

Do not disable this item if your system has a USB installed on the system board and you want to use it.

➤ The choice: Disabled, V1.1 + V2.0, or V1.1.

USB Keyboard Support

Select Enabled if your system contains a Universal Serial Bus (USB) controller and you have a USB keyboard.

➤ The Choice: Enabled or Disabled.

Sil3112A SATA Raid ROM

This item allows you to control the Sil3112A SATA Raid ROM.

➤ The Choice: Enabled or Disabled.

Intel GbE 82540EM ROM

This item allows you to control the Intel GbE 82540EM ROM.

➤ The Choice: Enabled or Disabled.

OnChip Audio

This item allows you to control the OnChip Audio.

➤ The Choice: Auto or Disabled.

OnChip 10/100 Mbps Lan

This item allows you to set the onboard LAN Chip.

➤ The Choice: Auto or Disabled.

Onboard SuperIO Device

Press <Enter> to enter the sub-menu of detailed options.

Onboard FDC Controller

This item specifies onboard floppy disk drive controller. This setting allows you to connect your floppy disk drives to the onboard floppy connector.

- The choice: Enabled or Disabled.

Onboard Serial Port 1

The option is used to assign the I/O address and interrupt request (IRQ) for the onboard serial port 1 (COM1).

- The Choice: Disabled, 3F8-IRQ4, 2F8-IRQ3, 3E8-IRQ4, 2E8-IRQ3, or Auto.

Onboard Infrared Port

The option is used to assign the I/O address and interrupt request (IRQ) for the onboard Infrared Port.

- The Choice: Disabled, 3F8-IRQ4, 2F8-IRQ3, 3E8-IRQ4, 2E8-IRQ3, or Auto.

UART Mode Select

This item allows you to select an operating mode for the IrDA infrared.

- The choice: Normal, IrDA, ASKIR, or SCR.

UR2 Duplex Mode

This item allows you to select the IR half or full duplex function.

- The choice: Full or Half.

Onboard Parallel Port

Allows you to determine an I/O address and interrupt request (IRQ) for the onboard parallel port.

- The choice: 378/IRQ7, 278/IRQ5, 3BC/IRQ7, or Disabled.

Parallel Port Mode

Select an operating mode for the onboard parallel port. Select SPP unless you are certain your system supports other modes.

- The choice: SPP, EPP, ECP, or ECP + EPP.

ECP Mode Use DMA

When the parallel port mode is set to ECP, this item becomes selectable.

- The choice: 1 or 3.



Power Management Setup

The Power Management Setup allows you to configure your system to most effectively saving energy while operating in a manner consistent with your own style of computer use.

Phoenix - AwardBIOS CMOS Setup Utility		
Power Management Setup		
ACPI function	Enabled	Item Help
ACPI Suspend Type	[S1(POS)]	
Power Management	[User Define]	Menu Level ▶
Uidea Off Method	[DPMS Support]	
HDD Power Down	[Disabled]	
HDD Down In Suspend	[Disabled]	
Soft-Off by PBTN	[Instant-Off]	
WOL(PME#) From Soft-Off	[Disabled]	
WOR(RI#) From Soft-Off	[Disabled]	
USB Resume from S3	[Disabled]	
Power-On by Alarm	[Disabled]	
x Day of Month Alarm	0	
x Time <hh:mm:ss> Alarm	0 : 0 : 1	
PS2 Keyboard Power ON	[Disabled]	
KB Power ON Password	[Enter]	
Hot Key Power ON	[Any Key]	
PS2 Mouse Power ON	[Disabled]	
PWRON After PWR-Fail	[Off]	

↑↓: Move Enter: Select +/-/PU/PD: Value F10: Save ESC: Exit F1: General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

ACPI Function

This item defines the ACPI (Advanced Configuration and Power Management) feature that makes hardware status information available to the operating system, enables a PC to turn its peripherals on or off for improving the power management, and allows a PC turned on or off by external devices, so that a mouse or keyboard can wake up it.

ACPI Suspend Type

This item allows you to select sleep state when suspend. In the default, S1(POS), the suspend mode is equivalent to a software power down; S3(STR), to the system that shuts down with the exception of a refresh current to the system memory.

➤ The choice: S1(POS), S3(STR), or S1&S3.

Power Management

This item acts like a master switch for the power-saving modes and hard disk timeouts. If this item is set to Max Saving, power-saving modes occur after a short timeout. If it is set to Min Saving, power-saving modes occur after a longer timeout. If it is set to User Define, you can insert your own timeouts for the power-saving modes.

➤ The choice: Min Saving, Max Saving, or User Define.

Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC + Blank This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.

Blank Screen The item only writes blanks to the video buffer.

DPMS Support Initial display power management signaling.

- The choice: V/H SYNC + Blank, Blank Screen, or DPMS Support.

HDD Power Down

The IDE hard drive will spin down if it is not accessed within a specified length of time. Options are from 1 Min to 15 Min and Disabled.

- The choice: Disabled or 1 Min ~ 15 Min.

HDD Down In Suspend

The item allows you to enable or disable the HDD Down In Suspend.

- The choice: Enabled or Disabled.

Soft-Off By PBTN

Under ACPI you can create a software power down. In a software power down, the system can be resumed by Wake UP Alarms. This item lets you install a software power down that is controlled by the power button on your system. If the item is set to Instant-Off, then the power button causes a software power down. If the item is set to Delay 4 Sec., then you have to hold the power button down for 4 seconds to cause a software power down.

- The choice: Delay 4 Sec. or Instant-Off.

WOL(PME#) From Soft-Off

If this item sets to Enabled, the system power will be turned on when the LAN port receives an incoming signal.

- The choice: Enabled or Disabled.

WOR(RI#) From Soft-Off

If this item is enabled, it allows the system to resume from a software power down or power-saving mode whenever there is an incoming call to an installed fax/modem. You have to connector the fax/modem to the mainboard.

- The choice: Enabled or Disabled.

USB Resume from S3

If you are using USB devices, and the ACPI Suspend Type is set to S3 or S1&S3, enable this item to have USB devices wake up the system from power saving mode.

- The choice: Enabled or Disabled.

Power-On by Alarm

When set to Enabled, the following three fields become available and you can set the date, hour, and minute to turn on your system.

- The choice: Enabled or Disabled.

Time(dd : hh : mm) of Alarm

This item selects the alarm Time.

[dd] ➤ Key in a DEC number: Min = 0, Max = 31.

[hh] ➤ Key in a DEC number: Min = 0, Max = 23.

[mm] ➤ Key in a DEC number: Min = 0, Max = 59.

PS2 Keyboard Power ON

Set a password or a key to awaken the system from a keyboard.

- The choice: Disabled, Password, or Hot KEY.

KB Power ON Password

Press <Enter> to set a password to awaken the system from a keyboard.

Hot Key Power ON

Set a key to awaken the system from a keyboard.

- The choice: Any Key or Ctrl-F1 ~ F12.

PS2 Mouse Power ON

Enable or disable the function of awakening the system from a mouse.

- The choice: Enabled or Disabled.

PWRON After PWR-Fail

This item defines your computer to shut off or automatically restart.

- The choice: Off, or On.

PnP/PCI Configurations

This category configures how PnP and PCI operate in your system. Correctly setting up the IRQ and DMA (both PnP and PCI use) assignments will make your system work stably. It is strongly recommended that only technical users make changes to the default settings.

Phoenix - AwardBIOS CMOS Setup Utility		
PnP/PCI Configurations		
Reset Configuration Data	[Disabled]	Item Help Menu Level ▶ Default is Disabled. Select Enabled to reset Extended System Configuration Data ESCD when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot
Resources Controlled By	[Auto(ESCD)]	
x IRQ Resources	Press Enter	
PCI/VGA Palette Snoop	[Disabled]	
↑↓:Move Enter:Select +/-:PU/PD:Value F10:Save ESC:Exit F1:General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Reset Configuration Data

When enabled, any PnP configuration data stored in the BIOS will be cleared from memory, with new data created.

- The choice: Enabled or Disabled.

Resources Controlled By

As stays auto(ESCD), the system will dynamically allocate resources to PnP devices as they are required. As set to manual, the following item become available.

- The choice: Auto(ESCD) or Manual.

IRQ Resources

When the previous item is set to manual, this item allows you respectively assign an interruptive type for IRQ-3, 4, 5, 7, 9, 10, 11, 12, 14, and 15.

- The choice: PCI Device or Reserved.

PCI/VGA Palette Snoop

The item is designed to solve problems caused by some non-standard VGA cards.

- The choice: Enabled or Disabled.



PC Health Status

Phoenix - AwardBIOS CMOS Setup Utility	
PC Health Status	
Shutdown Temperature [Disabled]	Item Help
CPU Voltage	Menu Level ▶
AGP Voltage	
3.3V VIN	
+ 5V VIN	
+12V VIN	
-12V VIN	
RAM Voltage	
5V SBVIN	
Voltage Battery	
System Temperature	
CPU Temperature	
PWM Temperature	
FAN1 Speed	
FAN2 Speed	
FAN3 Speed	

↑↓:Move Enter:Select +/-PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Shutdown Temperature

Enables you to set the maximum temperature that system can reach before powering down.

- The choice: 60°C/140°F, 65°C/149°F, 70°C/158°F, or Disabled.

The following items provide you with information about the system's current operating status. You cannot make changes to one of them.

CPU Voltage

FAN1 Speed

AGP Voltage

FAN2 Speed

3.3V VIN

FAN3 Speed

+ 5V VIN

+ 12V VIN

-12V VIN

RAM Voltage

5V SBVIN

Voltage Battery

System Temperature

CPU Temperature

PWM Temperature



Frequency/Voltage Control

Phoenix - AwardBIOS CMOS Setup Utility	
Frequency/Voltage Control	
	Item Help
CPU Voltage Select [Auto]	Menu Level ▶
RAM Voltage Select [Auto]	
AGP Voltage Select [Auto]	
Chipset Voltage Select [Auto]	
LDT Voltage Select [Auto]	

CPU Voltage Select

This item allows you to adjust CPU Voltage.

- The choice: Auto, 0.800V ~ 1.700V.

RAM Voltage Select

This item allows you to adjust RAM Voltage.

- The choice: Auto, 2.70 V, 2.80V or 2.90 V.

AGP Voltage Select

This item allows you to adjust AGP Voltage.

- The choice: Auto, 1.60 V, 1.70V or 1.80 V.

Chipset Voltage Select

This item allows you to adjust chipset Voltage.

- The choice: Auto, 1.70 V, 1.80V or 1.90 V.

LDT Voltage Select

This item allows you to adjust LDT Voltage.

- The choice: Auto, 1.30 V, 1.40V or 1.50 V.



Load Fail-Safe Defaults

When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

Load Fail-Safe Defaults (Y/N) ? N

Pressing 'Y' loads the BIOS default values for the most stable, minimal performance system operations.



Load Optimized Defaults

When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

Load Optimized Defaults (Y/N) ? N

Pressing 'Y' loads the default values that are factory-set for optimal performance system operation.



Set Supervisor/User Password

Phoenix - AwardBIOS CMOS Setup Utility

▶ Standard CMOS Features	▶ Frequency/Voltage Control
▶ Advanced BIOS Features	Load Fail-Safe Defaults
▶ Advanced Chipset Features	Load Optimized Defaults
▶ Integrated Peripherals	Set Supervisor Password
▶ Power Management Setup	Set User Password
▶ PnP/PCI Configuration	
▶ PC Health Status	

Enter Password: []

Esc : Quit F9 : Menu in BIOS ↑ ↓ ← → : Select Item
F10 : Save & Exit Setup

Change/Set/Disable Password

Steps to set supervisor/user password are described as follows:

New Password Setting:

1. While pressing <Enter> to set a password, a dialog box appears to ask you enter a password.
2. Key in a new password. The password can not exceed eight characters.
3. System will request you to confirm the new password again.
4. When completed, new code takes effect.

No Password Setting:

If you want to disable the password, just press <Enter> as a password input is requested.

If You Forget Password:

If you forget the password, the only way to access the system is to clear the CMOS memory. Please refer to page 28 on clear CMOS setting.

Save & Exit Setup

Pressing <Enter> on this item asks for confirmation:

SAVE to CMOS and EXIT (Y/N)? Y

Pressing "Y" stores the selections made in the menus of CMOS - a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

Exit Without Saving

Pressing <Enter> on this item asks for confirmation:

Quit Without Saving (Y/N)? N

This allows you to exit from Setup without storing in CMOS any change. The previous selections remain in effect. This exits from the Setup utility and restarts your computer.