

❖ Installation Guide ❖

1



- ❖ Place the switching power supply on the socket, and lodge it in the holder.

- ❖ 安裝電源供應器，並卡住扣具。

3



- ❖ Put the HDD power wire through the reserved hole.

- ❖ 將硬碟電源線穿過定位孔。

5



- ❖ Plug in the 2X2-pin or 1x4-pin ATX power supply header.

- ❖ 插入 2X2-pin or 1x4-pin 的 ATX 電源供應器接頭。

2



- ❖ Fasten the screws.

- ❖ 鎖上固定螺絲。

4



- ❖ Plug in the 20-pin ATX power supply header.

- ❖ 插入 20-pin 的 ATX 電源供應品器接頭。

6



- ❖ Completed.

- ❖ 完成。