




❖ Installation Guide ❖

- 
 - ❖ Place the switching power supply on the socket, and lodge it in the holder.
 - ❖ 安裝電源供應器，並卡住扣具。
- 
 - ❖ Fasten the screws.
 - ❖ 鎖上固定螺絲。
- 
 - ❖ Put the HDD power wire through the reserved hole.
 - ❖ 將硬碟電源線穿過定位孔。
- 
 - ❖ Plug in the 20-pin ATX power supply header.
 - ❖ 插入 20-pin 的 ATX 電源供應品器接頭。
- 
 - ❖ Plug in the 2X2-pin or 1x4-pin ATX power supply header.
 - ❖ 插入 2X2-pin or 1x4-pin 的 ATX 電源供應器接頭。
- 
 - ❖ Completed.
 - ❖ 完成。