



www.shuttle.com

-  **Power**  
This key will let you turn off the system and lead you to Windows operating system screen.
-  **Media**  
This key will let you launch the window of Microsoft Media Player.
-  **Internet**  
This key will launch the default Internet Browser. The browser will go to the home page set for the browser.
-  **E-mail**  
This key will launch the default mail application installed on your system. If there is no response after you press this key, check the default mail application by selecting the Internet option applet from the control panel.
-  **My Computer**  
This key will open My Computer after entering Windows system.
-  **My Favorite**  
This key will open My Favorite after entering Internet browser application.
-  **Previous Page**  
This key will bring you back to the previous pages accessed before.
-  **Next Page**  
This key will bring you to the next Internet pages accessed before.

-  **Mouse Control Pad**  
This key will let you control the cursor on screen.
-  **L**  
This key works as left button on mouse.
-  **R**  
This key works as right button on mouse.
-  **M**  
This key will let you select and drag an object by manipulating the Mouse Control Pad.
-  **Previous Track**  
This key will let you skip the current track and go to the beginning position of the previous track.
-  **Play / Pause**  
This key will let you start to play, or pause the current play status.
-  **Next Track**  
This key will let you skip the current track and go to the beginning position of the next track.
-  **Full Screen**  
This key will leave the window of Microsoft Media Player in full screen when video plays.

-  **Stop**  
This key will stop playing and return to the beginning position of the track.
-  **Mute**  
This key will toggle the sound mute or not mute.
-  **Volume Increase/Decrease**  
This key will increase/decrease the main volume of the sound.
-  **Windows Start**  
This key will present the Windows Start Menu.
-  **Page Up / Down**  
This key will let you scroll up / down pages.
-  **Esc**  
Function as <Esc> on keyboards.
-  **Tab**  
Function as <Tab> on keyboards.
-  **Back Space**  
Function as <Backspace> on keyboard.
-  **Number Key**  
This key will let you navigate through CD titles in Microsoft Media Player.
-  **Enter**  
This key has the same function as <Enter> on keyboards.

