

---

# **PF27 User Guide**

---

---

# TABLE OF CONTENTS

---

<b>Driver and Software Installation .....</b>	<b>1</b>
<b>Install Software .....</b>	<b>1</b>
<b>Shuttle Versatile Front-panel Display (VFD) Introduction .....</b>	<b>2</b>
<b>Remote Control Key Definition .....</b>	<b>3</b>
<b>XPC Tools Software .....</b>	<b>4</b>

---


## Driver and Software Installation

---

### ■ Install Software

Insert the attached CD into your CD-ROM drive. The CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on Autorun icon in My Computer to bring up Shuttle PF27 Software Setup screen.


- ☞ Install VFD Driver
- ☞ Install E-home IR Receiver HotFix
- ☞ Install XPCTools
- ☞ Manual - PF27 manual in PDF format.
- ☞ Quit - Close this CD.




















---


## ■ Shuttle Versatile Front-panel Display (VFD) Introduction

The VFD panel included in this XPC is designed to serve as an alternative display for enhanced multimedia enjoyment. As such, the VPD panel can display; music track info, time, track time, DVD info, DVD play length, TV channel, radio stations, picture information and much more. Better still, this VFD panel delivers all this content without obstructing your main display or vision.



-  Text Display
-  Time
-  Radio
-  Music
-  DVD/VCD
-  TV
-  Picture
-  Rew (Rewind)
-  Record
-  Play
-  Pause
-  Stop
-  FF (Fast Forward)
-  Repeat
-  Shuffle
-  Mute
-  Volume

## ■ Remote Control Key Definition



---

## ■ XPC Tools Software

Created especially for the XPC, XPC Tools includes many useful features to allow you to manage and control your system from the comfort of your Windows operating environment.

Included in this version of XPC Tools are features to allow you to:

1. Manage Performance settings
2. Control Acoustic environment
3. Control Thermals (CPU and System)
4. Monitor System Information
5. Manage Versatile Front-panel Display (VFD) settings
6. Select Hot Keys for your Optical Drive
7. Optimize System settings for certain applications
8. Schedule auto shutdown

To install XPC Tools:

1. Select the utilities bar in the mainboard driver CD.
2. Click on XPC Tools. Follow the on screen instructions.
3. An XPC Tools icon will automatically appear on the desktop following installation. Click this to run XPC Tools.
4. For instructions on how to use XPC Tools, click the help icon on the XPC Tools Menu.

Using XPC Tools:

XPC Tools Main view

The main XPC Tools interface contains 3 groups of buttons.

Each group allows access to different XPC Tools functions.

