



# X50 Series Quick Guide 【 English 】

Shuttle®


## Front/Rear/Side View



- 01 Webcam
- 02 Microphone
- 03 LCD Display (Touch enabled)
- 04 Hard disk drive LED
- 05 Volume controls
- 06 Brightness controls
- 07 Light Bar controls
- 08 WiFi LED
- 09 Stereo speaker




- 10 VGA Port
- 11 Printer Port (for X50i only)
- 12 COM Ports (for X50i only)
- 13 Stand / Handle
- 14 USB Ports
- 15 Power input DCIN
- 16 UP/Down +/-
- 17 Setup selection button
- 18 Stylus pen
- 19 Power Switch



- 20 4 in 1 Memory card reader
- 21 USB Ports
- 22 Audio Line-In Port
- 23 Audio Line-Out Port
- 24 MIC-In Port
- 25 LAN Port
- 26 Kensington® Lock Port


## Placing on the desktop




- To placing on the desktop and carry your X50, do the following:  
Place X50 on a flat surface such as a table (Picture 1), and pull the stand open until it snaps in place. Then, you can adjust X50 for the comfortable angle. (Picture 2)  
When carry or move your X50, hold the Top of the computer by its handle. (Picture 3)

## Powering on the system

- Follow the steps (1~3) below to connect the AC adapter to the DCIN jack.  
Press the **Power Switch** to turn on the system.



## How to use Touch Panel



- X50 brings digital life for an easy touch experience. Experience the ease of managing your digital life with a few touches or the use of the stylus pen. Your touch functions like a mouse device and all you need to interact with the X50.

- Touch = left-click on the mouse
- Touch and hold = right-click on the mouse


## Cleaning the touch screen

- Follow these rules for cleaning the outside and handling your screen on the computer :  
Turn off the system and disconnect all cables.  
Use a damp, or cleaning cloth, soft, lint-free cloth with gentle water only and gently wipe the screen surface.  
Do not spray liquid directly on the screen.


## 4 Point Calibration

- Run the screen calibration program and correct 4 point locations on screen with the panel.


Click **Start / All Programs / eGalax Touch / Configure Utility**  
Select **Tools** tab and click **4 Points Calibration**.




- Touch and hold the center of the target.  
Repeat on four corners and the screen will adjust automatically.



- When the 4 points calibration completed, press **OK** to continue.



## VESA mounting to the wall



- If you are mounting your X50 to the wall, remove the "Shuttle" Cover on the back of X50 first.

Unscrew 4 screws of the stand mount and remove the stand. Standard VESA to let user mount it on the wall easily. Please refer to the user guide of the wall/arm mount kit you bought to install it.

Note: X50 can be mounted on a wall using a VESA compatible 100mm x 100mm wall/arm bracket.

## Safety Information

Read the following precautions before setting up a Shuttle X50.

### CAUTION

Do not walk on the power cord or allow anything to rest on it.  
The warranty does not apply to the products that have been disassembled by users.

### CAUTION

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

## How to adjust LCD brightness, volume, light bar brightness

- Press the setup selection button to select between LCD brightness or volume or light bar brightness controls. Use UP + or DOWN - key to adjust brightness and volume.

