


SH67H3 Quick Guide 【English】

Front Panel



- F1. 5.25" Bay
- F2. 3.5" Bay
- F3. Power Switch & Power LED
- F4. HDD LED
- F5. Reset
- F6. Headphone
- F7. Mic In
- F8. USB3.0 Ports
- F9. eSATA+USB2.0 Port


Back Panel



- B1. AC Power Socket
- B2. DVI-I Port
- B3. HDMI Port
- B4. USB3.0 Ports
- B5. Esata & USB2.0 Ports
- B6. LAN & USB2.0 Ports
- B7. Line-In Port
- B8. Center/Bass Port
- B9. Front Out (L/R)
- B10. Side Surr (L/R)
- B11. Clear CMOS Button
- B12. Surround Back (L/R) Port
- B13. SPDIF Out Port
- B14. Wireless LAN Perforation
- B15. Serial Port Perforation

⚠ DVI-I & HDMI Ports cannot be used, if the PCI-e/ PCI Express graphics card is installed.


Motherboard Illustration





Jumper Settings

J1 S/PDIF Out connector

- Pin Assignments (JP1):
- 1=GND
 - 2=VCC
 - 3=SPDIFO




J2 Fan Connectors




J3 AUX IN Connector

- Pin Assignments (AUX_IN1):
- 1=CD_IN_L
 - 2=Ground
 - 3=Ground
 - 4=CD_IN_R




J4 CIR connector

- Pin Assignments (JP6):
- 1=Ground
 - 2=5V_DUAL
 - 3=CIR-RX




J5 USB Connector

- Pin Assignments (USB1):
- 1=VCC
 - 2=VCC
 - 3=D1-
 - 4=D0-
 - 5=D1+
 - 6=D0+
 - 7=Ground
 - 8=Ground
 - 9=KEY
 - 10=Ground




J6 Front Connector

- Pin Assignments (JP3):
- 1=HDD_IED
 - 2=Power_LED
 - 3=HDD_IED-
 - 4=Ground
 - 5=Reset_button
 - 6=Power_button
 - 7=Ground
 - 8=Ground
 - 9=NC
 - 10=NA




J7 USB 3.0 Connector

- Pin Assignments (CN5):
- 1=Wake-
 - 2=-PCI-E RST
 - 3=Ground
 - 4=USB3_100M+
 - 5=USB3_100M-
 - 6=Ground
 - 7=PET2P
 - 8=PET2N
 - 9=-Ground
 - 10=PER2P
 - 11=PER2N
 - 12=Ground
 - 13=VCC3
 - 14=VCC3



J8 RS232 Header

- Pin Assignments (COM1):
- 1=DCD1P
 - 2=RX1P
 - 3=TXD1P
 - 4=DTR1P
 - 5=Ground
 - 6=DSR1P
 - 7=RTS1P
 - 8=CTS1P
 - 9=-XRI
 - 10=NA



Safety Information

Read the following precautions before setting up a Shuttle XPC.

CAUTION

Incorrectly replacing the battery may damage this computer. Replace only with the same or equivalent as recommended by Shuttle. Disposal of used batteries according to the manufacturer's instructions.

Laser compliance statement

The optical disc drive in this PC is a laser product. The drive's classification label is located on the drive.


CLASS 1 LASER PRODUCT

CAUTION: INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM.

A. Begin Installation

⚠ For safety reasons, please ensure that the power cord is disconnected before opening the case.

1. Unscrew 3 thumbscrews of the chassis cover.
2. Slide the cover backwards and upwards.



3. Unfasten the rack mount screws and remove the rack.



B. CPU and ICE Installation


1. Unfasten the ICE fan thumbscrews on the back of the chassis.
2. Unfasten the four ICE module attachment screws and unplug the fan connector.




3. Remove the ICE module from the chassis and put it aside.

⚠ This 1155 pin socket is fragile and easily damaged. Always use extreme care when installing a CPU and limit the number of times that you remove or change the CPU. Before installing the CPU, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the CPU.

- Follow the steps below to correctly install the CPU into the motherboard CPU socket.




5. Lift the metal load plate on the CPU socket.




⚠ DO NOT touch socket contacts. To protect the CPU socket, always replace the protective socket cover when the CPU is not installed.

6. Orientate the CPU and socket, you may align the CPU notches with the socket alignment keys. Make sure the CPU is perfectly horizontal, insert the CPU into the socket.



⚠ Please be aware of the CPU orientation, DO NOT force the CPU into the socket to avoid bending of pins on the socket and damage of CPU!

7. Close the metal load plate, lower the CPU socket lever and lock in place.
8. Spread thermal paste evenly on the CPU surface.




⚠ Please do not apply excess amount of thermal paste.

9. Tear off the protective membrane from the bottom of ICE module. Remove the protective socket mylar from the CPU socket.

10. Screw the ICE module to the mainboard. Note to press down on the opposite diagonal corner while tightening each screw.

11. Connect the fan connector.



12. Fasten the Smart Fan to the chassis with the 4 thumbscrews.



C. Memory module Installation

Guidelines for Memory Configuration

Before installing DIMMs, read and follow these guidelines for memory configuration.


⚠ Make sure that the motherboard supports the memory.

It is recommended that memory of the same capacity, brand, speed, and chips are used.

(Go to Shuttle's website for the latest memory support list.) Memory modules have a foolproof design. A memory module can be installed in only one direction. If you are unable to insert the memory, switch the direction.

Dual-Channel mode Population Rule

In Dual-Channel mode, the memory modules can transmit and receive data with two data bus lines simultaneously. Enabling Dual-Channel mode can enhance the system performance. The following illustrations explain the population rules for Dual-Channel mode.




Installing a memory module


DDR3 DIMMs are not compatible to each other or DDR DIMMs. Be sure to install DDR3 DIMMs on this motherboard. Follow the steps below to correctly install your memory modules in the memory sockets.

1. Unlock the DIMM latch.
2. Align the memory module's cutout with the DIMM slot notch. Slide the memory module into the DIMM slot.

⚠ A DDR3 memory module has a cutout, so it can only fit in one direction.




3. Check that the latches are closed, and the memory module is firmly installed.




⚠ Repeat the above steps to install additional memory modules, if required.

D. Peripheral Installation


1. Loosen the purse lock and separate the Serial ATA and power cables.
2. Place the HDD and optical drive in the rack and secure with screws from the side.




3. Place the rack in the chassis and refasten the rack.



4. Connect the Serial ATA and power cables to the HDD.




5. Connect the Serial ATA and power cables to the optical drive.



E. Accessories Installation

1. Unfasten expansion slot bracket screws. Remove the back panel bracket and put the bracket aside.

⚠ The maximum size acceptable for display cards is 267mm x 98mm x 34.6mm.




2. Install the PCI/PCI Express x16 card into the PCI/PCI Express x16 slots.
3. Secure the bracket.



F. Complete

1. Replace the cover and refasten the thumbscrews.



2. Complete.

⚠ Please press "Del" key while booting to enter BIOS and load the optimised BIOS settings.