

MV43V/MV43VN

Pentium 4 Processor

Based DDR/SDR MAIN BOARD

User's Manual

Shuttle® MV43V/MV43VN

Pentium 4/Celeron , 478-pin processor based DDR Mainboard Manual Version 1.0

Copyright

Copyright© 2003 by Shuttle® Inc. All Rights Reserved.

No part of this publication may be reproduced, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without prior written permission from Shuttle® Inc.

Disclaimer

Shuttle® Inc. shall not be liable for any incidental or consequential damages resulting from the performance or use of this product.

This company makes no representations or warranties regarding the contents of this manual. Information in this manual has been carefully checked for reliability; however, no guarantee is given as to the correctness of the contents. In the interest of continued product improvement, this company reserves the right to revise the manual or include changes in the specifications of the product described within it at any time without notice and without obligation to notify any person of such revision or changes. The information contained in this manual is provided for general use by the customers.

Trademarks

Shuttle is a registered trademark of Shuttle Inc.

Intel Pentium is a registered trademarks of Intel Corporation.

VIA is a registered trademarks of VIA Corporation.

PS/2 is a registered trademark of IBM Corporation.

AMI is a registered trademark of AMI Software Inc.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

General Notice: Other product names used in this manual are ascribed to their respective owners and acknowledged.

Statement of Shuttle Mainboard via the EMI Test

Shuttle mainboards have been via the EMI test in terms of series of regulations: EN55022/ CISPR22/AS/NZS3548 Class B, EN55024 (1998/AS/NZS), EN4252.1 (1994), EN61000, ANSI C63.4 (1992), CFR47 Part 15 Subpart B, and CNS13438 (1997). The items tested are illustrated as follows:

(A) Voltage: AC 110V/60HZ & AC 230V/50HZ

(B) Tested Product Information:

Product Name: PC Mainboard

Status: Sample

Model Name: MV43V/MV43VN

S/N: N/A

CPU:

External Frequency: 133 MHz

Intel Pentium4: 2.26GHz/ 2.4GHz/ 2.53GHz/ 2.66GHz/ 2.8GHz/ 3.06GHz

External Frequency: 100 MHz

Intel Pentium4: 2GHz/ 2.2GHz/ 2.4/ 2.5GHz

Keyboard Port: One port with 6 pins

Mouse Port: One port with 6 pins

USB 2.0 Port: Two ports with 4 pins respectively

Parallel Port: One port with 25 pins

Serial Port: One port with 9 pins respectively

VGA Port: One port with 15 pins

LAN Port: One port with 8 pins

Line-Out & Line-In & Mic-In Ports: one port for each

DDR Memory: 256 MB *2

All CPUs have completely been tested, and values offered by the worst EMI combination of CPU external frequency are listed as follows:

Test Mode	External Frequency	CPU	Power Supply	Case Open/Closed
1	133MHz	P4 3.06GHz	ENP-0730(ATX12V)	Closed
2	133MHz	P4 3.06GHz	ENP-0730(ATX12V)	Open
3	100MHz	P4 2.5GHz	ENP-0730(ATX12V)	Closed
4	100MHz	P4 2.5GHz	ENP-0730(ATX12V)	Open

(C) Remedy for the Tested Product & Its EMI Interference:

Remedy: N/A

EMI Interference:

Crystal: 14.318 MHz(Y1)/24.576 MHz(Y2)/32.768 KHz(Y3)/25MHz(Y4)/
12MHz(Y5)

Clock Generator: CLK1

(D) Supported Host Peripherals:

Host Peripheral	Product Name	Model Name	S/N	FCC ID
#1	Case	KF45A	N/A	
#2	Power Supply (300W)	ENP-0730 (ATX12V)	100002885	
#3	IBM HDD (30.7GB)	91024UB	YKFY7981	3892I168
#4	MITSUMI FDD	D353M		
#5	SONY VCD Player	CDU4811	3892A291	
#6	AGP Card	Winfast Geforce 2MX		3892C520
#7	Power Cable	Detachable and Shielded		

TABLE OF CONTENTS

WHAT'S IN THE MANUAL	5
Quick Reference	5
About This Manual	5
1 INTRODUCTION	6
1.1 TO DIFFERENT USERS	6
FIRST-TIME DIY SYSTEM BUILDER	6
EXPERIENCED DIY USER	6
SYSTEM INTEGRATOR	6
1.2 ITEM CHECKLIST:	7
2 FEATURES	8
2.1 SPECIFICATIONS	8
3 HARDWARE INSTALLATION	11
3.1 STEP BY STEP INSTALLATION	11
Accessories of MV43V/MV43VN	11
STEP 1 Install the CPU	12
STEP 2 Set Jumpers	13
STEP 3 Install DDR SDRAM System Memory	13
STEP 4 Install Peripherals in System Case	14
STEP 5 Mount the Mainboard on the Computer Chassis	15
STEP 6 Connect Front Panel Switches/LEDs/Speaker/USB	16
STEP 7 Connect IDE and Floppy Disk Drives	17
STEP 8 Connect Other Internal Peripherals	18
STEP 9 Connect the Power Supply	18
STEP 10 Install Add-on Cards in Expansion Slots	19
STEP 11 Connect External Peripherals to Back Panel	20
STEP 12 First Time System Boot Up	21
STEP 13 Install Drivers & Software Components	22

3.2 JUMPER SETTINGS	23
JUMPERS & CONNECTORS GUIDE	24
<i>Jumpers</i>	
Clear CMOS Setting (JBAT1)	27
CPU Clock Setting (JP1A1/JP1B1)	27
Keyboard Power On(JP2)	28
<i>Back-Panel Connectors</i>	
PS/2 Keyboard & PS/2 Mouse Connectors	29
Parallel Port Connector	29
COM1 Port Connector	29
VGA Port Connector	29
USB1/USB2 Port Connectors	29
LAN Port Connector(MV43VN Only)	30
USB3/USB4 Port Connectors	30
Line-In Port Connector	30
Line-Out Port Connector	30
Mic-In Port Connector	30
<i>Front-Panel Connectors</i>	
HDD LED Connector(HD_LED)	31
Green LED Connector (SP_LED)	31
Hardware Reset Connector (RST)	32
ATX Power On/Off Switch Connector (PW_BN)	32
Speaker Connector (SPK1)	33
Extended USB Header (USB2)	33
<i>Internal Peripherals Connectors</i>	
Enhanced IDE and Floppy Connector	34
<i>Other Connectors</i>	
ATX Power Supply Connectors (CN5/PJ1)	35

CPU & System Fan Connectors (CPU-FAN, SYSTEM-FAN)	36
Serialinfrared Port (SIR1)	36
Audio Cable Header (CD2)	37
Front-Panel Microphone and Line_out Header (PANEL1)	37
3.3 SYSTEM MEMORY CONFIGURATION	38
1. INSTALL MEMORY	38
2. UPGRADE MEMORY	38
4 SOFTWARE UTILITY	39
4.1 Mainboard CD Overview	39
4.2 Install Mainboard Software Driver	40
4.2A Install VIA Chipset Driver	41
4.2B Install VGA Driver	42
4.2C Install Audio Driver	43
4.2D Install USB2.0 Driver	44
4.2E Install LAN Driver(MV43VN Only)	45
4.3 View the User's Manual	46
5 BIOS SETUP	47
5.1 ENTER BIOS	47
5.2 THE MAIN MENU	48
STANDARD CMOS SETUP	50
ADVANCED SETUP	52
POWER MANAGEMENT SETUP	56
PCI/PLUG AND PLAY SETUP	58
LOAD OPTIMAL SETTING	59
LOAD BEST PERFORMANCE SETTING	59
FEATUNES SETUP	60

CPU PNP SETUP	62
HARDWARE MONITOR	63
CHANGE PASSWORD	64
EXIT	65

WHAT'S IN THE MANUAL

Quick Reference

Hardware Installation >> Step-by-Step	Page 11
Jumper Settings >> A Closer Look	Page 23
Drivers/Software Utilities >> How to Install	Page 39
BIOS Setup >> How to Configure	Page 47

About This Manual

For First-Time DIY System Builder	Page 6
For Experienced DIY User	Page 6
For System Integrator	Page 6

1 INTRODUCTION

1.1 To Different Users

First-Time DIY System Builder

Welcome to the DIY world! Building your own computer system is not as difficult as you may think. To make your first computer DIY experience successful, right from the start, we have designed the 3.1 Hardware Installation section in a step-by-step fashion for all the first-time DIY system builders. Prior to installation, we also suggest you to read the whole manual carefully to gain a complete understanding of your new Shuttle MV43V/MV43VN mainboard.

Experienced DIY User

Congratulate on your purchase of the Shuttle MV43V/MV43VN mainboard. You will find that installing your new Shuttle MV43V/MV43VN mainboard is just easy. Bundled with an array of onboard functions, the highly-integrated MV43V/MV43VN mainboard provides you with a total solution to build the most stable and reliable system. Refer to sections 3.2 Jumper Settings and Chapter 4 Drivers/Software Utilities to find out how to get the best out of your new mainboard. Chapter 5 BIOS Setup also contains the relevant information on how to tune up your system to achieve higher performance.

System Integrator


You have wisely chosen Shuttle MV43V/MV43VN to construct your system. Shuttle MV43V/MV43VN incorporates all the state-of-the-art technology of the P4 M266A chipset from VIA. It integrates the most advanced functions you can find to date in a compact Micro ATX board.

This mainboard adopted in MV43V and MV43VN mainboards at the same time. The difference between MV43V and MV43VN is that MV43VN equips with onboard VIA VT6103 LAN PHY. In the manual, if there are some standards, characters, equipment or software only appeared or adopted by MV43VN; it will be mentioned(MV43VN Only).

1.2 Item Checklist:

Check all items with your MV43V/MV43VN mainboard to make sure nothing is missing. The complete package should include:

- ★ One piece of Shuttle MV43V/MV43VN Mainboard



- ★ One piece of ATA 133/100/66/33 Ribbon Cable




- ★ IO Shielding



- ★ One piece of Floppy Ribbon Cable




- ★ One piece of twin ports USB Cable (optional)



- ★ MV43V/MV43VN User's Manual



- ★ One piece of Bundled CD-ROM with containing:
 - MV43V/MV43VN user's manual saved in PDF format
 - VIA Chipset System Driver
 - VIA VGA Driver
 - Onboard Audio controller driver
 - AMI Flashing Utility
 - LAN Driver (MV43VN Only)
 - USB2.0 Driver



2 FEATURES

MV43V/MV43VN mainboard is carefully designed for the demanding PC user who wants high performance and maximum Intelligent features in a compact package.

2.1 Specifications

★ CPU Support

Intel Pentium 4, 478-pin processors with 400/533 MHz FSB.

★ Chipset

Features VIA P4M266A N.B. and VIA VT8235 S.B..

★ Integrated Graphics Controller

P4M266A integrates S3® Savag4™ graphics accelerator into a single chip. P4M266A brings mainstream graphics performance to the Value PC with leading-edge 2D, 3D and DVD video acceleration into a cost effective package. Based on its capabilities, P4M266A is an ideal solution for the consumer, corporate mobile users and entry-level professionals.

Maximum-shared memory size is 32MB.

★ Built-in Ethernet LAN (MV43VN Only)

Built-in 10BaseT/100BaseTX Ethernet LAN.

VT8235 integrates Fast Ethernet MAC and VT6103 LAN PHY in compliance with IEEE802.3u 100BASE-TX, 10BASE-T and ANSI X3.263 TP-PMD standards.

In compliance with ACPI 1.0 and the Network Device Class Power Management 1.0.

High performance achieved by 100Mbps clock generator and data recovery circuit for 100Mbps receiver.

★ AC'97 Audio Codec

AC'97 2.1 compliant.

Spread independent PCI functions for Audio and Modem.

★ Versatile Memory Support

Two 184-pin DIMM slots to support up to 2GB of PC1600 or PC2100 compliant DDR SDRAM module.

★ PCI Expansion Slots

Provides two 32-bit PCI slots.

★ AGP Expansion Slots

Provides one 32-bit AGP slot which supports 4X AGP devices.

★ CNR Expansion Slot

Provides one CNR (Communication/ Network Riser) slot.

★ 6 USB 2.0 Interface Onboard

- 4 USB connectors on back-panel and one set of dual USB ports headers on mid-board.

★ I/O Interface

Provides a variety of I/O interfaces:

- 1* Floppy interface for 3.5-inch FDD with 720KB, 1.44MB, or 2.88MB format or for 5.25-inch FDD with 360K or 1.2MB format.
- 1*PS/2 mouse connector.
- 1*PS/2 Keyboard connector.
- 1*RJ45 LAN connector.(MV43VN Only)
- 1*DB9 serial connector 16550 UART compatible.
- 4*USB ports.
- 1*VGA port.
- 1*DB25 Parallel port supports Standard Parallel Port and Bi-directional (SPP), Enhanced Parallel Port (EPP), and Extended Capabilities Port (ECP) data transmission schemes.
- 1*Line-Out port.
- 1*Line-In port.
- 1*Mic-In port.

★ PCI Bus Master IDE Controller Onboard

Two Ultra DMA 133/100/66/33 Bus Master Dual-channel IDE ports provide support to a maximum of four IDE devices (one Master and one Slave per channel). The IDE Bus implements data transfer speeds of up to 133/100 /66/33 MB/sec and also supports Enhanced PIO Modes.

80-pin Cable Backward Compatible Legacy ATAPI Devices, ATAPI IDE CD-ROM, CD-R, CD-RW, and LS-120 Supports.net).

★ ATX Power Supply Connector

ATX power supply unit can connected to the onboard 20-pin Pentium 4 standard ATX power connectors, supporting Suspend and Soft-On/Off by dual-function power button.

The Pentium 4 ATX power include one 4-pin + 12V ATX power connector.

★ **Advanced Configuration and Power Interface**

Features four power saving modes: S1 (Snoop), S4 (Suspend to DISK), and S5 (Soft-Off). ACPI provides more efficient Energy Saving Features controlled by your operating system that supports OS Direct Power Management (OSPM) functionality.

★ **System BIOS**

Provides licensed AMI BIOS 2Mb Flash core and supports Green PC, Desktop Management Interface (DMI).

★ **Micro ATX Form Factor**

System board conforms to Micro ATX specification.

Board dimension: 244mm*200mm.

★ **Advanced Features**

- Low EMI - Built in spread spectrum and automatic clock shut-off of unused PCI/SDRAMS slots to reduce EMI.
- Dual Function Power Button - The system can be in one of two states, one is Suspend mode and the other is Soft-Off mode. Pushing the power button for less than 4 seconds places the system into Suspend mode. When the power button is pressed for longer than 4 seconds, the system enters Soft-Off mode.
- CPU Clock Setting - This item allows users to adjust CPU Host Clock in BIOS.
- CPU Multiplier Setting - This item allows users to adjust CPU Multiplier in BIOS.

★ **Intelligent Features**

- Voltage Monitoring - Monitors various voltages of key elements, such as the CPU, and other critical system voltage levels to ensure stable current passing through mainboard components.
- Fan Status Monitoring - To prevent CPU from overheating, the CPU fan is monitored for RPM and failure. (CPU Cooling FAN with RPM sensor is required.)
- Temperature Monitoring - This item allows users to make sure whether the CPU or system runs in a suitable temperature.


3 HARDWARE INSTALLATION

Before removing or installing any of these devices including CPU, DIMMs, Add-On Cards, Cables, please make sure to unplug the onboard power connector.

This section outlines how to install and configure your mainboard. Refer to the following mainboard layout to help you to identify various jumpers, connectors, slots, and ports. Then follow these steps designed to guide you through a quick and correct installation of your system.

3.1 Step-by-Step Installation

Accessories Of MV43V/MV43VN




Step 1

CPU Installation:

This mainboard supports Intel Pentium 4/Celeron Socket 478 series CPU. Please follow the steps as follows to finish CPU installation.


Note the CPU orientation when you plug it into CPU socket.

1. Pull up the CPU socket lever to 90-degree angle.




CPU socket lever up to 90-degree angle

2. Locate Pin 1 in the socket and look for a black dot or cut edge on the CPU upper interface. Match Pin 1 and cut edge, and insert the CPU into the socket.



CPU Pin 1 and cut edge

3. Press down the CPU socket lever and finish CPU installation.



Note: The CPU might be damaged if you do not match the CPU socket Pin 1 and cut edge well.

4. Intel Pentium 4/Celeron processors require a set of heatsink and fan to cool down the processor. You need to purchase a heatsink and fan if they are not bundled with your CPU. Required is that install the set and plug its cable in the CPU fan power connector. Note that there are kinds of CPU fan connectors. Normally, if your mainboard supports a hardware monitoring function, a 3-pin fan power connector can have your system detect the CPU fan's speed. A CPU fan with a 2-pin or 4-pin fan power connector does not support the detection of the CPU fan's speed, and must directly be connected to the system's power supply unit.

Step 2.

Set Jumpers

The default jumper settings have been set for the common usage standard of this mainboard. Therefore, you do not need to reset the jumpers unless you require special adjustments as any of the following cases:

1. Clear CMOS
2. CPU Clock Setting
3. Keyboard power on Setting


For first-time DIY system builders, we recommend that you do not change the default jumper settings if you are not totally familiar with the mainboard configuration procedures. The factory-set default settings are tuned for optimum system performance. For the advanced users who wish to customize their system, section 3.2 Jumper Settings will provide detailed information on how to configure your mainboard manually.

Step 3

Install DDR SDRAM System Memory

To insert memory , insert DDR SDRAM memory module(s) in DIMM slot(s). Note that DDR SDRAM modules are directional and will not go in the DIMM slots unless properly oriented. After the module is fully inserted into the DIMM slots, lift the chips of both sides of the DIMM slot to lock the module in place.

DDR SDRAM



Step 4

Install Internal Peripherals in System Case

Before you install and connect the mainboard into your system case, we recommend that you first assemble all the internal peripheral devices into the computer housing, including but not limited to the hard disk drive (IDE/HDD), floppy disk drive (FDD), CD-ROM drive, and ATX power supply unit. This will greatly facilitate in making the connections to the mainboard described below.


To install IDE & FDD drives, follow this procedure:

1. Set the required jumpers on each device according to the instructions provided by the manufacturer. (IDE devices, HDD, and CD-ROM, have to set jumpers to Master or Slave mode depending on whether you install more than one device of each kind.)
2. Connect IDE cable and FDD cable on the back-panel of the internal peripheral devices to the corresponding headers on board. Note that the cable should be oriented with its colored stripe (usually in red or magenta) connected to pin#1 both on the mainboard IDE or FDD connector and on the device as well.
3. Connect an available power cable from your system power supply unit to the back-panel of each peripheral device. Note that the power cable is directional and cannot fit in if not properly positioned.

Step 5

Mount the Mainboard on the Computer Chassis

1. You may find that there are a lot of different mounting hole positions both on your computer chassis and on the mainboard. To choose correct mounting holes, the key point is to keep the back-panel of the mainboard in a close fit with your system case, as shown below.



2. After deciding on the proper mounting holes, position the studs between the frame of the chassis and the mainboard. The studs are used to fix the mainboard and to keep a certain distance between the system chassis and the mainboard, in order to avoid any electrical shorts between the board and the metal frame of the chassis. (If your computer case is already equipped with mounting studs, you will need to tighten screws to attach the mainboard.)


Note:

1. In most computer housings, you will be able to find 4 or more attachment points to install mounting studs and then fix the mainboard. If there aren't enough matching holes, then make sure to install at least 4 mounting studs to ensure proper attachment of the mainboard.
2. There are two rubber pads attached on the solder-side of the mainboard. It prevents the mainboard damaged by the improper force while installing devices such as IDE cable, DIMM modules. You may also move the rubber pad's position varies with your chassis design.

Step 6

Connect Front Panel Switches/LEDs/USB

You can find there are several different cables already existing in the system case and originating from the computer's front-panel devices (HDD LED, Power LED, Reset Switch, Audio Line-out, Microphone-in, or USB devices etc.) These cables serve to connect the front-panel switches, LEDs, and USB connectors to the mainboard's front-panel connectors group, as shown below.






PANEL 1

1. MIC IN
2. GND
3. VCC MIC
4. +5V Audio
5. Line Out(R)
6. Line Out(R)
7. NC
8. Empty
9. Line Out(L)
10. Line Out(L)

PANEL 2


- 11.HDD_LED(HD_LED)
12. Green LED (SP_LED)
- 13.Reset Switch(RST)
- 14.Power Switch (PW_BN)
- 15.Extend USB headers(USB2)




Step 7

Connect IDE and Floppy Disk Drives

1. IDE cable connector




2. Floppy cable connector




Step 8

Connect Other Internal Peripherals

1. CD-IN connectors




2. IR Header



Step 9

Connect the Power Supply


1. System power connectors




Step 10

Install Add-on Cards in Expansion Slots


1. Accelerated Graphics Port (AGP) Card



2. PCI Card




3. CNR Card




Step 11

Connect External Peripherals to Back-Panel

You are now ready to put the computer case back together and get on to the external peripherals connections to your system's back-panel.



1. PS/2 Mouse and PS/2 Keyboard
2. Parallel Port
3. COM1 Port
4. VGA Port
5. USB1/2 Ports
6. USB3/4 Ports
7. LAN Port(MV43VN Only)
8. Audio Line-In Port
9. Audio Line-Out Port
10. Audio Mic-In Port



Step 12

First Time System Boot Up

To assure the completeness and correctness of your system installation, you may check the above installation steps once again before you boot up your system for the first time.

1. Insert a bootable system floppy disk (DOS 6.2x, Windows 95/98/NT, or others) which contains FDISK and FORMAT utilities into the FDD.
2. Turn on the system power.
3. First, you must use the FDISK utility to create a primary partition of the hard disk. You can also add an extended partition if your primary partition does not use all of the available hard disk space. If you choose to add an extended partition, you will have to create one or more logical partitions to occupy all the space available to the extended partition. The FDISK utility will assign a drive letter (i.e., C:, D:, E:,...) to each partition which will be shown in the FDISK program. After FDISK procedure, reboot your system by using the same system floppy disk.

Note: DOS 6.2x and Windows 95A can only support up to 2.1GB of HDD partition. If you use the FDISK utility with one of the operating systems mentioned above, you can only install your HDD into partitions no larger than 2.1GB each.

4. Now, use the FORMAT utility to format all the partitions you've created. When formatting the primary partition (C:), make sure to use the `FORMAT C: /S` command.

Note: `FORMAT C: /S` can transfer all the necessary system files into the primary partition of your hard disk. Then, your HDD will become a bootable drive.

5. Install all the necessary drivers for CD-ROM, Mouse, etc.
6. Setup the complete operating system according to your OS installation guide.

Step 13

Install Drivers & Software Components

Please note that all the system utilities and drivers are designed for Win 9x/2000/ME/NT operating systems only. Make sure your operating system is already installed before running the drivers installation CD-ROM programs.

1. Insert the MV43V/MV43VN bundled CD-ROM into your CD-ROM drive. The autorun program will display the drivers main installation window on screen.
2. Choose "Install Mainboard MV43V Driver" bar to run into sub- menu for MV43V setup.
3. Choose "Install Mainboard MV43VN Driver" bar to run into sub- menu for MV43VN setup.
4. Choose "Install VIA Chipset Driver" and complete it.
5. Choose "Install VGA Device Driver" and complete it.
6. Choose "Install Audio Driver" and complete it.
7. Choose "Install USB2.0 Driver" and complete it.
8. Choose "Install LAN Driver" and complete it.(MV43 VN Only)
9. Return to the main installation window and exit from the auto-run drivers installation program.

3.2 Jumper Settings

Several hardware settings are made through the use of mini jumpers to connect jumper pins on the mainboard. Pin #1 could be located at any corner of each jumper, you just find the location with a white right angle which stands for pin 1#. There are several types of pin 1# shown as below:

3-pin and multi (> 3) pin jumpers shown as following:

Pin #1 to the left:



Pin #1 on the top:





Pin #1 to the right:



Pin #1 on the bottom:




Jumpers with two pins are shown as  for Close [On] or  for Open [Off]. To Short jumper pins, simply place a plastic mini jumpers over the desired pair of pins.

Caution!

1. Do not remove the mainboard from its antistatic protective packaging until you are ready to install it.
2. Carefully hold the mainboard by its edges and avoid touching its components. When putting the mainboard down, place it on top of its original packaging film, on an even surface, and components side up.
3. Wear an antistatic wrist strap or take other suitable measures to prevent electrostatic discharge (ESD) whenever handling this equipment.

Jumpers & Connectors Guide

Use the mainboard layout on page 11 to locate CPU socket, memory banks, expansion slots, jumpers and connectors on the mainboard during the installation. The following list will help you to identify jumpers, slots, and connectors along with their assigned functions:



CPU/Memory/Expansion Slots

- | | |
|-----------|--|
| Socket478 | : CPU Socket for Pentium 4 processors |
| DDR1/2 | : Two DIMM Slots for 64, 128, 256, 512 MB, and 1GB of 2.5V DDR SDRAM
(The total installed memory does not exceed 2GB) |
| AGP | : One AGP (Accelerated Graphics Port) Slot |
| PCI | : Two 32-bit PCI Expansion Slots |
| CNR | : Communication Network Riser slot |

Jumpers

- | | | |
|-----------|-------------|-----------------------------|
| A1 | JBAT1 | : Clear CMOS setting |
| A2 | JP1A1/JP1B1 | : CPU Clock setting |
| A3 | JP2 | : Keyboard Power On setting |

Back Panel Connectors

- | | | |
|------------|----------|--------------------------------------|
| B1 | KB | : PS/2 keyboard port |
| B1 | MS | : PS/2 mouse port |
| B2 | PRINTER | : Parallel port (DB25 female) |
| B3 | COM1 | : Serial port 1 |
| B4 | VGA | : VGA Port |
| B5 | USB | : 2 USB (Universal Serial Bus) ports |
| B6 | LAN | : RJ45 LAN Port (MV43VN Only) |
| B7 | USB | : 2 USB (Universal Serial Bus) ports |
| B8 | LINE-IN | : Line-In Port |
| B9 | LINE-Out | : Line-Out Port |
| B10 | MIC-IN | : Mic-In Port |

Front Panel Connectors

- | | | |
|-----------|--------|--|
| C1 | HD_LED | : IDE drive active LED |
| C2 | SP_LED | : Green LED |
| C3 | RST | : Hardware reset switch |
| C4 | PW_BN | : ATX power on/off momentary type switch |
| C5 | SPK1 | : Speaker Connector |
| C6 | USB2 | : Extended USB Header |

Internal Peripherals Connectors

- | | | |
|-----------|------|--|
| D1 | FDC | : Floppy disk drive interface |
| D1 | IDE1 | : IDE primary interface (Dual-channel) |
| D1 | IDE2 | : IDE secondary interface (Dual-channel) |

Other Connectors

- Ⓔ1 CN5/PJ1 : ATX power connectors
- Ⓔ2 CPU FAN : CPU fan connector
- Ⓔ2 SYSTEM FAN : System fan connector
- Ⓔ3 SIR1 : IR header
- Ⓔ4 CD2 : Onboard Audio Connector
- Ⓔ5 PANEL1 : Front-Panel Audio Line_Out/ Mic_In connector

Jumpers

A1 Clear CMOS Setting (JBAT1)


JBAT1 is used to clear CMOS data. Clearing CMOS will result in the permanently erasing previous system configuration settings and the restoring original (factory-set) system settings.



Pin 1-2 (Default)



Pin 2-3 (Clear CMOS)



- Step 1. Turn off the system power (PC-> Off).
- Step 2. Remove ATX Power cable from ATX Power connector.
- Step 3. Remove jumper cap from JBAT1 pins 1-2.
- Step 4. Place the jumper cap on JBAT1 pin 2-3 for a few seconds.
- Step 5. Return the jumper cap to pin 1-2.
- Step 6. Plug ATX Power cable into ATX Power connector.
- Step 7. Turn on the system power (PC-> On).

A2 CPU Clock Setting (JP1A1/JP1B1)

This jumper enables user to select CPU frequency.

JP1A1 JP1B1



JP1A1 (Pin1-2)/


JP1B1 (Pin2-3)(100MHz)

JP1A1 JP1B1



JP1A1 (Pin2-3)/

JP1B1 (Pin1-2)(133MHz)



A3 Keyboard Power On(JP2)


This jumper enables any keyboard activity to power up a system which is previously in a standby or sleep state.



Disabled
Short Pins 1-2 (5V)




Enabled
Short Pins 2-3 (5VSB)



Back-Panel Connectors


B1 PS/2 Keyboard & PS/2 Mouse Connectors

Two 6-pin female PS/2 keyboard & Mouse connectors are located at the rear panel of the mainboard. Depending on the computer housing you use (desktop or tower), the PS/2 Mouse connector is situated at the top of the PS/2 Keyboard connector when the mainboard is laid into a desktop, as opposed to a tower where the PS/2 Mouse connector is located at the right of the PS/2 Keyboard's. Plug the PS/2 keyboard and mouse jacks into their corresponding connectors.




B2 Parallel Port Connector

One DB25 female parallel connector is located at the rear panel of the mainboard. Plug the connection cable from your parallel device (printer, scanner, etc.) into this connector.




B3 COM1 Port Connector

This mainboard can accommodate one serial device on COM1. Attach a serial device cable to the DB9 serial port COM1 at the back-panel of your computer.




B4 VGA Connector

One 15-pin VGA connector is located at the rear panel of the mainboard.



B5 USB1/USB2 Port Connectors


This mainboard offers 2 USB ports on back panel. Plug each USB device jack into an available USB1/USB2 connector.



B6 LAN Port Connector(MV43VN Only)


This mainboard can accommodate one device on LAN.

Attach a 10/100 baseT cable to the RJ45 at the back-panel of your computer.




B7 USB3/USB4 Port Connectors

This mainboard offers 2 USB ports on back panel. Plug each USB device jack into an available USB3/USB4 connector.




B8 Line-In Port Connector

Line-In is a stereo line-level input port that accepts a 1/8-inch TRS stereo plug. It can be used as a source for digital sound recording, a source to be mixed with the output, or both.




B9 Line-Out Port Connector

Line-Out is a stereo output port through which the combined signal of all internal and external audio sources on the board is output. It can be connected to 1/8-inch TRS stereo headphones or to amplified speakers.



B10 Mic-In Port Connector


Mic-In is a 1/8-inch jack that provides a mono input. It can use a dynamic mono or stereo microphone with a resistance of not more than 600 Ohms.



Front-Panel Connectors

HDD LED Connector (HD_LED)


Attach the connector cable from the IDE device LED to the 2-pin (HD_LED) header. The HDD LED lights up whenever an IDE device is active.



Note: Please notice all the LED connectors are directional. If your chassis's LED does not light up during running, please simply change to the opposite direction.


Green LED Connector (SP_LED)

The Green-LED(SP_LED) indicates that the system is currently in one of the power saving mode(Doze/Standby/Suspend). When the system resumes to normal operation mode, the Green LED will go off. Attach a 2-pin Green LED cable to Green LED header.




③ Hardware Reset Connector (RST)

Attach the 2-pin hardware reset switch cable to the (RST) header. Pressing the reset switch causes the system to restart.







④ ATX Power On/Off Switch Connector (PW_BN)


The Power On/Off Switch is a momentary type switch used for turning on or off the system ATX power supply. Attach the connector cable from the Power Switch to the 2-pin (PW_BN) header on the mainboard.



⑥ Speaker Connector (SPK1)











Attach the PC speaker cable from the case to the 4-pin speaker connector (SPK1).


Pins Assignment:	
	1
	2
	3
	4
1 = SPKR	
2 = NC	
3 = GND	
4 = + 5V	



⑥ Extended USB Header (USB2)

The mainboard has USB ports installed on the rear edge I/O port array. Some computer cases have a special module that mounts USB ports at the front of the case. If you have this kind of case, use auxiliary USB cable to connect the front-mounted ports to the mainboard.

2	4	6	8	10
				
				
1	3	5	7	9



Pins Assignment:


1 = VERG_FP_USBPWR0	2 = VERG_FP_USBPWR0
3 = USB_FP_P0-	4 = USB_FP_P1-
5 = USB_FP_P0+	6 = USB_FP_P1+
7 = GND	8 = GND
9 = KEY	10 = USB_FP_OC0(Overcurrent signal)

Internal Peripherals Connectors

Enhanced IDE and Floppy Connectors

The mainboard features two 40-pin dual-channel IDE device connectors (IDE1/IDE2) providing support for up to four IDE devices, such as CD-ROM and Hard Disk Drives (H.D.D.).

This mainboard also includes one 34-pin floppy disk controller (FDC) to accommodate the Floppy Disk Drive (FDD). Moreover, this mainboard comes with one 80-pin ATA 133/100/66/33 ribbon cable to connect to IDE H.D.D. and one 34-pin ribbon cable for F.D.D. connection.




Important: Ribbon cables are directional, therefore, make sure to always connect with the red cable stripe on the same side as pin #1 of the IDE1/IDE2 or FDC connector on the mainboard.

☞ Other Connectors

④ ATX Power Supply Connector (CN5/PJ1)

This motherboard uses 20-pin (CN5) Pentium 4 standard ATX power header, and other PJ1 with 2x2-pin + 12V PC ATX power supply headers.

Please make sure you plug in the right direction.



A traditional ATX system should remain at power off stage when AC power resumes from power failure. In such case, if there is no an UPS to keep power-on, the kind of design is inconvenient for a network server or workstation.

However, this motherboard implements an AC Power Auto Recovery function to solve this problem. You may enable the function "Restore On AC/Power Loss" that is under sub-menu of Power Management Setup through BIOS setup program.

Note 1: The ATX power connector is directional and will not go in unless the guides match perfectly making sure that pin#1 is properly positioned.



Note 2: Make sure the latch of the ATX power connector clicks into place to ensure a solid attachment.

Note 3: Your ATX power supply must be supplied to ACPI + 5V standby power and at least 720mA compatible.

Note 4: Make sure your power supply have enough power for higher speed processor installed.

② CPU and System Fan connectors (CPU-FAN, SYSTEM-FAN)


The mainboard provides two onboard 12V cooling fan power connectors to support CPU and System cooling fans.



Note: Both cable wiring and type of plug may vary, which depends on the fan maker. Keep in mind that the red wire should always be connected to the +12V header and the black wire to the ground (GND) header.


③ IR Header (SIR1)

The mainboard supports a Serial Infrared (SIR) data port. Infrared ports allow the wireless exchange of information between your computer and similarly equipped devices such as printers, laptops, Personal Digital Assistants (PDAs), and other computers.




Pins Assignment:

1 = NC	2 = KEY
3 = +5V	4 = GROUND
5 = IRTX	6 = IRRX



E4 Audio CD_IN Headers (CD2)

Use the audio cable provided with the CD-ROM/DVD drive to connect to the mainboard CD-in connector CD2.




Pins Assignment:(CD2)

1 = CD IN L

2 = GND


3 = GND

4 = CD IN R



E5 Front-Panel Microphone and Line_out Header (PANEL1)

This header allows users to install auxiliary front-oriented microphone and line-out ports for easier access. Either the Mic and Line_out connector on back-panel or Panel1 header are available at the same time. If you would like to use this Panel1 header on front-panel, please remove all jumpers from PANEL1 and install your special Extra Mic / Line_out cable instead.



Two mini jumpers must be set on pin5-6 and pin9-10 when the header is not used.

Pins Assignment:

1 = MIC In

2 = GND

3 = VCCMIC

4 = + 5V Audio

5 = Line Out(R)


6 = Line Out(R)

7 = NC

8 = Empty

9 = Line Out(L)

10 = Line Out(L)



3.3 System Memory Configuration

The MV43V/MV43VN mainboard has two 184-pin DIMM slots that allow you to install from 64MB up to 2GB of system memory.

Each 184-pin DIMM (Dual In-line Memory Module) slot can accommodate 64MB, 128MB, 256MB, 512MB, and 1GB of PC1600/PC2100 compliant 2.5V single or double side DDR SDRAM modules. DIMM slots are arranged in two banks, each memory bank made of one bank and providing a 64-bit wide data path.

Install Memory:

Install memory in any or all of the slots and in any combination shown as follows.

DDR SDRAM

DIMM Slot	Memory Modules	Module Quantity
DDR 1	64MB, 128MB, 256MB, 512MB and 1GB 184-pin 2.5V DDR SDRAM DIMM	x 1
DDR 2	64MB, 128MB, 256MB, 512MB and 1GB 184-pin 2.5V DDR SDRAM DIMM	x 1

Note: *The total installed memory does not exceed 2GB.*

Note: You do not need to set any jumper to configure memory since the BIOS utility can detect the system memory automatically. You can check the total system memory value in the BIOS Standard CMOS Setup menu.

Upgrade Memory:

You can easily upgrade the system memory by inserting additional DRAM modules in available DIMM slots. The total system memory is calculated by simply adding up the memory in all DIMM slots. After upgrade, the new system memory value will automatically be computed and displayed in the field "Standard CMOS Setup" of BIOS setup program.

4 SOFTWARE UTILITY

4.1 Mainboard CD Overview

Note: The CD contents attached in MV43V/MV43VN mainboard are subject to change without notice.

To start your mainboard CD disc, just insert it into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click or run D:\Autorun.exe (assuming that your CD-ROM drive is drive D:)

Navigation Bar Description:

- ☞ Install Mainboard MV43V Driver- Installing VIA Chipset, VGA, Audio, USB2.0 drivers.
- ☞ Install Mainboard MV43VN Driver- Installing VIA Chipset, VGA, Audio, USB2.0, LAN drivers.
- ☞ Manual - MV43V/MV43VN Series mainboard user's manual in PDF format.
- ☞ Link to Shuttle Homepage - Link to shuttle website homepage.
- ☞ Browse this CD - Allows you to see contents of this CD.
- ☞ Quit - Close this CD.



4.2 Install Mainboard Software

Insert the attached CD into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on Autorun icon in My Computer to bring up Shuttle Mainboard Software Setup screen.

Select using your pointing device (e.g. mouse) on the "Install Mainboard MV43V Driver" or "Install Mainboard MV43VN Driver" bar to run into sub-menu.

The Mainboard MV43V Driver include:

- [4.2.A] Install VIA Chipset Driver
- [4.2.B] Install VGA Device Driver
- [4.2.C] Install Audio Driver
- [4.2.D] Install USB2.0 Driver



The Mainboard MV43VN Driver include:

- [4.2.A] Install VIA Chipset Driver
- [4.2.B] Install VGA Device Driver
- [4.2.C] Install Audio Driver
- [4.2.D] Install USB2.0 Driver
- [4.2.E] Install LAN Driver (MV43VN Only)



4.2.A Install VIA Chipset Driver

Select using your pointing device (e.g. mouse) on the "Install VIA Chipset Driver" bar to install VIA chipset driver.



MV43V



MV43VN

Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.B Install VGA Driver

Select using your pointing device (e.g. mouse) on the "Install VGA Device Driver" bar to install VGA driver.



MV43V



MV43VN

Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.C Install Audio Driver

Select using your pointing device (e.g. mouse) on the "Install Audio Driver" bar to install AC'97 Audio driver.



MV43V




MV43VN

Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.D Install USB2.0 Driver

Select using your pointing device (e.g. mouse) on the "Install USB2.0 Driver" bar to install USB2.0 driver.



MV43V



MV43VN

Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.2.E Install LAN Driver(MV43VN Only)

Select using your pointing device (e.g. mouse) on the “Install LAN Driver” bar to install LAN driver.



MV43VN

Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.3 View the User's Manual

Insert the attached CD into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on AutoRun icon in My Computer to bring up Shuttle Mainboard Software Setup screen.

Select using your pointing device (e.g. mouse) on the "Manual" bar.



Then Online Information windows will appear on your screen. Click on the "Install Acrobat Reader" bar if you need to install acrobat reader.



Then click on "MV43V/MV43VN Manual" bar to view user's manual.

5 BIOS SETUP

MV43V/MV43VN BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in battery-backed RAM so that it retains the Setup information even if the system power is turned off.

The system BIOS is managing and executing a variety of hardware related functions in the system, including:

System date and time

Hardware execution sequence

Power management functions

Allocation of system resources

5.1 Enter the BIOS

To enter the BIOS (Basic Input / Output System) utility, follow these steps:

- Step 1. Power on the computer, and the system will perform its POST (Power-On Self Test) routine checks.
- Step 2. As you see the message "Hit F2 if you want to run setup.", press <F2> key immediately.


Note 1. If you miss the train (the message disappears before you can respond) and you still wish to enter BIOS Setup, restart the system and try again by turning the computer OFF and ON again or by pressing the <RESET> switch located at the computer's front panel. You may also reboot by simultaneously pressing the <Ctrl>, <Alt>, keys.

- Step 3. As you enter the BIOS program, the CMOS Setup Utility will prompt you the Main Menu, as shown in the next section.

Please be noted that the content of this manual is subject to change without notice in advance.

5.2 The Main Menu

Once you enter the AMIBIOS(tm) CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.



Note that a brief description of each highlighted selection appears at the bottom of the screen.

Standard CMOS Setup

This setup page includes all items in a standard compatible BIOS.

Advanced Setup

This setup page includes all items of Advanced features.

Power Management Setup

This setup page includes all items of Power Management features.

PCI / Plug and Play setup

This page sets some of the parameters for devices installed on the PCI bus and devices that use the system plug and play capability.

Load Optimal Settings

Optimal settings load the values required by the System for the fail-safe default values. However, you can change the parameter through each Setup Menu.

Load Best Performance Settings

Fail Safe settings load the values required by the system for the best performance and default values. However, you can change the parameter through each Setup Menu.

Features Setup

This setup page includes all items of peripheral features.

CPU PnP Setup

This setup page includes all items of CPU PnP features.

Hardware Monitor

This setup page includes all items of Hardware Monitor features.

Change Password

Change, set, or disable password. It allows you to limit access to the system and Setup, or just to Setup.

Exit

Save all the CMOS values changed to CMOS and exit setup.



Standard CMOS Setup

The items in Standard CMOS Setup Menu are divided into 8 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

AMIBIOS SETUP - STANDARD CMOS SETUP									
(C)2000 American Megatrends, Inc. All Rights Reserved									
Date (mm/dd/yyyy): Wed Apr 02, 2003									
Time (hh/mm/ss) : 20:55:45									
	Type	Size	Cyl	Head	WPcom	Sec	Mode	Mode	Mode
Pri Master	:Not Installed								
Pri Slave	:Not Installed								
Sec Master	:Not Installed								
Sec Slave	:Not Installed								
Floppy Drive A: Not Installed									
Floppy Drive B: Not Installed									
Month: Jan - Dec							ESC : Exit		
Day: 01 - 31							↑↓ : Select Item		
Year: 1980 - 2099							PU/PD/+/- : Modify		
							(Shift)F2 : Color		
							F3 : Detect All HDD		

Date

<mm> <dd> <yyyy>

Set the system date. Note that the 'Day' automatically changes when you set the date.

Time

<hh> : <mm> : <ss>

The time is converted based on the 24-hour military-time clock. For example, 5 p.m. is 17:00:00.

Pri Master

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

Pri Slave

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

Sec Master

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

Sec Slave

Options are in its sub menu.

Press <Enter> to enter the sub-menu of detailed options.

Floppy Drive A/ Floppy Drive B

Select the type of floppy disk drive installed in your system.

- The choice: None, 360K, 5.25 in, 1.2M, 5.25 in, 720K, 3.5 in, 1.44M, 3.5 in, or 2.88M, 3.5 in.



ADVANCED SETUP

This section allows you to configure your system for basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing, and security.

AMIBIOS SETUP - ADVANCED SETUP			
(C)2000 American Megatrends, Inc. All Rights Reserved			
Quick Boot	Disabled	Manual AGP Comp. Driving	00
1st Boot Device	Disabled	AGP Aperture Size	256MB
2nd Boot Device	Disabled	Auto Detect DIMM/PCI Clk	Disabled
3rd Boot Device	Disabled	CLK GEN Spread Spectrum	Disabled
Try Other Boot Devices	Yes	Onboard Lan Boot Rom	Disabled
S.M.A.R.T. for Hard Disks	Disabled	Hyper Threading Function	Disabled
BootUp Num-Lock	Off		
Floppy Drive Swap	Disabled		
Floppy Drive Seek	Disabled		
Password Check	Setup		
Boot To OS/2	No		
L2 Cache	Disabled		
System BIOS Cacheable	Disabled		
DRAM Timing by SPD	Disabled		
DRAM Frequency	133MHz		
DRAM CAS# Latency	2.5	ESC : Quit	↑↓ : Select Item
DRAM Bank Interleave	Disabled	F1 : Help	PU/PD/+/- : Modify
AGP Mode	4x	F5 : Old Values (Shift)	F2 : Color
AGP Comp. Driving	Manual	F6 : Load Optimal Values	
		F7 : Load Best Performance Values	

Quick Boot

If you enable this item, the system starts up more quickly by elimination of some of the power on test routines. Quick Power On Self Test (Enabled)

- The choice: Enabled or Disabled .

1st/2nd/3rd Boot Device

Use these items to determine the device order the computer uses to look for an operating system to load at start-up time.

- The choice: CDROM, SCSI, NETWORK, BBS-0, BBS-1, BBS-2, BBS-3, USB FDD, USB CDROM, USB HDD, USB LS120, ZIP MO, Disabled, IDE-0, IDE-1, IDE-2, IDE-3, Floppy, ZIP A:/LS120, ATAPI ZIP C: .

Try Other Boot Devices

If you enable this item, the system will also search for other boot devices if it fails to find an operating system from the first two locations. Boot Up

- The choice: Yes or No.

S.M.A.R.T. for Hard Disks

Enable this item if any IDE hard disks support the S.M.A.R.T. (Self-Monitoring, Analysis and Reporting Technology) feature.

- The choice: Enabled or Disabled .

BootUp Num-Lock

This item determines if the Num Lock key is active or inactive at system start-up time.

- The choice: Off or On .

Floppy Drive Swap

If you have two diskette drives installed and you enable this item, drive A becomes drive B and drive B becomes drive A.

- The choice: Enabled or Disabled .

Floppy Drive Seek

If you enable this item, your system will check all floppy disk drives at start up. Disable this item unless you are using an old 360KB drive.

- The choice: Enabled or Disabled .

Password Check

If you have entered a password for the system, use this item to determine, if the password is required to enter the Setup Utility (Setup) or required both at start-up and to enter the Setup Utility (Always).

- The choice: Setup or Always.

Boot to OS/2

Enable this item if you are booting the OS/2 operating system and you have more than 64MB of system memory installed.

- The choice: YES or No.

L2 Cache

Leave these items enabled since all the processors that can be installed on this board have internal L1/L2 cache memory.

- The choice: Enabled or Disabled .

System BIOS Cacheable

If you enable this item, a segment of the system BIOS will be copied to main memory for faster execution.

- The choice: Enabled or Disabled .

SDRAM Timing By SPD

This item allows you to enable or disable the SDRAM timing defined by the Serial Presence Detect electrical.

- The choice: Enabled or Disabled .

SDRAM Frequency

This item determines frequency of SDRAM memory.

- The choice: Auto, 100MHz, 133 MHz.

SDRAM CAS# Latency

This item determines the operation of SDRAM memory CAS (column address strobe). It is recommended that you leave this item at the default value. The 2T setting requires faster memory that specifically supports this mode.

- The choice: 3, 2.

SDRAM Bank Interleave

Enable this item to increase SDRAM memory speed. When enabled, separate memory banks are set for odd and even addresses and the next byte of memory can be accessed while the current byte is being refreshed.

- The choice: Enabled or Disabled .

AGP Mode

This item provides the OnBoard VGA mode with three options of 1,2, 4 multiplied frequency.

- The choice: 4X, 2X, 1X .

AGP Comp. Driving

Use this item to signal driving current on AGP cards to auto or manual. Some AGP cards need stronger than normal driving current in order to operate. We recommend that you set this item to the default.

- The choice: Auto or Manual .

Manual AGP Comp. Driving

When AGP Driving is set to Manual, use this item to set the AGP current driving value.

- The choice: Auto, Manual.

AGP Aperture Size

This item defines an AGP for the graphics. Leave this item at the default value 64MB.

- The choice: 4MB,8MB,16MB,32MB,64MB,128MB,256MB.

Auto Detect DIMM/PCI CLK

When this item is enabled, BIOS will disable the clock signal of free DIMM/PCI slots.

- The choice: Enabled or Disabled.

CLK GEN Spread Spectrum

Use this item to set the system bus spread spectrum for the installed processor.

- The choice: Enabled or Disabled.

Onboard Lan Boot Rom

Use this item to enable/disable onboard Lan Boot Rom.

- The choice: Enabled or Disabled.

Hyper Threading Function

This item is dependent when your system supports the Hyper-Threading technology. If your system doesn't have the Hyper-Threading technology installed, this item is hidden.

- The choice: Enabled or Disabled.



Power Management Setup

AMIBIOS SETUP - POWER MANAGEMENT SETUP	
(C)2000 American Megatrends, Inc. All Rights Reserved	
ACPI Aware O/S	Yes
Power Management	Disabled
Suspend Time Out (Min.)	Disabled
Hard Disk Time Out (Min.)	Disabled
PWR Button < 4 secs	Delay 4 secs
Restore on AC/Power Loss	Power Off
Resume On RTC Alarm	Disabled
RTC Alarm Date	Every Day
RTC Alarm Hour	00
RTC Alarm Minute	00
RTC Alarm Second	00
LAN/Ring Power On	Disabled

ESC : Quit	↑↓ : Select Item
F1 : Help	PU/PD/+/- : Modify
F5 : Old Values	(Shift)F2 : Color
F6 : Load Optimal Values	
F7 : Load Best Performance Values	

ACPI Aware O/S

This item supports ACPI (Advanced Configuration and Power management Interface). Use this item to enable or disable the ACPI feature.

- The choice: Yes or No.

Power Management

Use this item to enable or disable a power management scheme. If you enable power management, you can use the items below to set the power management operation. Both APM and ACPI are supported.

- The choice: Enabled or Disabled .

Suspend Time Out

This sets the timeout for Suspend mode in minutes. If the time selected passes without any system activity, the computer will enter power-saving Suspend mode.

- The choice: Enabled or Disabled .

Hard Disk Time Out

This item sets up the timeout to power down the hard disk driver, if there is no hard disk activity after passing the preset period of time

- The choice: Enabled or Disabled .

PWR Button < 4 secs

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state when the system has "hung".

- The choice: Instant-Off or Delay 4 Sec. .

Restore On AC/Power Loss

This allow you to set whether you want your system to reboot after power has been interrupted.

- The choice: Power off, Power on, or Last state.

Resume On RTC Alarm / Date / Hour / Minute / Second

The system can be turned off with a software command. If you enable this item, the system can automatically resume at a fixed time based on the system's RTC (realtime clock). Use the items below this one to set the date and time of the wake-up alarm. You must use an ATX power supply in order to use this feature.

- The choice: Enabled or Disabled .

LAN/Ring Power On

The system can be turned off with a software command. If you enable this item, the system can automatically resume if there is an incoming call on the Modem. You must use an ATX power supply in order to use this feature.

- The choice: Enabled or Disabled .



PCI /Plug and Play Setup

AMIBIOS SETUP - PCI / PLUG AND PLAY SETUP	
(C)2000 American Megatrends, Inc. All Rights Reserved	
Plug and Play Aware O/S	No
Share Memory Size	None
Primary Graphics Adapter	PCI
Allocate IRQ to PCI VGA	Yes
PCI IDE BusMaster	Disabled

ESC : Quit	↑↓ : Select Item
F1 : Help	PU/PD/+/- : Modify
F5 : Old Values	(Shift)F2 : Color
F6 : Load Optimal Values	
F7 : Load Best Performance Values	

Plug and Play Aware O/S

Enable this item if you are using an O/S that supports Plug and Play such as Windows 95 or 98.

- The choice: Yes or No.

Share Memory Size

This item lets you allocate a portion of the main memory for the onboard VGA display application with three options of 8/16/32MB.

- The choice: 8MB,16MB,32MB or None.

Primary Graphics Adapter

This item indicates if the primary graphics adapter uses the PCI or the AGP bus. The default AGP setting still lets the onboard display work and allows the use of a second display card installed in an AGP slot.

- The choice: AGP/Onboard or PCI.

Allocate IRQ for PCI VGA

If this item is enabled, an IRQ will be assigned to the PCI VGA graphics system. You set this value to No to free up an IRQ.

- The choice: Yes or No.

PCI IDE BusMaster

This item enables or disables the DMA under DOS mode. We recommend you to leave this item at the default value.

- The choice: Enable or Disable.



Load Optimal Settings

When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

Load Optimal settings (Y/N) ? N

Pressing 'Y' the Setup Utility loads a set of fail-safe default values. These default values are not very demanding and they should allow your system to function with most kinds of hardware and memory chips.



Load Best Performance Settings

When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

Load best performance settings (Y/N) ? N

Pressing 'Y' the Setup Utility loads a set of best-performance default values. These default values are quite demanding and your system might not function properly if you are using slower memory chips or other low-performance components.



Features Setup

AMIBIOS SETUP - FEATURES SETUP	
(C)2000 American Megatrends, Inc. All Rights Reserved	
OnBoard FDC	Auto
OnBoard Serial PortA	Auto
OnBoard IR Port	Disabled
OnBoard Parallel Port	Auto
Parallel Port Mode	SPP
Parallel Port IRQ	Auto
Parallel Port DMA	N/A
OnBoard Game Port	Reserved
OnBoard MIDI Port	Reserved
MIDI Port IRQ	N/A
OnBoard IDE	Reserved
Audio Device	Auto
Modem Device	Enabled
Ethernet Device	Disabled
USB Controller	Disabled
USB Device Legacy Support	Disabled
ThumbDrive Support for DOS	Disabled
ESC : Quit ↑↓ : Select Item	
F1 : Help PU/PD/+/- : Modify	
F5 : Old Values (Shift)F2 : Color	
F6 : Load Optimal Values	
F7 : Load Best Performance Values	

OnBoard FDC

Use this item to enable or disable the onboard floppy disk drive interface.

- The choice: Enabled,Auto,Disabled .

OnBoard Serial PortA

Use this item to enable or disable the onboard COM1 serial port, and to assign a port address.

- The choice: Disabled,3F8h/COM1,2F8h/COM2,3E8h/COM3,2E8h/COM4,Auto.

OnBoard IR Port

Use this item to enable or disable the onboard infrared port, and to assign a port address.

- The choice: Disabled, ASKIR,IrDA.

OnBoard Parallel Port

Use this item to enable or disable the onboard LPT1 parallel port, and to assign a port address. The Auto setting will detect and available address.

- The choice: Auto, Disabled, 378h, 278h, or 3BCh.

Parallel Port Mode

Use this item to set the parallel port mode. You can select SPP (Standard Parallel Port), ECP (Extended Capabilities Port), EPP (Enhanced Parallel Port), or ECP + EPP.

- The choice: SPP,EPP,ECP,EPP + ECP.

Parallel Port IRQ

Use this item to assign IRQ to the parallel port.a port address.

- The choice: 7,5.

Parallel Port DMA

Use this item to assign a DMA channel to the parallel port.

- The choice: N/A.

OnBoard GAME Port

This item enables or disables the I/O address for the GAME Port.

- The choice: 201h,209h,Disabled.

OnBoard MIDI Port

Use this item to enable or disable the onboard MIDI port, and to assign a port address.

MIDI Port IRQ

Use this item to assign IRQ 7 to the parallel port.

- The choice: 10,11,5.

OnBoard IDE

Use this item to enable or disable the onboard IDE channel.

- The choice: Both,Disabled,Primary or Secondary.

Audio Device

This item enables or disables the AC'97 audio chip.

- The choice: Enable or Disable.

Modem Device

This item enables or disables the MC'97 modem chip.

- The choice: Enable or Disable.

Ethernet Device

This item enables or disables the onboard Ethernet LAN.

- The choice: Enable or Disable.

USB Controller

Use this item to select the USB ports or disabled.

- The choice: Disabled, All USB Port, USB1, USB2, USB1&2, USB3, USB1&3, USB2&3.

USB Device Legacy Support

This item allows you to enable the USB device, if you have installed a USB device on the system board.

- The choice: Disabled, No Mice, All Device.

ThumbDrive Support for DOS

This item allows user to use ThumbDrive under DOS Environment.

- The choice: Disabled, Enabled.

CPU PnP Setup

This page helps you manually configure the mainboard for the CPU. The system will automatically detect the type of installed CPU and make the appropriate adjustments to the items on this page.

AMIBIOS SETUP - CPU PnP SETUP	
(C)2000 American Megatrends, Inc. All Rights Reserved	
CPU BRAND	INTEL
CPU Type	Pentium 4
CPU Ratio	8.0x
CPU Frequency	133MHz
<div>ESC : Quit ↑↓ : Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift)F2 : Color F6 : Load Optimal Values F7 : Load Best Performance Values</div>	

CPU BRAND

This item show the Brand of CPU installed in your system.

CPU Type

This item show the Type of CPU installed in your system.

CPU Ratio

This item show the Ratio Selection of CPU installed in your system.

CPU Frequency

This item show the Frequency of CPU installed in your system.

Hardware Monitor

On mainboards that support hardware monitoring, this item lets you monitor the parameters for critical voltages, critical temperatures, and fan speeds:

AMIBIOS SETUP - HARDWARE MONITOR	
(C)2000 American Megatrends, Inc. All Rights Reserved	
-- System Hardware --	
Vcore	1.520 V
Vcc2.5V	2.544 V
Vcc3.3V	3.200 V
Vcc5V	5.134 V
+12V	11.520 V
-12V	-11.147 V
SB5V	4.999 V
VBAT	3.344 V
SYSTEM Fan Speed	0 RPM
CPU FAN Speed	0 RPM
POWER Temperature	48°C/118°F
SYSTEM Temperature	39°C/102°F
CPU Temperature	38°C/100°F
ESC : Quit ↑↓ : Select Item	
F1 : Help PU/PD/+/- : Modify	
F5 : Old Values (Shift)F2 : Color	
F6 : Load Optimal Values	
F7 : Load Best Performance Values	

System Hardware


These fields provide you with information about the systems current operating status. You cannot make changes to these fields.

The fields include

- Vcore
- Vcc2.5V
- Vcc3.3V
- Vcc5V
- + 12V
- 12V
- SB5V
- VBAT
- System Fan Speed
- CPU Fan speed
- Power Temperature
- System Temperature
- CPU Temperature

Change Password

If you highlight this item and press Enter, a dialog box appears which lets you enter a Supervisor password. You can enter no more than six letters or numbers. Press Enter after you have typed in the password. A second dialog box asks you to retype the password for confirmation. Press Enter after you have retyped it correctly. The password is then required to access the Setup Utility or for that and at start-up, depending on the setting of the Password Check item in Advanced Setup.



The screenshot shows the 'AMIBIOS SIMPLE SETUP UTILITY - VERSION 1.21.12' interface. A dialog box titled 'Enter current password:' is overlaid on the 'Load Optimal Settings' option. The background menu lists various setup options: Standard CMOS Setup, Advanced Setup, Power Management Setup, PCI / Plug and Play, Load Optimal Settings, Load Best Performance, Features Setup, CPU PnP Setup, and Hardware Monitor. At the bottom, a legend defines keyboard shortcuts: ESC for Quit, ↑↓ for Select Item, (Shift)F2 for Change Color, F5 for Old Values, F6 for Optimal values, F7 for Best performance values, and F10 for Save&Exit. The 'Change password' option is highlighted at the very bottom of the screen.

Enter Password

Type the password up to six characters, and press <Enter>. The password typed now will clear any previously entered password from CMOS memory. You will be asked to confirm the password. Type the password again and press <Enter>. You may also press <Esc> to abort the selection and not enter a password.

To disable password, just press <Enter> when you are prompted to enter password. A message will confirm the password being disabled. Once the password is disabled, the system will boot and you can enter Setup freely.

Password Disable

If you select System at Security Option of BIOS Features Setup Menu, you will be prompted in entering the password whenever the system is rebooted or you try to enter Setup. If you select Setup at Security Option of BIOS Features Setup Menu, you will be prompted only when you try to enter Setup.

Warning : Retain a record of your password in a safe place. If you forget the password, the only way to access the system is to clear CMOS, please refer to "Clear CMOS" on page 28.

Exit

Highlight this item and press <Enter> to save the changes that you have made in the Setup Utility configuration and exit the program.

Save current settings and exit (Y/N)? Y

Pressing "Y" stores the selections made in the menus of CMOS - a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

Pressing "N" to exit from Setup without storing in CMOS any change. The previous selections remain in effect. This exits from the Setup utility and restarts your computer.