

MS52P/MS52PN
Pentium 4 Processor
Based DDR MAIN BOARD
User's Manual

Shuttle® MS52P/MS52PN

Pentium 4 , 478-pin processor based DDR Mainboard Manual Version 1.0

Copyright

Copyright© 2003 by Shuttle® Inc. All Rights Reserved.

No part of this publication may be reproduced, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without prior written permission from Shuttle® Inc.

Disclaimer

Shuttle® Inc. shall not be liable for any incidental or consequential damages resulting from the performance or use of this product.

This company makes no representations or warranties regarding the contents of this manual. Information in this manual has been carefully checked for reliability; however, no guarantee is given as to the correctness of the contents. In the interest of continued product improvement, this company reserves the right to revise the manual or include changes in the specifications of the product described within it at any time without notice and without obligation to notify any person of such revision or changes. The information contained in this manual is provided for general use by the customers.

Trademarks

Shuttle is a registered trademark of Shuttle Inc.

Intel, Pentium is a registered trademarks of Intel Corporation.

SiS is a registered trademarks of SiS Corporation.

PS/2 is a registered trademark of IBM Corporation.

AWARD is a registered trademark of Award Software Inc.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

General Notice: Other product names used in this manual are ascribed to their respective owners and acknowledged.

Statement of Shuttle Mainboard via the EMI Test

Shuttle mainboards have been via the EMI test in terms of series of regulations: EN55022/ CISPR22/AS/NZS3548 Class B, EN55024 (1998/AS/NZS), EN4252.1 (1994), EN61000, ANSI C63.4 (1992), CFR47 Part 15 Subpart B, and CNS13438 (1997). The items tested are illustrated as follows:

(A) Voltage: AC 110V/60HZ & AC 230V/50HZ

(B) Tested Product Information:

Product Name: PC Mainboard

Status: Sample

Model Name: MS52PN

S/N:

CPU:

External Frequency: 100 MHz

Intel P4 1.4/1.5/1.6/1.7/1.8/1.9/2/2.2/2.4 GHz

External Frequency: 133 MHz

Intel P4 1.6/1.7/2.26/2.4/2.8/3.06 GHz

Keyboard Port: one port with 6 pins

Mouse Port: one port with 6 pins

USB 2.0 Port: two ports with 4 pins respectively

Parallel Port: one port with 9 pins

Serial Port: two ports with 9 pins respectively

MIDI/Game Port: one port with 15 pins

Line-Out & Line-In & Mic-In Ports: one port for each

DDR Memory: 256 MB *2

LAN Port: one port with 8 pins

All CPUs have completely been tested, and values offered by the worst EMI combination of CPU external frequency are listed as follows:

Test Mode	External Frequency	CPU	Case Open/Closed
1	133MHz	Pentium4 3.06GHz	Closed
2	133MHz	Pentium4 3.06GHz	Open
3	100MHz	Pentium4 2.4GHz	Closed
4	100MHz	Pentium4 2.4GHz	Open

(C) Remedy for the Tested Product & Its EMI Interference:

Remedy: N/A

EMI Interference:

Crystal: 14.318 KHz(Y1)/24.576 MHz(Y2)/32.768 MHz(Y3)/25MHz(Y4)/12MHz(Y5)

Clock Generator: CLK1/CLK2

(D) Supported Host Peripherals:

Host Peripheral	Product Name	Model Name	S/N	FCC ID
#1	Case	KF45A	N/A	
#2	Power Supply (300W)	ENP-0730 (ATX12V)	1000002885	
#3	IBM HDD (30.7GB)	91024UB	YKFY7981	3892I168
#4	MITSUMI FDD	D353M		
#5	SONY VCD Player	CDU4811	3892A291	
#6	AGP Card	Winfast Geforce 2 MX		3892C520
#7	Power Cable	Detachable and Shielded		

(G) Notices for Assembling Computers:

1. Cases should be made of iron or other metal that has good electric conductivity.
2. Cylinders in a case should be made of metal, and as having a mainboard mounted in a case, make sure screws are all utilized and fastened on a mainboard.
3. An I/O shielding should be contacted with I/O metallic parts of a mainboard.
4. Cables should appropriately be arranged and fixed in a case. Follow instructions:
 - Leave IDE cables not crossed upon CPU and SDRAM;
 - Leave power cables minimum in length, and not crossed upon a mainboard;
 - Leave CPU fan cables minimum in length, and not near CPU;
 - Leave cables on panels and other spare cables tied in a computer case.
5. Make sure an EMI shielding attached to a case has properly been installed.
6. Make sure a 5.25" or 3.5" FDD and screws are fastened to an EMI shielding.
7. Make sure a case is closely in contact with EMI connected points.
8. Make sure there is no cleft in a case which is not deformed.
9. Make sure a PCI or AGP door is bound to a case.
10. Make sure cables of other devices (fans or some others) are fixed in a case.

TABLE OF CONTENTS

WHAT'S IN THE MANUAL	5
Quick Reference	5
About This Manual	5
1 INTRODUCTION	6
1.1 TO DIFFERENT USERS	6
FIRST-TIME DIY SYSTEM BUILDER	6
EXPERIENCED DIY USER	6
SYSTEM INTEGRATOR	6
1.2 ITEM CHECKLIST	7
2 FEATURES	8
2.1 SPECIFICATIONS	8
3 HARDWARE INSTALLATION	11
3.1 STEP BY STEP INSTALLATION	11
Accessories of MS52P/MS52PN	11
STEP 1 CPU Installation	12
STEP 2 Set Jumpers	14
STEP 3 Install DDR SDRAM System Memory	14
STEP 4 Install Peripherals in System Case	15
STEP 5 Mount the Mainboard on the Computer Chassis	16
STEP 6 Connect Front Panel Switches/LEDs/Speaker/USB	17
STEP 7 Connect IDE and Floppy Disk Drives	18
STEP 8 Connect Other Internal Peripherals	18
STEP 9 Connect the Power Supply	19
STEP 10 Install Add-on Cards in Expansion Slots	20
STEP 11 Connect External Peripherals to Back Panel	21
STEP 12 First Time System Boot Up	22
STEP 13 Install Drivers & Software Components	23

3.2 JUMPER SETTINGS	24
JUMPERS & CONNECTORS GUIDE	25
<i>Jumpers</i>	
Clear CMOS Setting (JP1)	28
BIOS Write Protection (JP3)	28
<i>Back-Panel Connectors</i>	
PS/2 Keyboard & PS/2 Mouse Connectors	29
COM1 Port Connector	29
Parallel Port Connector	29
Line-out port connector	29
Line-in port connector	30
Mic-in port connector	30
GAME/MIDI port connector	30
LAN port connector	30
USB port1 / USB port2 connectors	30
<i>Front-Panel Connectors</i>	
ATX power on/off switch connector (PWRSW)	31
Green LED connector (GRN LED)	31
HDD LED connector (HDD LED)	31
Hardware reset connector (RST)	32
Speaker connectorn (SPEAKER1)	32
Front-oriented Microphone/Line-out port header (AUDIO1)	32
Extended USB headers (USB2/3)	33
<i>Internal Peripherals Connectors</i>	
Enhanced IDE and Floppy Connector	34
<i>Other Connectors</i>	
ATX Power Supply Connectors (ATX1/ATX2)	35
Audio CD_IN connectors (CDIN1/CDIN2)	35

Wake-on-Modem connector (WOM1)	36
Wake-on-Lan connector (WOL1)	36
Cooling Fan Connectors for CPU (CPUFAN1), Case (CASFAN1/ PWRFAN1)	36
IR header (IR1)	37
3.3 SYSTEM MEMORY CONFIGURATION	38
1. INSTALL MEMORY	38
2. UPGRADE MEMORY	38
4 SOFTWARE UTILITY	39
4.1 Mainboard CD Overview	39
4.2 Install Mainboard Software	40
4.3 Install VGA Device Driver	41
4.4 Install SIS AGP Driver	42
4.5 Install Audio Device Driver	43
4.6 Install LAN Driver(MS52PN only)	44
4.7 Install USB2.0 Driver	45
4.7 View the User's Manual	46
5 BIOS SETUP	47
5.1 ENTER BIOS	47
5.2 THE MAIN MENU	48
STANDARD CMOS FEATURES	50
ADVANCED BIOS FEATURES	53
ADVANCED CHIPSET FEATURES	57
INTEGRATED PERIPHERALS	59
POWER MANAGEMENT SETUP	64
PNP/PCI CONFIGURATION	68

PC HEALTH STATUS	70
FREQUENCY/VOLTAGE CONTROL	71
LOAD FAIL-SAFE DEFAULTS	72
LOAD OPTIMIZED DEFAULTS	72
SET PASSWORD	73
SAVE & EXIT SETUP	74
EXIT WITHOUT SAVING	74

WHAT'S IN THE MANUAL

Quick Reference

Hardware Installation >> Step-by-Step	Page 11
Jumper Settings >> A Closer Look	Page 25
Drivers/Software Utilities >> How to Install	Page 39
BIOS Setup >> How to Configure	Page 47

About This Manual

For First-Time DIY System Builder	Page 6
For Experienced DIY User	Page 6
For System Integrator	Page 6

1 INTRODUCTION

1.1 To Different Users

First-Time DIY System Builder

Welcome to the DIY world! Building your own computer system is not as difficult as you may think. To make your first computer DIY experience successful, right from the start, we have designed the 3.1 Hardware Installation section in a step-by-step fashion for all the first-time DIY system builders. Prior to installation, we also suggest you to read the whole manual carefully to gain a complete understanding of your new Shuttle MS52P/MS52PN mainboard.

Experienced DIY User

Congratulate on your purchase of the Shuttle MS52P/MS52PN mainboard. You will find that installing your new Shuttle MS52P/MS52PN mainboard is just easy. Bundled with an array of onboard functions, the highly-integrated MS52P/MS52PN mainboard provides you with a total solution to build the most stable and reliable system. Refer to sections 3.2 Jumper Settings and Chapter 4 Drivers/Software Utilities to find out how to get the best out of your new mainboard. Chapter 5 BIOS Setup also contains the relevant information on how to tune up your system to achieve higher performance.

System Integrator


You have wisely chosen Shuttle MS52P/MS52PN to construct your system. Shuttle MS52P/MS52PN incorporates all the state-of-the-art technology of the SiS651 Northbridge and SiS962L Southbridge chipsets from SiS. It integrates the most advanced functions you can find to date in a compact Micro ATX board.

This manual adopted in MS52P and MS52PN mainboards at the same time. The difference between MS52P and MS52PN equips with onboard LAN Controller. In the manual, if there are some standards, characters, equipment or software only appeared or adopted by MS52PN; it will be mentioned (MS52PN only).

1.2 Item Checklist:

Check all items with your MS52P/MS52PN mainboard to make sure nothing is missing. The complete package should include:

- ✴ One piece of Shuttle
MS52P/MS52PN Mainboard




- ✴ One piece of ATA133/100/66/33 Ribbon Cable




- ✴ One piece of Floppy Ribbon Cable



- ✴ One piece of twin ports USB Cable (optional)




- ✴ I/O Shielding



- ✴ MS52P/MS52PN User's Manual



- ✴ One piece of Bundled CD-ROM with containing:
 - MS52P/MS52PN user manual saved in PDF format
 - SiS Chipset driver
 - SiS AGP driver
 - AC'97 Audio Device driver
 - LAN driver (MS52PN only)
 - USB 2.0 driver
 - Award Flashing Utility



2 FEATURES

MS52P/MS52PN mainboard is carefully designed for the demanding PC user who wants high performance and maximum intelligent features in a compact package.

2.1 Specifications

★ CPU Support

Intel Pentium 4/Celeron/Hyper Threading, 478-pin processors with 400 / 533MHz FSB.

★ Chipset

Features SiS 651 N.B. and SiS 962L S.B..

★ Onboard Lan (MS52PN only)

Realtek RTL8100B, support 10Mb/s and 100Mb/s operation.

★ Jumperless CPU Configuration

Soft-configuration FSB (The FSB speed is software configurable from 100MHz to 133MHz in the Frequency/Voltage Control of BIOS setup program.)

★ AC'97 Link for Audio and Telephony CODEC

AC'97 2.2 compliant.

Spread independent PCI functions for Modem and 4 channel Audio.

★ Versatile Memory Support

Two 184-pin DIMM slots to support up to 2GB of PC1600 and PC2100 or PC2700 compliant DDR SDRAM module

★ AGP Expansion Slot

Provides one 32-bit AGP slot which supports 4x AGP devices.

★ PCI Expansion Slots

Provides three 32-bit PCI slots.

★ CNR Expansion Slot

Provides one Communication and Network Riser (CNR) slot.

★ 6 USB2.0 Interface Onboard

- 2 USB connectors on back-panel and two sets of dual USB ports header on board.

*** I/O Interface**

Provides a variety of I/O interfaces:

- 1 PS/2 mouse connector
- 1 PS/2 keyboard connector
- 1 serial port.
- 1 VGA port.
- 1 parallel port..
- 1 MIDI/GAME port.
- 2 USB ports.
- 1 LAN port.(MS52PN only)
- 1 Line-Out port.
- 1 Line-In port.
- 1 Mic-In port.

*** PCI Bus Master IDE Controller Onboard**

Two Ultra DMA 133/100/66 Bus Master Dual-channel IDE ports provide support to a maximum of four IDE devices (one Master and one Slave per channel). The IDE Bus implements data transfer speeds of up to 133/100/66/33 MB/sec and also supports Enhanced PIO Modes.

80-pin Cable Backward Compatible Legacy ATAPI Devices, ATAPI IDE CD-ROM, CD-R, CD-RW, and LS-120 Supports.

*** ATX Power Supply Connector**

ATX power supply unit can connected to the onboard 20-pin Pentium 4 standard ATX power connectors, supporting Suspend and Soft-On/Off by dual-function power button.

The Pentium 4 ATX power include one 4-pin + 12V ATX power connector.

*** Advanced Configuration and Power Interface**

Features four power saving modes: S1 (Snoop), S3 (Suspend to RAM), S4 (Suspend to DISK), and S5 (Soft-Off). ACPI provides more efficient Energy Saving Features controlled by your operating system that supports OS Direct Power Management (OSPM) functionality.

*** System BIOS**

Provides licensed Award BIOS V6.0 PG on 2Mb Flash core and supports Green PC, Desktop Management Interface (DMI).

★ Form Factor

System board conforms to Micro ATX specification.

Board dimension: 244mm x244mm.

★ Advanced Features

- Low EMI - Built in spread spectrum and automatic clock shut-off of unused PCI/SDRAMS slots to reduce EMI.
- Dual Function Power Button - The system can be in one of two states, one is Suspend mode and the other is Soft-Off mode. Pushing the power button for less than 4 seconds places the system into Suspend mode. When the power button is pressed for longer than 4 seconds, the system enters Soft-Off mode.
- Modem Ring Power-On (WOM1) - The system can be powered on automatically by the activation of modem ringing.
- Wake-on-Lan (WOL1) - The onboard WOL connector can be attached to a network card that supports this function to wake up the system via LAN.
- CPU Host/DRAM/PCI Clock Setting - This item allows users to adjust CPU Host Clock, DRAM, and PCI Clock in BIOS.
- CPU Multiplier Setting - This item allows users to adjust CPU Multiplier in BIOS.

★ Intelligent Features

- Voltage Monitoring - Monitors various voltages of key elements, such as the CPU, and other critical system voltage levels to ensure stable current passing through mainboard components.
- Fan Status Monitoring - To prevent CPU from overheating, the CPU fan is monitored for RPM (CPU Cooling FAN with RPM sensor is required.)
- Temperature Monitoring - This item allows users to make sure whether the CPU or system runs in a suitable temperature.


3 HARDWARE INSTALLATION

Before removing or installing any of these devices including CPU, DIMMs, Add-On Cards, Cables, please make sure to unplug the onboard power connector.

This section outlines how to install and configure your mainboard. Refer to the following mainboard layout to help you to identify various jumpers, connectors, slots, and ports. Then follow these steps designed to guide you through a quick and correct installation of your system.

3.1 Step-by-Step Installation

Accessories Of MS52P/MS52PN




Step 1

CPU Installation:


This mainboard supports Intel Pentium 4/Celeron , Socket 478 series CPU. Please follow the step as below to finish CPU installation.

Be careful of CPU orientation when you plug it into CPU socket.


1. Pull up the CPU socket lever and up to 90-degree angle.



2. Locate Pin 1 in the socket and look for a black dot or cut edge on the CPU upper interface. Match Pin 1 and cut edge, then insert the CPU into the socket.



-
3. Press down the CPU socket lever and finish CPU installation.



Note: If you do not match the CPU socket Pin 1 and CPU cut edge well, it may damage the CPU.

4. The Intel Pentium4/Celeron processor requires a set of heatsink/fan to ensure proper cooling of the processor. If heatsink/fan have not been already bundled with your CPU, you must purchase the heatsink/fan separately and have it installed. Plug the cable through the heatsink/fan in the CPU fan power connector located nearby. Note that there are several types of CPU fan connectors. Normally, if your mainboard supports the hardware monitoring function, a 3-pin fan power connector should allow your system to detect the CPU fan's speed. The CPU fan can also run with a 2-pin fan power connector, however, detection of CPU fan's speed is not supported. Another type of CPU fan may feature a large 4-pin fan power connector, which does not support CPU fan's speed detection and must be directly connected to the system's power supply unit.

Step 2.

Set Jumpers

The default jumper settings have been set for the common usage standard of this mainboard. Therefore, you do not need to reset the jumpers unless you require special adjustments as any of the following cases:

1. Clear CMOS
2. BIOS Write Protect


For first-time DIY system builders, we recommend that you do not change the default jumper settings if you are not totally familiar with the mainboard configuration procedures. The factory-set default settings are tuned for optimum system performance. For the advanced users who wish to customize their system, section 3.2 Jumper Settings will provide detailed information on how to configure your mainboard manually.

Step 3

Install DDR SDRAM System Memory

To install memory, insert DDR SDRAM memory module(s) in DIMM slot(s). Note that DDR SDRAM modules are directional and will not go in the DIMM slots unless properly oriented. After the module is fully inserted into the DIMM slots, lift the clips of both sides of the DIMM slot to lock the module in place.

DDR SDRAM



Step 4

Install Internal Peripherals in System Case

Before you install and connect the mainboard into your system case, we recommend that you first assemble all the internal peripheral devices into the computer housing, including but not limited to the hard disk drive (IDE/HDD), floppy disk drive (FDD), CD-ROM drive, and ATX power supply unit. This will greatly facilitate in making the connections to the mainboard described below.


To install IDE & FDD drives, follow this procedure:

1. Set the required jumpers on each device according to the instructions provided by the manufacturer. (IDE devices, HDD, and CD-ROM, have to set jumpers to Master or Slave mode depending on whether you install more than one device of each kind.)
2. Connect IDE cable and FDD cable on the back-panel of the internal peripheral devices to the corresponding headers on board. Note that the cable should be oriented with its colored stripe (usually red or magenta) connected to pin#1 both on the mainboard IDE or FDD connector and on the device as well.
3. Connect an available power cable from your system power supply unit to the back-panel of each peripheral device. Note that the power cable is directional and cannot fit in if not properly positioned.

Step 5

Mount the Mainboard on the Computer Chassis

1. You may find that there are a lot of different mounting hole positions both on your computer chassis and on the mainboard. To choose correct mounting holes, the key point is to keep the back-panel of the mainboard in a close fit with your system case, as shown below.



2. After deciding on the proper mounting holes, position the studs between the frame of the chassis and the mainboard. The studs are used to fix the mainboard and to keep a certain distance between the system chassis and the mainboard, in order to avoid any electrical shorts between the board and the metal frame of the chassis. (If your computer case is already equipped with mounting studs, you will need to tighten screws to attach the mainboard.)


Note: In most computer housings, you will be able to find 4 or more attachment points to install mounting studs and then fix the mainboard. If there aren't enough matching holes, then make sure to install at least 4 mounting studs to ensure proper attachment of the mainboard.

Step 6


Connect Front Panel Switches/LEDs/Speaker/USB

You can find there are several different cables already existing in the system case and originating from the computer front-panel devices (HDD LED, Power LED, Reset Switch, PC Speaker, or USB devices etc.) These cables serve to connect the front-panel switches, LEDs, and USB connectors to the mainboard front-panel connectors group (USB2/USB3 and PANEL1, SPEAKER1,AUDIO1), as shown below.


1.USB2/USB3




2.PANEL1



3.SPEAKER 1




4.AUDIO 1




Step 7

Connect IDE and Floppy Disk Drives

1. IDE cable connector




2. Floppy cable connector




Step 8

Connect Other Internal Peripherals



1. CDIN1/CDIN2 connectors



2. IR header




4. Wake On LAN and Wake On Modem headers



Step 9

Connect the Power Supply


1. System power connector




Step 10

Install Add-on Cards in Expansion Slots


1. AGP Card



2. PCI Card




3. CNR Card




Step 11

Connect External Peripherals to Back-Panel

You are now ready to put the computer case back together and get on to the external peripherals connections to your system's back-panel.



1. PS/2 Mouse and PS/2 Keyboard
2. COM1 Port
3. VGA Port
4. Parallel Port
5. Audio Line-Out /Line-In / Mic-In Ports
6. MIDI/GAME Port
7. LAN Port (MS52PN only)
8. USB ports



Step 12

First Time System Boot Up

To assure the completeness and correctness of your system installation, you may check the above installation steps once again before you boot up your system for the first time.

1. Insert a bootable system floppy disk (DOS 6.2x, Windows 95/98/NT, or others) which contains FDISK and FORMAT utilities into the FDD.
2. Turn on the system power.
3. First, you must use the FDISK utility to create a primary partition of the hard disk. You can also add an extended partition if your primary partition does not use all of the available hard disk space. If you choose to add an extended partition, you will have to create one or more logical partitions to occupy all the space available to the extended partition. The FDISK utility will assign a drive letter (i.e., C:, D:, E:,...) to each partition which will be shown in the FDISK program. After FDISK procedure, reboot your system by using the same system floppy disk.

Note: DOS 6.2x and Windows 95A can only support up to 2.1GB of HDD partition. If you use the FDISK utility with one of the operating systems mentioned above, you can only install your HDD into partitions no larger than 2.1GB each.

4. Now, use the FORMAT utility to format all the partitions you've created. When formatting the primary partition (C:), make sure to use the `FORMAT C: /S` command.

Note: `FORMAT C: /S` can transfer all the necessary system files into the primary partition of your hard disk. Then, your HDD will become a bootable drive.

5. Install all the necessary drivers for CD-ROM, Mouse, etc.
6. Setup the complete operating system according to your OS installation guide.

Step 13

Install Drivers & Software Components

Please note that all the system utilities and drivers are designed for Win 9x/2000/ME/XP/NT operating systems only. Make sure your operating system is already installed before running the drivers installation CD-ROM programs.

1. Insert the MS52P/MS52PN bundled CD-ROM into your CD-ROM drive. The autorun program will display the drivers main installation window on screen.
2. Choose "Install VGA Device Driver" and complete it.
3. Choose "Install SIS AGP Driver" and complete it.
4. Choose "Install Audio Device Driver" and complete it.
5. Choose "Install LAN Driver" and complete it. (MS52PN only)
6. Choose "Install USB 2.0 Driver" and complete it.
7. Exit from the autorun drivers installation program.

⚙ Please refer to section Chapter 4 Software Utility to install driver.

3.2 Jumper Settings

Several hardware settings are made through the use of mini jumpers to connect jumper pins on the mainboard. Pin #1 could be located at any corner of each jumper, you just find the location with a white right angle which stands for pin 1#. There are several types of pin 1# shown as below:

3-pin and multi (> 3) pin jumpers shown as following:

Pin #1 to the left:



Pin #1 on the top:





Pin #1 to the right:



Pin #1 on the bottom:




Jumpers with two pins are shown as  for Close [On] or  for Open [Off]. To Short jumper pins, simply place a plastic mini jumpers over the desired pair of pins.

Caution!

1. Do not remove the mainboard from its antistatic protective packaging until you are ready to install it.
2. Carefully hold the mainboard by its edges and avoid touching its components. When putting the mainboard down, place it on top of its original packaging film, on an even surface, and components side up.
3. Wear an antistatic wrist strap or take other suitable measures to prevent electrostatic discharge (ESD) whenever handling this equipment.

Jumpers & Connectors Guide

Use the mainboard layout on page 11 to locate CPU socket, memory banks, expansion slots, jumpers and connectors on the mainboard during the installation. The following list will help you to identify jumpers, slots, and connectors along with their assigned functions:



CPU/Memory/Expansion Slots

- | | |
|-----------|--|
| Socket478 | : CPU Socket for Pentium 4 processors |
| DIMM1/2 | : Two 184-pin DIMM Slots for 128, 256, 512 MB, and 1GB of 2.5V DDR SDRAM
(The total installed memory does not exceed 2GB) |
| AGP | : One AGP (Accelerated Graphics Port) Slot |
| PCI | : Three 32-bit PCI Expansion Slots |
| CNR | : One CNR (Communications and Network Riser) Slot |

Jumpers

- | | | |
|-----------|-----|---------------------------------|
| A1 | JP1 | : Clear CMOS setting |
| A2 | JP3 | : BIOS Write Protection setting |

Back Panel Connectors

- | | | |
|------------|-----------|--------------------------------------|
| B1 | PSKBM1 | : PS/2 keyboard port |
| B2 | PSKBM1 | : PS/2 mouse port |
| B3 | COM1 | : Serial port |
| B4 | VGA1 | : VGA port |
| B5 | LPT1 | : Parallel port |
| B6 | LINE_OUT | : Line-Out port |
| B7 | LINE_IN | : Line-In port |
| B8 | MIC_IN | : Mic-In port |
| B9 | GAME/MIDI | : GAME/MIDI port |
| B10 | LAN1 | : RJ45 LAN port (MS52PN only) |
| B11 | USB | : 2 USB (Universal Serial Bus) ports |

Front Panel Connectors

- | | | |
|-----------|----------|--|
| C1 | PWRSW | : ATX power on/off momentary type switch |
| C2 | GRNLED | : Green LED |
| C3 | HDLED | : IDE drive active LED |
| C4 | RST | : Hardware Reset Switch |
| C5 | SPEAKER1 | : speaker connector |
| C6 | AUDIO1 | : Front audio connector |
| C7 | USB2/3 | : Extended USB connector headers |

Internal Peripherals Connectors

- | | | |
|-----------|------|--|
| D1 | FDD1 | : Floppy disk drive connector |
| D1 | IDE1 | : IDE primary interface (Dual-channel) |
| D1 | IDE2 | : IDE secondary interface (Dual-channel) |



Other Connectors

- E1** ATX1 : ATX 12V power connector
- E1** ATX2 : ATX power connector
- E2** CDIN1/CDIN2 : Primary/ Secondary CD_IN connectors
- E3** WOM1 : Wake On Modem wakeup connector
- E4** WOL1 : Wake On LAN wakeup connector
- E5** CPUFAN1 : CPU fan connector
- E5** CASFAN1 : Case fan connector 1
- E5** PWRFAN1 : Case fan connector 2
- E6** IR1 : Infrared header

Jumpers

A1 Clear CMOS Setting (JP1)

JP1 is used to clear CMOS data. Clearing CMOS will result in the permanently erasing previous system configuration settings and the restoring original (factory-set) system settings.



- Step 1. Turn off the system power (PC-> Off).

Step 2. Remove ATX Power cable from ATX Power connector.

Step 3. Remove jumper cap from JP1 pins 1-2.

Step 4. Place the jumper cap on JP1 pin 2-3 for a few seconds.

Step 5. Return the jumper cap to pin 1-2.



Step 6. Plug ATX Power cable into ATX Power connector.

Step 7. Turn on the system power (PC-> On).

A2 BIOS Write Protection (JP3)

JP3 is used to protect BIOS from abnormal writing.


You may choose to place mini jumper on pin2-3 for BIOS write protection; however, please to place mini jumper on pin1-2 if you need to reflash BIOS.



Back-Panel Connectors


B1~B2 PS/2 Keyboard & PS/2 Mouse Connectors

Two 6-pin female PS/2 keyboard & Mouse connectors are located at the rear panel of the mainboard. Depending on the computer housing you use (desktop or tower), the PS/2 Mouse connector is situated at the top of the PS/2 Keyboard connector when the mainboard is laid into a desktop, as opposed to a tower where the PS/2 Mouse connector is located at the right of the PS/2 Keyboard's. Plug the PS/2 keyboard and mouse jacks into their corresponding connectors.




B3 COM1 Port Connector

This mainboard can accommodate one serial device on COM1. Attach a serial device cable to the DB9 serial port COM1 at the back panel of your computer.



B4 VGA Connector


One 15-pin VGA connector is located at the rear panel of the mainboard.



B5 Parallel Port Connector


One DB25 female parallel connector is located at the rear panel of the mainboard.

Plug the connection cable from your parallel device (printer, scanner, etc.) into this connector.




B6 Line-Out Port Connector

Line-Out is a stereo output port through which the combined signal of all internal and external audio sources on the board is output. It can be connected to 1/8-inch TRS stereo headphones or to amplified speakers




B7 Line-In Port Connector

Line-In is a stereo line-level input port that accepts a 1/8-inch TRS stereo plug. It can be used as a source for digital sound recording, a source to be mixed with the output, or both.




B8 Mic-In Port Connector

Mic-In is a 1/8-inch jack that provides a mono input. It can use a dynamic mono or stereo microphone with a resistance of not more than 600 Ohms.



B9 GAME/MIDI Port Connector

The MIDI/GAME port is a 15-pin female connector. This port can be connected to any IBM PC compatible game with a 15-pin D-sub connector.




MIDI Instrument Connection

You will need a MIDI adapter to connect a MIDI compatible instrument to the sound card. The MIDI adapter can in turn be connected to the Joystick/MIDI port. You will also need the MIDI sequencing software to run MIDI instruments with your computer etc. into this connector.

B10 LAN Port Connector (MS52PN only)


This mainboard can accommodate one device on LAN.

Attach a 10/100 baseT cable to the RJ45 at the back-panel of your computer.



B11 USB port1/USB port2 Connectors


This mainboard offers 2 USB ports on back panel. Plug each USB device jack into an available USB port1/USB port2 connector.



Front-Panel Connectors

❶ ATX Power On/Off Switch Connector (PWRSW)

The Power On/ Off Switch is a momentary-type switch used for turning on or off the system's ATX power supply. Attach the connector cable from the Power Switch to the 2-pin Power Switch header on the mainboard.




❷ Green LED Connector (GRN LED)

The Green LED (GRN LED) indicates that the system is currently in one of the power saving mode (Doze//standby/Suspend). When the system resumes to normal operation mode, the Green LED will go off. Attach a 2-pin Green LED cable to GRN LED header.


Note:

Please note all the LED connectors are directional. If your chassis's LED does not light up during running, please simply change to the opposite direction.




❸ HDD LED Connector (HDD LED)

Attach the connector cable from the IDE device LED to the 2-pin HDD LED header. The HDD LED lights up whenever an IDE device is active.



C4 Hardware Reset Connector (RST)

Attach the 2-pin hardware reset switch cable to the Reset Switch header. Pressing the reset switch causes the system to restart.




C5 Speaker Connector (SPEAKER1)

Attach the PC speaker cable from the case to the 4-pin speaker connector (SPEAKER1).

Pin assignment:

1. Signal
2. Key
3. Ground
4. VCC




C6 Front-Oriented Microphone /Line-out Port Header (AUDIO1)

This header allows the user to install auxiliary front-panel1 microphone and line-out ports for easier access. When frontpanel Microphone and line-out ports are not used, make sure to place two attached mini jumpers to the right position shown as below.



Two mini jumper must be setted on pin 9-10 and pin pin5-6, when this header is not used.




Pin assignment:

- | | | |
|---------------|----------------|-----------------|
| 1. AUD_MIC | 2. AUD_GND | 3. AUD_MIC_BIAS |
| 4. AUD_VCC | 5. AUD_FPOUT_R | 6. AUD_RET_R |
| 7. HP_ON | 8. KEY | 9. AUD_FPOUT_L |
| 10. AUD_RET_L | | |

⑦ Extended USB Headers (USB2/USB3)

The headers are used to connect the cable attached to USB connectors which are mounted on front panel or back panel. But the USB cable is optional at the time of purchase.



Pins Assignment:

1 = VREG_FP_USBPWR0

3 = USB_FP_P0-

5 = USB_FP_P0+

7 = GND

9 = KEY

2 = VREG_FP_USBPWR0

4 = USB_FP_P1-

6 = USB_FP_P1+

8 = GND


10 = USB_FP_OC0

Internal Peripherals Connectors

D1 Enhanced IDE and Floppy Connectors

The mainboard features two 40-pin dual-channel IDE device connectors (IDE1/IDE2) providing support for up to four IDE devices, such as CD-ROM and Hard Disk Drives (H.D.D.).

This mainboard also includes one 34-pin floppy disk controller (FLOPPY1) to accommodate the Floppy Disk Drive (FDD). Moreover, this mainboard comes with one 80-pin ATA 133/100/66/33 ribbon cable to connect to IDE H.D.D. and one 34-pin ribbon cable for F.D.D. connection.




Important: Ribbon cables are directional, therefore, make sure to always connect with the red cable stripe on the same side as pin #1 of the IDE1/IDE2 or FDD1 connector on the mainboard.

☞ Other Connectors

Ⓔ1 ATX Power Supply Connectors (ATX1/ATX2)

This motherboard uses 20-pin Pentium 4 standard ATX power header, ATX2 and comes with another header ATX1. ATX1 is with 2x2-pin + 12 V PC ATX power supply header. Please make sure you plug in the right direction.



A traditional ATX system should remain at power off stage when AC power resumes from power failure. In such case, if there is no an UPS to keep power-on, the kind of design is inconvenient for a network server or workstation. However, this motherboard implements an AC Power Auto Recovery function to solve this problem. You may enable the function "PWRON After PWR-Fail" that is under sub-menu of "Power Management Setup" through BIOS setup program.

- Note 1: The ATX power connector is directional and will not go in unless the guides match perfectly making sure that pin#1 is properly positioned.


Note 2: Make sure the latch of the ATX power connector clicks into place to ensure a solid attachment.

Note 3: Your ATX power supply must be supplied to ACPI + 5V standby power and at least 720mA compatible.

Note 4: Make sure your power supply have enough power for higher speed processor installed.

Ⓔ2 Audio CD_IN Connector (CDIN1/CDIN2)

Use the audio cable provided with the CD-ROM/DVD drive to connect to the mainboard CD-in connector CDIN1 or CDIN2.




E3 Wake-On-Modem Connector (WOM1)

Attach a 3-pin connector through the Modem card which supports the Wake-On-Modem (WOM1) function. This function lets users wake up the connected system through the Modem card.

Pins Assignment:

- 1 = 5VSB
- 2 = GND
- 3 = Ring#




E4 Wake-On-LAN Connector (WOL1)

Attach a 3-pin connector through the LAN card which supports the Wake-On-LAN (WOL1) function. This function lets users wake up the connected system through the LAN card.

Pins Assignment:

- 1 = 5VSB
- 2 = Ground
- 3 = Ring#





E5 CPU, Case Fan connectors - CPUFAN1/CASFAN1/PWRFAN1

The mainboard provides three onboard 12V cooling fan power connectors to support CPU (CPUFAN1), Case (CASFAN1/PWRFAN1) cooling fans.

Note:

Both cable wiring and type of plug may vary, which depends on the fan maker. Keep in mind that the red wire should always be connected to the +12V header and the black wire to the ground (GND) header.




E6 IR Header (IR1)

If you have an Infrared device, this mainboard can implement IR transfer function. To enable the IR transfer function, follow these steps:

Pins Assignment:

- 1 = Not assigned
- 2 = KEY
- 3 = +5V
- 4 = GND
- 5 = IRTX
- 6 = IRRX



Note: Before connect your IR device, please be sure each IR on board pin allocation is matchable with the pin of the IR device. Otherwise, incorrect IR connection may do damage to your IR device.

- Step 1. Attach the 6-pin infrared device cable to IR1.
(Refer to the above diagram for IR pin assignment.)
- Step 2. This mainboard supports Normal, IrDA transfer modes.

3.3 System Memory Configuration

The MS52P/MS52PN mainboard has two 184-pin DIMM slots that allow you to install from 128MB up to 2GB of system memory.

Each 184-pin DIMM (Dual In-line Memory Module) Slot can accommodate , 128MB, 256MB, 512MB, and 1GB of PC1600/PC2100/PC2700 compliant 2.5V single (1 Bank) or double (2 Bank) side 64-bit wide data path DDR SDRAM modules.

Install Memory:

Install memory in any or all of the slots and in any combination shown as follows.

DIMM	Memory Modules	Module Quantity
DIMM 1	128MB, 256MB, 512MB, and 1GB 184-pin 2.5V DDR SDRAM DIMM	x 1
DIMM 2	128MB, 256MB, 512MB, and 1GB 184-pin 2.5V DDR SDRAM DIMM	x 1

Note: Maximum installed memory is 2GB.

Note: You do not need to set any jumper to configure memory since the BIOS utility can detect the system memory automatically. You can check the total system memory value in the BIOS Standard CMOS Setup menu.

Upgrade Memory:

You can easily upgrade the system memory by inserting additional DDR SDRAM modules in available DIMM slots. The total system memory is calculated by simply adding up the memory in all DIMM slots. After upgrade, the new system memory value will automatically be computed and displayed in the field " Standard CMOS Setup" of BIOS setup program.

4 SOFTWARE UTILITY


4.1 Mainboard CD Overview

Note: The CD contents attached in MS52P/MS52PN mainboard are subject to change without notice.

To start your mainboard CD disc, just insert it into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click or run D:\Autorun.exe (assuming that your CD-ROM drive is drive D:)

Navigation Bar Description:

- ☞ Install Mainboard MS52P Software - Installing VGA, SIS AGP, Audio, USB2.0 drivers.
- ☞ Install Mainboard MS52PN Software - Installing VGA, SIS AGP, Audio, LAN and USB2.0 drivers.
- ☞ Manual - MS52P & MS52PN Series mainboard user's manual in PDF format.
- ☞ Link to Shuttle Homepage - Link to shuttle website homepage.
- ☞ Browse this CD - Allows you to see contents of this CD.
- ☞ Quit - Close this CD.



4.2 Install Mainboard Software

Insert the attached CD into your CD-ROM drive and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on Autorun icon in My Computer to bring up Shuttle Mainboard Software Setup screen.

Select using your pointing device (e.g. mouse) on the "Install Mainboard MS52P Software" or "Install Mainboard MS52PN Software" bar to run into sub-menu.


The Mainboard MS52P Software include:

- [4.3] Install VGA Device Driver
- [4.4] Install SIS AGP Driver
- [4.5] Install Audio Device Driver
- [4.7] Install USB2.0 Driver



The Mainboard MS52PN Software include:


- [4.3] Install VGA Device Driver
- [4.4] Install SIS AGP Driver
- [4.5] Install Audio Device Driver
- [4.6] Install LAN Driver (MS52PN only)
- [4.7] Install USB2.0 Driver




4.3 Install VGA Device Driver

Select using your pointing device (e.g. mouse) on the "Install VGA Device Driver" bar to install VGA driver.

MS52P



MS52PN



Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.4 Install SiS AGP Driver

Select using your pointing device (e.g. mouse) on the "Install SiS AGP Driver" bar to install SiS AGP Driver.

MS52P



MS52PN




Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.5 Install Audio Device Driver

Select using your pointing device (e.g. mouse) on the "Install Audio Device Driver" bar to install Audio Device driver.

MS52P



MS52PN




Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.6 Install LAN Driver (MS52PN only)

Select using your pointing device (e.g. mouse) on the “Install LAN Driver” bar to install LAN driver.




Once you made your selection, a Setup window run the installation automatically.

When the copying files is done, make sure you reboot the system to take the installation effect.

4.7 Install USB2.0 Driver

Select using your pointing device (e.g.mouse) on the "Install USB Driver" bar to install USB 2.0 driver.

MS52P



MS52PN



Once you made your selection, a setup window run the installation automatically. When the copying file is done, make sure your reboot the system to take the installation effect.

4.8 View the User's Manual

Insert the attached CD into your CD-ROM driver and the CD AutoRun screen should appear. If the AutoRun screen does not appear, double click on Autorun icon in My Computer to bring up Shuttle Mainboard Software Setup screen.

Select using your pointing device (e.g.mouse) on the "manual" bar.



Then Online Information windows will appear on your screen. Click on the " Install Acrobat Reader " bar if you need to install acrobe reader.



Then click on " MSS2P/MSS2PN Manual" bar to view user's manual.

5 BIOS SETUP

MS52P/MS52PN BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in battery-backed RAM so that it retains the Setup information even if the system power is turned off.

The system BIOS is managing and executing a variety of hardware related functions in the system, including:

System date and time

Hardware execution sequence

Power management functions

Allocation of system resources

5.1 Enter the BIOS

To enter the BIOS (Basic Input / Output System) utility, follow these steps:

- Step 1. Power on the computer, and the system will perform its POST (Power-On Self Test) routine checks.
- Step 2. Press key immediately, or at the following message:
Press DEL to enter SETUP, or simultaneously press <Ctrl>, <Alt>, <Esc> keys

Note 1. If you miss trains of words meationed in step2 (the message disappears before you can respond) and you still wish to enter BIOS Setup, restart the system and try again by turning the computer OFF and ON again or by pressing the <RESET> switch located at the computer's front-panel. You may also reboot by simultaneously pressing the <Ctrl>, <Alt>, keys.


Note 2. If you do not press the keys in time and system does not boot, the screen will prompt an error message, and you will be given the following options:

"Press F1 to Continue, DEL to Enter Setup"

- Step 3. As you enter the BIOS program, the CMOS Setup Utility will prompt you the Main Menu, as shown in the next section.

5.2 The Main Menu

Once you enter the AwardBIOS(tm) CMOS Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and two exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.



Note that a brief description of each highlighted selection appears at the bottom of the screen.

Setup Items

The main menu includes the following main setup categories. Recall that some systems may not include all entries.

Standard CMOS Features

Use this menu for basic system configuration.

Advanced BIOS Features

Use this menu to set the Advanced Features available on your system.

Advanced Chipset Features

Use this menu to change the values in the chipset registers and optimize your system's performance.

Integrated Peripherals

Use this menu to specify your settings for integrated peripherals.

Power Management Setup

Use this menu to specify your settings for power management.

PnP / PCI Configurations

This entry appears if your system supports PnP / PCI.

PC Health Status

This entry shows the current system temperature, Voltage, and FAN speed.

Frequency/Voltage Control

Use this menu to specify your settings for frequency/voltage control.

Load Fail-Safe Defaults

Use this menu to load the BIOS default values for the minimal/stable performance of your system to operate.

Load Optimized Defaults

Use this menu to load the BIOS default values that are factory-set for optimal performance system operation. While Award has designed the custom BIOS to maximize performance, the factory has the right to change these defaults to meet users' needs.

Set Password

Use this menu to change, set, or disable password. It allows you to limit access to the system and Setup, or only to Setup.

Save & Exit Setup

Save CMOS value changes in CMOS and exit from setup.

Exit Without Saving

Abandon all CMOS value changes and exit from setup.



Standard CMOS Features

The items in Standard CMOS Setup Menu are divided into 10 categories. Each category includes no, one or more than one setup items. Use the arrow keys to highlight the item and then use the <PgUp> or <PgDn> keys to select the value you want in each item.

Phoenix - Award WorkstationBIOS CMOS Setup Utility Standard CMOS Features		
Date (mm:dd:yy)	Tue, Mar 4 2003	Item Help Menu Level ▶ Change the day, month, year and century
Time (hh:mm:ss)	14 : 14 : 28	
▶ IDE Primary Master		
▶ IDE Primary Slave		
▶ IDE Secondary Master		
▶ IDE Secondary Slave		
Drive A	[1.44M, 3.5 in.]	
Drive B	[None]	
Floppy 3 Mode Support	[Disabled]	
Video	[EGA/VGA]	
Halt On	[All Errors]	
Base Memory	640K	
Extended Memory	65535K	
Total Memory	1024K	
↑↓:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults		

Date

<Month> <DD> <YYYY>

Set the system date. Note that the 'Day' automatically changes when you set the date.

Time

<HH : MM : SS>

The time is converted based on the 24-hour military-time clock. For example, 5 p.m. is 17:00:00.

IDE Primary Master

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

IDE Primary Slave

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

IDE Secondary Master

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

IDE Secondary Slave

Options are in its sub menu.

Press <Enter> to enter the sub-menu of detailed options.

Drive A/Drive B

Select the type of floppy disk drive installed in your system.

- The choice: None, 360K, 5.25 in, 1.2M, 5.25 in, 720K, 3.5 in, 1.44M, 3.5 in, or 2.88M, 3.5 in.

Floppy 3 Mode Support

This Item enable/disable the Floppy mode 3 options. This mode is used mostly in Japan PC.

- The choice: Disabled, Drive A, Drive B, or Both.

Video

Select the default video device.

- The choice: EGA/VGA, CGA 40, CGA 80, or MONO.

Halt On

Select the situation in which you want the BIOS to stop the POST process and notify you.

- The choice: All Errors, No Errors, All, But Keyboard, All, But Diskette, or All, But Disk/Key.

Base Memory

Displays the amount of conventional memory detected during boot up.

- The choice: N/A.

Extended Memory

Displays the amount of extended memory detected during boot up.

- The choice: N/A.

Total Memory

Displays the total memory available in the system.

- The choice: N/A.

IDE Adapters

The IDE adapters control the hard disk drive. Use a separate sub-menu to configure each hard disk drive.

IDE HDD Auto-Detection

Press <Enter> to auto-detect HDD on this channel. If detection is successful, it fills the remaining fields on this menu.

- Press Enter

IDE Primary Master

Selecting 'manual' lets you set the remaining fields on this screen and select the type of fixed disk. "User Type" will let you select the number of cylinders, heads, etc., Note: PRECOMP = 65535 means NONE!

- The choice: None, Auto, or Manual.

Access Mode

Choose the access mode for this hard disk.

- The choice: CHS, LBA, Large, or Auto.

Capacity

Disk drive capacity (Approximated). Note that this size is usually slightly greater than the size of a formatted disk given by a disk checking program.

- Auto-Display your disk drive size.

The following options are selectable only if the 'IDE Primary Master' item is set to 'Manual'

Cylinder

Set the number of cylinders for this hard disk.

- Min = 0, Max = 65535

Head

Set the number of read/write heads.

- Min = 0, Max = 255

Precomp

Warning: Setting a value of 65535 means no hard disk.

- Min = 0, Max = 65535

Landing zone

Set the Landing zone size.

- Min = 0, Max = 65535

Sector


Number of sector per track.

- Min = 0, Max = 255



Advanced BIOS Features

This section allows you to configure your system for basic operation. You have the opportunity to select the system's default speed, boot-up sequence, keyboard operation, shadowing, and security.



Virus Warning

Allows you to choose the VIRUS Warning feature for IDE Hard Disk boot sector protection. If this function is enabled and someone attempts to write data into this area, BIOS will show a warning message on screen, and an alarm beep.

Enabled Activates automatically when the system boots up, causing a warning message to appear when anything attempts to access the boot sector or hard disk partition table.

Disabled No warning message will appear when anything attempts to access the boot sector or hard disk partition table.

➤ The choice: Enabled or Disabled.

CPU L1 & L2 Cache

This item enables CPU L1 internal and CPU secondary cache to speed up memory access.

➤ The choice: Enabled or Disabled.

Hyper-Threading Technology

This item allows you to enable or disable CPU Hyper-Threading function. If it is set to enable, the CPU performance will better.

- The choice: Enabled, or Disabled.

Quick Power On Self Test

This item speeds up Power-On Self Test (POST) after you power on the computer. If it is set to enabled, BIOS will shorten or skip some check items during POST.

- The choice: Enabled, or Disabled.

First/Second/Third Boot Device

The BIOS attempts to load the operating system from the devices in the sequence selected in these items.

- The Choice: Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, USB-FDD, USB-ZIP, USB-CDROM, USB-HDD, LAN, or Disabled.

Boot Other Device

Select Your Boot Device Priority.

- The choice: Enabled or Disabled.

Swap Floppy Drive

If the system has two floppy drives, you can swap the logical drive name assignment.

- The choice: Enabled or Disabled.

Boot Up Floppy Seek

Seeks disk drives during boot-Up. Disabling speed boots up.

- The choice: Enabled or Disabled.

Boot Up NumLock Status

Selects power-on state for NumLock.

- The choice: Off or On.

Gate A20 Option

This entry allows you to select how the gate A20 is handled. The gate A20 is a device used for above 1MByte of address memory. Initially, the gate A20 was handled via a pin on the keyboard. Today, while a keyboard still provides this support, it is more common and much faster in setting to Fast for the system chipset to provide support for gate A20.

- The choice: Normal, or Fast.

ATA 66/100 Cable MSG

This item enables or disables the display of the ATA 66/100 Cable MSG.

- The choice: Enabled, Disabled.

Typematic Rate Setting

Keystrokes repeat at a rate determined by the keyboard controller. When this controller enabled, the typematic rate and typematic delay can be selected.

- The choice: Enabled or Disabled.

Typematic Rate (Chars/Sec)

This item sets how many times the keystroke will be repeated in a second when you hold the key down.

- The choice: 6, 8, 10, 12, 15, 20, 24, or 30.

Typematic Delay (Msec)

Sets the delay time after the key is held down before it begins to repeat the keystroke.

- The choice: 250, 500, 750, or 1000.

Security Option

Select whether the password is required every time the system boots or only when you enter setup.

- | | |
|--------|--|
| System | The system will not boot and access to Setup will be denied if the correct password is not entered promptly. |
| Setup | The system will boot, but access to Setup will be denied if the correct password is not entered promptly. |

- The choice: System or Setup.

Note: To disabled security, select PASSWORD SETTING at Main Menu, and then you will be asked to enter password. Do not type anything and just press <Enter>; it will disable security.
Once the security is disabled, the system will boot, and you can enter Setup freely.

APIC Mode

Selects enable/disable IO APIC function

- The choice: Enabled or Disabled.

OS Select For DRAM > 64MB

Selects the operating system that is running with greater than 64MB of RAM in the system.

- The choice: Non-OS2 or OS2.

HDD S.M.A.R.T. Capability

This item enable/disable the HDD system management function.

- The choice: Enabled or Disabled.

Report No FDD For Win 95

Whether report no FDD runs for Win 95 or not.

- The choice: Yes or No.

Small Logo(EPA) Show


This item allows you to enable/disable the EPA Logo.

- The choice: Enabled or Disabled.

Advanced Chipset Features

This section allows you to configure the system based on the specific features of the installed chipset. This chipset manages bus speeds and access to system memory resources, such as DRAM and the external cache. It also coordinates communications between the conventional ISA bus and the PCI bus. It states that these items should never need to be altered.

The default settings have been chosen because they provide the best operating conditions for your system. If you discovered that data was being lost while using your system, you might consider making any changes.



Advanced DRAM Control 1

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

System Performance

This item select the system timing(Safe/Normal/Fast/Ultra) for DDR SDRAM,

- The Choice: Safe Mode, Normal Mode, Fast Mode, Turbo Mode, or Ultra Mode.

CAS Latency Setting

This item select the CAS latency for DDR SDRAM

- The Choice: 2T, 2.5T, or 3T.

DRAM Addr/Cmd Rate

This item select the Cmd Rate of DDR SDRAM(1T/2T).

- The Choice: Auto Mode, 1T, or 2T.

Prefetch Caching

This item enable/disable the Prefetch cache function of DRAM controller

- The Choice: Enabled or Disabled.

Memory Hole at 15M-16M

You can reserve this area of system memory for ISA adapter ROM.

When this area is reserved, it cannot be cached. The user information of peripherals that need to use this area of system memory usually discusses their memory requirements.

- The Choice: Enabled or Disabled.

AGP Aperture Size

Select the size of Accelerated Graphics Port (AGP) aperture. The aperture is a portion of the PCI memory address range dedicated to graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation.


- The Choice: 4M, 8M, 16M, 32M, 64M, 128M, or 256M.

Graphic Window WR Combin

This item enable/disable the write combine function for Graphic address space.

- The Choice: Enabled or Disabled.

Integrated Peripherals



SIS OnChip IDE Device

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

Internal PCI/IDE

This chipset contains an internal PCI IDE interface with support for two IDE channels.

- The choice: Disabled, Primary, Secondary, or Both.

IDE Primary/Secondary Master/Slave PIO

The four IDE PIO (Programmed Input/Output) fields let you set a PIO mode (0-4) for each of the four IDE devices that the onboard IDE interface supports. Modes 0 through 4 provide successively increased performance. In Auto mode, the system automatically determines the best mode for each device.

- The choice: Auto, Mode 0, Mode 1, Mode 2, Mode 3, or Mode 4.

Primary/Secondary Master/Slave UltraDMA

Ultra DMA/100 implementation is possible only if your IDE hard drive supports it and the operating environment includes a DMA driver (Windows 95 OSR2 or a third-party IDE bus master driver). If both of your hard drive and your system software support Ultra DMA/100, select Auto to enable BIOS support.

- The choice: Auto or Disabled.

IDE DMA transfer access
Internal PCI/IDE field, above, is Disabled.

➤ The choice: Enabled or Disabled.

IDE Burst Mode

Selecting Enabled reduces latency between each drive read/write cycle, but may cause instability in IDE subsystems that cannot support such fast performance. If you are getting disk drive errors, try setting this value to Disabled. This field does not appear when the Internal PCI/IDE field, above, is Disabled.

➤ The choice: Enabled or Disabled.

SIS OnChip PCI Device

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

SIS-7012 AC97 AUDIO

This item allows you to control the onboard AC 97 audio.

➤ The Choice: Enabled or Disabled.

SIS-7013 S/W Modem

This item allows you to control the onboard modem.

➤ The Choice: Enabled or Disabled.

System Share Memory Size

This Item will be disabled by BIOS code. It is for 650 chipsets.

➤ The choice: 4MB, 8MB, 16MB, 32MB, or 64MB.

Onboard Super IO Device

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

Onboard FDC Controller

Select Enabled if your system has a floppy disk controller (FDC) installed on the system board and you want to use it. If you install add-on FDC or the system has no floppy drive, select Disabled in this field.

➤ The choice: Enabled or Disabled.

Onboard Serial Port1/Port2

Select an address and corresponding interrupt for the first and second serial ports.

➤ The choice: 3E8/IRQ4, 2E8/IRQ3, 3F8/IRQ4, 2F8/IRQ3, Auto, or Disabled.

UART Mode Select

This item allows you to select which mode for the Onboard Serial Port.

- The choice: Normal, or IrDA.

UR2 Duplex Mode

This item allows you to select the IR half/full duplex function.

- The choice: Full or Half.

Onboard Parallel Port

This item allows you to determine onboard parallel port controller I/O address setting.

- The choice: 378/IRQ7, 278/IRQ5, 3BC/IRQ7, or Disabled.

Parallel Port Mode

Select an operating mode for the onboard parallel (printer) port. Select Normal, Compatible, or SPP unless you are certain your hardware and software both support one of the other available modes.

- The choice: SPP, EPP, ECP, or ECP + EPP.

ECP Mode Use DMA

Select a DMA channel for the parallel port for use during ECP mode.

- The choice: 1 or 3.

Game Port Address

This item selects Game Port Address.

- The choice: Disabled, 201, 209.

Midi Port Address

This item selects Midi Port Address.

- The choice: Disabled, 330, or 300.

Midi Port IRQ

This item selects Midi Port IRQ.

- The choice: 5 or 10.

USB Controller

Select Enabled if your system contains a Universal Serial Bus (USB) controller and you have USB peripherals.

- The choice: Enabled or Disabled.

USB 2.0 support

Select Enabled if your system contains a Universal Serial Bus2.0 controller and you have USB peripherals.

- The Choice: Enabled or Disabled.

USB Keyboard Support

This item is used to defined USB Keyboard id Enabled or Disabled.

- The Choice: Enabled or Disabled.

USB Mouse Support

This item is used to defined USB Mouse id Enabled or Disabled.

- The Choice: Enabled or Disabled.

Onboard LAN

This item is used to enabled/disabled onboard LAN.

- The Choice: Enabled or Disabled.

Onboard LAN Boot ROM

This item is used to enabled/disabled onboard LAN boot ROM.

- The Choice: Enabled or Disabled.

IDE HDD Block Mode

The chipset contains a PCI IDE interface with support for two IED channels. Select Enabled to activate the primary and/or secondary IDE interface. Select Disabled to deactivate this interface, if you install a primary and/or secondary add-in IDE interface IDE interface.

- The choice: Enabled or Disabled.

Init Display First

This item is used to determine initial device when system power on.

- The choice: AGP or PCI Slot.

AGP Auto Calibration

This item enable/disable the AGP driving functions.

- The choice: EDB or Disabled.

IDECH0/IDECH1 Access Interface

This item determines whether the IDE access interface is the PCI bus or the embedded bus.

- The choice: EDB Bus or PCI Bus.

USB0/USB1/USB2/USB2.0 Access Interface

This option determines whether the USB0/USB1/USB2/USB2.0 access interface is the embedded bus or a PCI bus.

- The choice: EDB Bus, or PCI Bus.


Audio Access Interface

This option determines whether the audio access interface is the embedded bus or a PCI bus.

- The choice: EDB Bus, or PCI Bus.



Power Management Setup



The Power Management Setup allows you to configure your system to most effectively saving energy while operating in a manner consistent with your own style of computer use.

ACPI Function

This item allows you to enable/disable the Advanced Configuration and Power Management (ACPI)

- The choice: Enabled or Disabled.

ACPI Suspend Type

This item allows you to select sleep state when suspend.

- The choice: S1(POS), S3(STR), or S1 & S3.

Video Off Option

When enabled, this feature allows the VGA adapter to operate in a power saving mode.

Always On Monitor will remain on during power saving mode.

Suspend --> Off Monitor is blanked when the system enters the Suspend mode.

Susp,Stby --> Off Monitor is blanked when the system enters either Suspend or Standby modes.

All Modes --> Off Monitor is blanked when the system enters any power saving mode.

- The choice: Always On, Suspend -> Off, Susp,stby -> Off, or All Modes -> Off.

Video Off Method

This determines the manner in which the monitor is blanked.

Blank Screened This option only writes blanks to the video buffer.

V/H SYNC + Blank This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.

DPMS Support Initial display power management signaling.

➤ The choice: Blank Screen, V/H SYNC + Blank, or DPMS Supported.

MODEM Use IRQ

This determines the IRQ which the MODEM can use.

➤ The choice: 3, 4, 5, 7, 9, 10, 11, or Auto.

USB S3 WakeUp Function

This item allows you to enabled/disabled USB device activity to wake the system from S3.

➤ The choice: Enabled, Disabled.

HDD Off After

The IDE hard drive will spin down if it is not accessed within a specified length of time. Options are from 1 Min to 15 Min and Disable.

➤ The choice: Disabled, 1 Min ~ 15 Min.

Power Button Override

Pressing the power button for more than 4 seconds forces the system to enter the Soft-Off state when the system has "hung".

➤ The choice: Instant-Off or Delay 4 Sec.

Power State Resume Control

This sets the power state after a shutdown due to an unexpected interrupt of AC power.

➤ The choice: Always off, Always on, Keep Pre-state.

PM Wake Up Events

Options are in its sub-menu.

Press <Enter> to enter the sub-menu of detailed options.

IRQ [3-7, 9-15], NMI

When enabled, any event occurring at IRQs 3 through 15 (excluding IRQ 8) will awaken a system, which has been powered down.

➤ The choice: Enabled, Disabled.

IRQ 8 Break Suspend

This field allows you to enable or disable monitoring of IRQ8 so that it does not awaken the system from a suspend mode.

➤ The choice: Enabled, Disabled.

RING/WOL/WOM PowerUp Control

This item enabled/disabled LAN or modem activity to wakeup the system from a power saving mode.

➤ The choice: Enabled, Disabled.

PCIPME Power Up Control

This item enabled/disabled PCI activity to wakeup the system from a power saving mode.

➤ The choice: Enabled, Disabled.

Power Up by Alarm

When set to Enabled, the following three fields become available and you can set the month, date (day of the month), hour, minute and second to turn on your system.

➤ The choice: Enabled, Disabled.

*****Reload Global Timer Events*****

If any of these items is set to Disabled, system will not monitor the activity event and reload global timer.

If these items is set to Enabled, system will monitor the system activity event; if any of the events it monitored, it will cause system to reload global timer.

These items include Primary IDE/ Secondary IDE/ FDD, COM, LPT Port/ PCI PIRQ[A-D]#.

➤ The choice: Enabled, Disabled.

Month Alarm

This is for specifying the alarm month which system will awaken the system from suspend mode.

➤ The choice: NA, 1 ~ 12.

Day of Month Alarm

This item selects the alarm day.

➤ Key in a DEC number:Min = 1, Max = 31.

Time (hh : mm : ss) Alarm

This item selects the alarm Time.

[hh]

➤ Key in a DEC number:Min = 0, Max = 23.

[mm/ss]

➤ Key in a DEC number:Min = 0, Max = 59.

Delay prior to Thermal

This sets the delay time before the CPU enters auto thermal mode.

➤ The choice:None,1/2/4/8/16/32/64Min.



PnP/PCI Configurations

Phoenix - Award WorkstationBIOS CMOS Setup Utility	
PnP/PCI Configurations	
Reset Configuration Data	[Disabled]
Resources Controlled By	[Auto(ESCD)]
x IRQ Resources	Press Enter
PCI/VGA Palette Snoop	[Disabled]
INT Pin 1 Assignment	[Auto]
INT Pin 2 Assignment	[Auto]
INT Pin 3 Assignment	[Auto]
INT Pin 4 Assignment	[Auto]
INT Pin 5 Assignment	[Auto]
INT Pin 6 Assignment	[Auto]
INT Pin 7 Assignment	[Auto]
INT Pin 8 Assignment	[Auto]

Item Help
Menu Level ▶
Default is Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on and the system reconfiguration has caused such a serious conflict that the OS cannot boot

↑↓:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

This section describes the configuration of PCI bus system. PCI or Personal Computer Interconnection is a system which allows I/O devices to operate at the speed CPU itself keeps when CPU communicating with its own special components.

This section covers some very technical items, and it is strongly recommended that only experienced users should make any changes to the default settings.

Reset Configuration Data

Normally, you leave this field Disabled. Select Enabled to reset Extended System Configuration Data (ESCD) when you exit from Setup if you have installed a new device or software and the system reconfiguration has caused such a serious conflict that the operating system can not boot.

- The choice: Enabled or Disabled .

Resource controlled By

The Award Plug-and-Play BIOS has the capacity to automatically configure all of the boot and Plug-and-Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug-and-Play operating system such as Windows 95.

If you set this field to "manual" , choose specific resources by going into each of the sub-menu that follows this field (a sub-menu is proceeded by a ">").

- The choice: Auto(ESCD) or Manual.

IRQ Resources

When resources are controlled manually, assign each system interrupt a type, depending on the type of device using the interrupt.

IRQ3/4/5/7/9/10/11/12/14/15 assigned

This item allows you to determine the IRQ assigned to the ISA bus and is not available to any PCI slot. Legacy ISA for devices is compliant with the original PC AT bus specification; PCI/ISA PnP for devices is compliant with the Plug-and-Play standard whether designed for PCI or ISA bus architecture.

- The choice: PCI Device or Reserved.

PCI/VGA Palette Snoop

It determines whether the MPEG ISA/VESA VGA Cards can work with PCI/VGA or not. If you have MPEG ISA/VESA VGA Cards and PCI/VGA Card worked, Enable this field. Otherwise, please Disable it.

- The choice: Enabled or Disabled.

INT Pin 1-8 Assignment

Identifies the interrupt request (IRQ) line assigned to a device connected to the PCI interface of your system.

- The choice: Auto, 3, 4, 5, 7, 9, 10, 11, 12, 14, 15.



PC Health Status

Phoenix - Award WorkstationBIOS CMOS Setup Utility	
PC Health Status	
Shutdown Temperature	[Disabled]
CPU Core Voltage	
+1.8V	
+3.3V	
+5.0V	
+12V	
StandBy 3.3V	
StandBy 5.0V	
Voltage Battery	
CPU Temperature	
System Temperature	
CPUFAN Speed	
CASFAN1 Speed	
PWRFAN1 Speed	

Item	Help
Menu Level	▶

↑↓:Move Enter:Select +/-/PU/PD:Value F10:Save ESC:Exit F1:General Help
F5: Previous Values F6: Fail-Safe Defaults F7: Optimized Defaults

Shutdown Temperature

Enables you to set the maximum temperature the system can reach before powering down.

- The choice: Disabled, 60°C/140°F, 65°C/149°F, 70°C/158°F.

System Component Characteristics


These fields provide you with information about the systems current operating status. You cannot make changes to these fields.

The fields include

CPU Core Voltage
+ 1.8V
+ 3.3V
+ 5.0V
+ 12V
StandBy 3.3V
StandBy 5.0V
Voltage Battery
CPU Temperature
System Temperature
CPUFan Speed
CASFan1 Speed
PWRFan1 Speed



Frequency/Voltage Control



CPU Clock Ratio

This item allows you to adjust CPU Ratio.

Min: 8

Max: 50

- Key in a DEC number: (Between Min and Max.) or left it auto detect.

Auto Detect DIMM/PCI Clk

This item allows you to enable/disable auto detection DIMM/PCI Clock.

- The choice: Enabled, or Disabled.

Spread Spectrum

This item allows you to enable/disable the spread spectrum modulation.

- The choice: Enabled, or Disabled.

CPU Host/DRAM/PCI Clock

This item allows the user to adjust CPU Host Clock/DRAM/PCI Clock.

- The choice: Default, 100/100/33 MHz, 100/133/33 MHz, 100/166/33 MHz, 133/100/33MHz, 133/133/33MHz, 133/166/33MHz.



Load Fail-Safe Defaults

When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

Load Fail-Safe Defaults (Y/N) ? N

Pressing 'Y' loads the BIOS default values for the most stable, minimal performance system operations.




Load Optimized Defaults

When you press <Enter> on this item, you will get a confirmation dialog box with a message similar to:

Load Optimized Defaults (Y/N) ? N

Pressing 'Y' loads the default values that are factory-set for optimal performance system operation.

Set Password



This item is to set supervisor password. Please follow below steps.

New Password Setting :

1. While pressing <Enter> key to start setting password function, a dialog box appears to ask you "Enter password: ".
2. Key in a new password now. However, the password can not be over eight characters or numbers.
3. Then system will request you to confirm new password by asking you to key in new password again.
4. Once the confirmation is completed, new code takes effect.

No Password Setting :

5. If you want to delete password, just press <Enter> key instead of new password while password input is requested. And the other procedures are the same as above password setting.

If You Forget Password :

6. While being asked of password, you just forget it and you must access the system. The only way is to turn off system and clear CMOS memory. Please take reference in page 28 for clear CMOS setting.

Save & Exit Setup

Pressing <Enter> on this item asks for confirmation:

Save to CMOS and EXIT (Y/N)? Y

Pressing "Y" stores the selections made in the menus of CMOS - a special section of memory that stays on after you turn your system off. The next time you boot your computer, the BIOS configures your system according to the Setup selections stored in CMOS. After saving the values the system is restarted again.

Exit Without Saving

Pressing <Enter> on this item asks for confirmation:

Quit without saving (Y/N)? Y

This allows you to exit from Setup without storing in CMOS any change. The previous selections remain in effect. This exits from the Setup utility and restarts your computer.